# SHARP PARTS GUIDE

CODE: 00ZSF2216/P1/



# 複写機 (Copier)

## MODEL SF-2216

このパーツガイドに掲載されている表示価格ランクは消費税抜きです。

CONTENTS


1 外装(Exteriors)
2 操作部(Operation panel section)
3 オリジナルカバー(Original cover)
5 右キャビ下‥国内,USA,CANADA, 台湾以外
(Right exterior Lower ‥ Except
Japan,USA,CANADA,Taiwan)
6 光学ユニット 1(Optical unit 1)
7 光学ユニット 2(Optical unit 2)
8 レンズ駆動ユニット(Lens drive unit)
9 ミラーホルダーユニット(Mirror holder unit)
10 上フレーム 1(Upper frame 1)
11 上フレーム 2(Upper frame 2)
12 コピーランプユニット(Copy lamp unit)
13 トナーホッパーユニット(Toner hopper unit)
14 ドラムフレームユニット(Drum frame unit)
15 現像ユニット(Developer unit)
16 定着ユニット(Fusing unit)
17 給紙ユニット(Paper feeding unit)
18 メイン駆動ユニット(Main drive unit)
19 下フレーム 1(Lower frame 1)
20 下フレーム 2(Lower frame 2)
21 手差しマルチ給紙ユニット‥
国内,USA,CANADA, 台湾
(Manual multi paper feeding unit ‥
Japan,USA,CANADA,Taiwan)
22 手差しマルチ給紙トレイユニット‥
国内,USA,CANADA, 台湾
(Manual multi paper feeding tray unit ‥
Japan,USA,CANADA,Taiwan)
25 MCユニット(MC unit)
26 TCケースユニット(TC case unit)
27 250 トレイ (250 Tray)
28 梱包材 & 付属品
(Packing material&Accessories)
29 メイン基板(Main PWB)
30 操作基板(Operation PWB)
33 AC回路基板(AC circuit PWB)
34 DC電源基板(DC Power supply PWB)
35 サブDC基板(Sub DC PWB)
■ 索引 (Index)


本書はサービス活動用に作成した資料です。
一部内容が製品の改良・改善等により予告なしにかわることがあります。

SHARP CORPORATION

This document has been published to be used for after sales service only.
The contents are subject to change without notice.

## 補修部品のランク付

市場における補修部品の在庫管理が、適正に運営出来る手助けとなることを、目的とします。

Ａランク：取替頻度が比較的多く、在庫を必要とするパーツ。

Ｂランク：取替頻度は比較的少ないが、在庫を必要とするパーツ。

Ｃランク：取替頻度はほとんどないと思われるパーツ。

Ｄランク：取替頻度はほとんどないが新品再生に必要なパーツ。

Ｅランク：ユニットパーツ。サービス効率アップの為、在庫する事を推奨するパーツ。

Ｓランク：消耗品

但し、複写機のパーツについては、同一パーツ名であっても、下記パーツは、使用箇所の相違により、Ａ・Ｂランク分けします。

パーツ名：金属性のギャー、スプロケット、ベアリング、ゴム製のベルト、スプリングクラッチ機構

Ａランク：常に回転しているか、負荷がかかっている箇所に使用され、回転回数が増える事により、変形又は摩耗が生じその性能が発揮出来なくなるパーツ。

Ｂランク：回転部分に使用されているが、摩耗度が比較的少ないパーツ。

## DEFINITION

The definition of each Rank is as follows and also noted in the list

A : Parts necessary to be stocked as High usage parts.

B : Parts necessary to be stocked as Standard usage parts.

C : Low usage parts.

D : Parts necessary for refurbish.

E : Unit parts recommended to be stocked for efficient after sales service.
Please note that the lead time for the said parts may be longer than normal parts.

S : Consumable parts.

Please note that the following parts used in Copier under the same description are classified into A or B Rank depending upon the place used.

Example : Gear made of Metal, Sprocket, Bearing, Belt made of Rubber, Spring clutch mechanism.

A Rank : The parts which may be with the revolution or loading.

B Rank : Parts similar to A Rank parts, but are not included in Rank A.

安全性・信頼性確保のため部品は、必ず正規のものをご使用下さい。

⚠印の部品は、安全上重要な部品です。交換する時は、安全および性能維持のため必ず指定の部品をご使用下さい。

Because parts marked with "⚠" is indispensable for the machine safety maintenance and operation, it must be replaced with the parts specific to the product specification.

○ 当モデルのサービス資料には、この資料以外にサービスマニュアル及び回路図集があります。合せて御利用下さい。

○ Other than this Parts Guide, please refer to documents Service Manual and Circuit Diagram of this model.

○ Please use the 13 digit code described in the right hand corner of front cover of the document, when you place an order.

○ For U.S. only-Use order codes provided in advertising literature.
Do not order from parts department.

## 1 外装 (Exteriors)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION | |
|---|---|---|---|---|---|---|---|
| | | Ex. | Ja. | | | | |
| 1 | CCAB-0876FC05 | BA | FX | N | D | Front exterior | ﾏｴｷｬﾋﾞ |
| 2 | GCAB-0877FCZ1 | AX | FG | N | D | Left exterior | ﾋﾀﾞﾘｷｬﾋﾞ |
| 3 | XHBSE40P10000 | AA | DD | | C | Screw (M4 X 10) | ﾋﾞｽ |
| 4 | GCAB-0747FCZZ | AN | EG | | D | Upper exterior left | ｳｴｷｬﾋﾞﾋﾀﾞﾘ |
| 5 | GCAB-0820FCZZ | AZ | FQ | | D | Rear exterior | ｳｼﾛｷｬﾋﾞ |
| 6 | GCAB-0818FCZ1 | AY | FQ | | D | Right exterior (Japan only) | ﾐｷﾞｷｬﾋﾞ |
| | GCAB-0818FCZZ | AY | FQ | | D | Right exterior (Except Japan) | ﾐｷﾞｷｬﾋﾞ |
| 7 | GCAB-0746FCZZ | AN | EG | | D | Upper exterior right | ｳｴｷｬﾋﾞﾐｷﾞ |
| 8 | PCOVP1271FCZZ | AZ | FQ | | D | Front frame cover | ﾏｴﾌﾚｰﾑｶﾊﾞｰ |
| 9 | PMAGT0015FCZZ | AD | DJ | | B | Magnet catch (10P) | ﾏｸﾞﾈｯﾄｷｬｯﾁ |
| 10 | LPLTM2573FCZ1 | AD | DJ | | C | ADF MG plate | ADF MG ﾌﾟﾚｰﾄ |
| 11 | XBSSE30P10000 | AA | DD | | C | Screw (M3 X 10) | ﾋﾞｽ |
| 12 | PCOVP1273FCZZ | AM | EG | | D | AC cover | ACｶﾊﾞｰ |
| 13 | TCAUH0918FCZZ | AA | DD | | C | Service caution label (Australia,New Zealand) | ｻｰﾋﾞｽﾁｭｳｲﾗﾍﾞﾙ |
| | TCAUH1028FCZZ | AC | DJ | | C | Service caution label (USA,CANADA) | ｻｰﾋﾞｽﾁｭｳｲﾗﾍﾞﾙ |
| | TCAUA0766FCZZ | AB | DD | | C | Service caution label (U.Kingdom only) | ｻｰﾋﾞｽﾁｭｳｲﾗﾍﾞﾙ |
| | TCAUA0770FCZZ | AB | DD | | C | Service caution label (Other countries--Except Japan) | ｻｰﾋﾞｽﾁｭｳｲﾗﾍﾞﾙ |
| 14 | XHBSE40P08000 | AA | DD | | C | Screw (M4 X 8) | ﾋﾞｽ |
| 15 | GCAB-0748FCZ2 | AU | FG | | D | Upper exterior rear | ｳｴｷｬﾋﾞ ｳｼﾛ |
| 16 | HPNLC0236FCZ1 | AW | FG | N | D | Operation panel | ｿｳｻﾊﾟﾈﾙ |
| 17 | XEBSE40P10000 | AA | DD | | C | Screw (M4 X 10) | ﾋﾞｽ |
| 18 | CGiDM1338FC10 | AR | EQ | | C | OR guide L (Japan only) | ORｶﾞｲﾄﾞL |
| | CGiDM1338FC11 | AQ | EQ | | C | OR guide L (Inch series) | ORｶﾞｲﾄﾞL IN |
| | CGiDM1338FC12 | AR | EQ | | C | OR guide L (AB series--Except Japan) | ORｶﾞｲﾄﾞL AB |
| | CGiDM1338FC08 | AQ | EQ | | C | OR guide L (Taiwan only) | ORｶﾞｲﾄﾞL |
| 19 | PGLSP0074FCZ3 | AZ | FQ | | B | Table glass | ﾃｰﾌﾞﾙｶﾞﾗｽ |
| 20 | PGiDM1337FCZZ | AK | EB | | C | OR guide R | ORｶﾞｲﾄﾞR |
| 21 | XBTSE40P04000 | AA | DD | | C | Screw | ﾋﾞｽ |
| 22 | TLABZ2811FCZZ | AB | DD | | C | Power supply mark label (Japan only) | ﾃﾞﾝｹﾞﾝﾏｰｸﾗﾍﾞﾙ |
| 23 | NSFTZ2499FCZZ | AD | DJ | N | C | Front exterior fulcrum shaft | ﾏｴｷｬﾋﾞｼﾃﾝｼﾞｸ |
| 24 | TLABH3709FCZZ | AC | DJ | | C | Warm heater sw label (Japan only) | ﾈｵﾝﾋｰﾀｰSWﾗﾍﾞﾙ |
| 26 | PCOVP1272FCZ1 | AH | DX | N | C | Front connector cover | Fｺﾈｸﾀｰｶﾊﾞｰ |
| 27 | PCOVP1327FCZZ | AF | DS | | C | Rear connector cover | Rｺﾈｸﾀｰｶﾊﾞｰ |
| 28 | XEBSE30P10000 | AA | DD | | C | Screw (M3 X 10) | ﾋﾞｽ |
| 29 | PRNGP0040FCZZ | AA | DD | | C | Grip ring (φ3) | ｸﾞﾘｯﾌﾟﾘﾝｸﾞ |
| 35 | PTPE-0226FCZZ | AC | DJ | | C | Hook tape | ﾌｯｸﾃｰﾌﾟ |
| 36 | PSPAZ1393FCZZ | AC | DJ | | C | MG catch spacer | MGｷｬｯﾁｽﾍﾟｰｻｰ |
| 37 | TLABZ3903FCZZ | AF | DS | | C | Label (Japan,USA) | ｴﾅｼﾞｽﾀｰﾗﾍﾞﾙ |
| 38 | TLABH4083FCZZ | AD | DJ | | C | Label (USA,Australia,New Zealand,U.Kingdom) | ﾎﾝﾀｲｸﾛｰｽﾞﾗﾍﾞﾙ U |
| | TLABH4084FCZZ | AE | DJ | | C | Label (Other countries) | ﾎﾝﾀｲｸﾛｰｽﾞﾗﾍﾞﾙ E4 |
| 51 | PCOVP0911FCZZ | AB | DD | | C | Upper exterior rear cover R (Except Japan) | ｳｴｷｬﾋﾞｱﾄｶﾊﾞｰ R |
| 52 | PCOVP0941FCZZ | AB | DD | | C | Upper exterior rear cover L (Except Japan) | ｳｴｷｬﾋﾞｱﾄｶﾊﾞｰ L |

## 1 外装 (Exteriors)



## 2 操作部(Operation panel section)

| NO. | PARTS CODE | PRICE RANK Ex. | PRICE RANK Ja. | NEW MARK | PART RANK | DESCRIPTION | |
|---|---|---|---|---|---|---|---|
| 1 | HiNDP0765FCZZ | AX | FG | N | D | Key sheet (Japan only) | ｷｰｼｰﾄ J |
| | HiNDP0768FCZZ | AX | FG | N | D | Key sheet (Inch series··USA,CANADA) | ｷｰｼｰﾄｴｲ IN 1 |
| | HiNDP0767FCZZ | AX | FG | N | D | Key sheet (AB series··Australia,New Zealand) | ｷｰｼｰﾄｴｲ AB 2 |
| | HiNDP0769FCZZ | AX | FG | N | D | Key sheet (AB series··Europe,Russia) | ｷｰｼｰﾄ ｼﾝﾎﾞﾙ AB 1 |
| | HiNDP0770FCZZ | AX | FG | N | D | Key sheet (AB series··Hong Kong) | ｷｰｼｰﾄ ｼﾝﾎﾞﾙ AB 2 |
| | HiNDP0772FCZZ | AX | FG | N | D | Key sheet (Inch series··CANADA) | ｷｰｼｰﾄB ｼﾝﾎﾞﾙIN 1 |
| | HiNDP0766FCZZ | AX | FG | N | D | Key sheet (AB series··U,Kingdom) | ｷｰｼｰﾄｴｲ AB 1 |
| | HiNDP0771FCZZ | AX | FG | N | D | Key sheet (AB series··Taiwan) | ｷｰｼｰﾄB ｼﾝﾎﾞﾙAB 3 |
| 2 | PSHEZ4203FCZZ | AK | EB | | D | Sheet (Japan only) | ﾖｺﾈｼｰﾄ J |
| | PSHEZ4204FCZZ | AK | EB | | D | Sheet (USA,Australia,New Zealand,U,Kingdom,CANADA) | ﾖｺﾈｼｰﾄ ｴｲﾌﾟﾝ |
| | PSHEZ4364FCZZ | AK | EB | N | D | Sheet (CANADA and other coutries) | ﾖｺﾈｼｰﾄ ｼﾝﾎﾞﾙ |
| 3 | HPNLC0236FCZ1 | AW | FG | N | D | Operation panel | ｿｳｻﾊﾟﾈﾙ |
| 4 | CBTN-0199FC01 | AL | EB | | C | Clear all key | ｸﾘｱｰｵｰﾙｷｰ |
| 5 | CBTN-0197FC32 | AL | EB | | E | Start key unit | ｽﾀｰﾄｷｰﾕﾆｯﾄ |
| 7 | CBTN-0198FC01 | AL | EB | | C | Clear key | ｸﾘｱｰｷｰ |
| 8 | CBTN-0196FC01 | AR | EQ | | C | Ten key | ﾃﾝｷｰ |
| 10 | CBTN-0201FC01 | AK | EB | | C | Cassette key | ｶｾｯﾄｷｰ |
| 11 | CBTN-0237FC02 | AN | EG | | C | Operation key A | ｿｳｻｷｰA |
| 12 | CBTN-0200FC01 | AL | EB | | C | Zoom key | ｽﾞｰﾑｷｰ |
| 13 | CPWBF1303FC51 | BN | LE | N | E | Operation PWB | ｿｳｻｷﾊﾞﾝ |
| 15 | XEPSD20P08000 | AA | DD | | C | Screw (M2 × 8) | ﾋﾞｽ |
| 16 | XEPSD30P08000 | AA | DD | | C | Screw (M3 × 8) | ﾋﾞｽ |
| 17 | DHAi-2496FCZZ | AH | DX | | C | OP joint harness | OPｾｯｿﾞｸﾊｰﾈｽ |
| 18 | DHAi-2404FCZZ | AY | FQ | | C | Operation main harness | ｿｳｻﾒｲﾝﾊｰﾈｽ |
| 19 | CBTN-0236FC01 | AK | DX | | C | Operation key A | ｿｳｻｷｰA |
| 20 | JBTN-0238FCZZ | AD | DJ | | C | Clear key | ｵｰﾃﾞｨﾄｸﾘｱｷｰ |
| 21 | PCOVP1398FCZZ | AN | EQ | | C | Oparation rear cover | ｿｳｻｳﾗｶﾊﾞｰ |

## 2 操作部(Operation panel section)



## 3 ｵﾘｼﾞﾅﾙｶﾊﾞｰ(Original cover)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION | |
|---|---|---|---|---|---|---|---|
| | | Ex. | Ja. | | | | |
| 1 | PSHEZ2714FCZZ | AT | FG | | D | OC sheet (Japan only) | OCﾏｯﾄ |
| 2 | XJBSD40P12000 | AA | DD | | C | Screw (M4 X 12)(Japan only) | ﾋﾞｽ |
| 3 | MHNG-0172FCZ1 | AQ | EQ | | C | OC hinge L (Japan only) | OCﾋﾝｼﾞ L |
| 4 | MHNG-0173FCZ1 | AQ | EQ | | C | OC hinge R (Japan only) | OCﾋﾝｼﾞ R |
| 5 | GCOVH0212FCZZ | AX | FQ | | D | Original cover R (Japan only) | ｵﾘｼﾞﾅﾙｶﾊﾞｰ R |
| 6 | PSTK-0015FCZZ | AQ | EZ | | C | OR stocker (Japan only) | ORｽﾄｯｶｰ |
| 8 | MHNG-0170FCZ1 | AE | DS | | C | OC cover hinge (Japan only) | OCｶﾊﾞｰﾋﾝｼﾞ |
| 9 | LPiNS0280FCZZ | AD | DJ | | C | OC cover hinge pin (Japan only) | OCｶﾊﾞｰﾋﾝｼﾞﾋﾟﾝ |
| 10 | XEBSD40P08000 | AA | DD | | C | Screw (M4 X 8)(Japan only) | ﾋﾞｽ |
| 11 | GCOVH0211FCZZ | AW | FG | | D | Original cover F (Japan only) | ｵﾘｼﾞﾅﾙｶﾊﾞｰ F |
| 12 | TLABH4082FCZZ | AD | DJ | | C | Label (Japan only) | ﾎﾝﾀｲｸﾛｰｽﾞﾗﾍﾞﾙ |
| 13 | PCUSF0336FCZZ | AH | DX | | C | OC support cushion (Japan only) | OC ｻﾎﾟｰﾄｽﾎﾟﾝｼﾞ |
| 21 | GCOVH0194FCZ2 | BB | GD | | D | Original cover (Except Japan) | ｵﾘｼﾞﾅﾙｶﾊﾞｰ |
| 22 | MHNG-0096FCZZ | AL | EG | | C | OC hinge R (Except Japan) | OCﾋﾝｼﾞ R |
| 23 | MHNG-0086FCZZ | AL | EG | | C | OC hinge L (Except Japan) | OCﾋﾝｼﾞ L |
| 24 | XJBSD40P12000 | AA | DD | | C | Screw (M4 X 12)(Except Japan) | ﾋﾞｽ |
| 25 | PSHEZ2715FCZZ | AU | FQ | | D | OC sheet (Except Japan) | OCﾏｯﾄ |

## 3 ｵﾘｼﾞﾅﾙｶﾊﾞｰ(Original cover)







FCP02626

## 5 右ｷｬﾋﾞ下･･国内,USA,CANADA,台湾以外
(Right exterior Lower ･･ Except Japan,USA,CANADA,Taiwan)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION | |
|---|---|---|---|---|---|---|---|
| | | Ex. | Ja. | | | | |
| 1 | XEPSD30P08000 | AA | DD | | C | Screw (M3 X 8) | ﾋﾞｽ |
| 3 | NGERR0377FCZZ | AD | DJ | | C | Manual feed gear | ﾃｻｼｷﾞﾔ |
| 4 | XWHSD30-08100 | AA | DD | | C | Washer (φ3) | ﾜｯｼｬ |
| 5 | NGERH0193FCZZ | AB | DD | | C | UC manual feed gear | UCﾃｻｼｷﾞﾔｰ |
| 6 | PSHEZ1760FCZZ | AB | DD | | C | Manual feed gear brake sheet | ﾃｻｼｷﾞﾔｰﾌﾞﾚｰｷｼｰﾄ |
| 7 | GCAB-0822FCZ2 | AX | FG | N | D | Right exterior lower | ﾐｷﾞｷｬﾋﾞ ｼﾀ |
| 8 | PGiDM1268FCZZ | AC | DJ | | C | MF guide F | ﾃｻｼｶﾞｲﾄﾞ F |
| 9 | PGiDM1269FCZZ | AC | DJ | | C | MF guide R | ﾃｻｼｶﾞｲﾄﾞ R |
| 10 | MLEVP0673FCZ1 | AF | DS | | C | Manual feed actuator | ﾃｻｼｱｸﾁｴｰﾀｰ |
| 11 | TLABZ3733FCZ1 | AF | DS | | C | Manual paper feeding size label | ﾃｻｼｻｲｽﾞﾗﾍﾞﾙAB |
| 12 | XHBSE40P08000 | AA | DD | | C | Screw (M4 X 8) | ﾋﾞｽ |
| 13 | LX-WZ0256FCZZ | AA | DD | | C | Washer | ﾎﾟﾘｽﾗｲﾀﾞｰ |

5 右ｷｬﾋﾞ下･･国内,USA,CANADA,台湾以外
(Right exterior Lower ･･ Except Japan,USA,CANADA,Taiwan)



## 6 光学ﾕﾆｯﾄ 1(Optical unit 1)

| NO. | PARTS CODE | PRICE RANK Ex. | PRICE RANK Ja. | NEW MARK | PART RANK | DESCRIPTION | |
|---|---|---|---|---|---|---|---|
| 1 | NSFTZ2131FCZ1 | AS | EQ | | C | Winder drive shaft | ﾏｷﾄﾘｸﾄﾞｳｼﾞｸ |
| 2 | XRESP70-08000 | AA | DD | | C | E type ring (7mm) | Eﾘﾝｸﾞ |
| 3 | NPLYZ0172FCZ1 | AL | EB | | C | Winder pulley | ﾏｷﾄﾘﾌﾟ－ﾘｰ |
| 4 | LX-BZ0032FCZZ | AB | DD | | C | Screw (M4 X 6) | ﾋﾞｽ |
| 5 | LPiNS0288FCZZ | AB | DJ | | C | Pin (φ3 X 10.6) | ﾍｲｺｳﾋﾟﾝ |
| 6 | NGERH1071FCZZ | AG | DS | | C | Winder drive gear | ﾏｷﾄﾘｸﾄﾞｳｷﾞﾔ |
| 7 | LX-BZ0324FCZZ | AA | DD | | C | Screw | ﾋﾞｽ |
| 8 | PWiR-0173FCZZ | AS | EQ | | C | MB wire | MBﾜｲﾔｰ |
| ⚠ 9 | CREFL0145FC35 | BP | LP | | E | Copy lamp unit (Japan, 100V series) | ｺﾋﾟｰﾗﾝﾌﾟﾕﾆｯﾄ100 |
| ⚠ 9 | CREFL0145FC36 | BP | LP | | E | Copy lamp unit (200V series) | ｺﾋﾟｰﾗﾝﾌﾟﾕﾆｯﾄ200 |
| 10 | XBBSD40P10000 | AA | DD | | C | Screw (M4 X 10) | ﾋﾞｽ |
| 11 | LPLTM4054FCZZ | AB | DD | | C | Wire fixing plate | ﾜｲﾔｰｺﾃｨﾊﾞﾝ |
| 12 | CHLDZ1234FC31 | BH | GX | | E | 2nd, 3rd mirror holder unit | 2,3ﾐﾗｰﾎﾙﾀﾞｰﾕﾆｯﾄ |
| 13 | PRNGP0025FCZZ | AA | DD | | C | G type ring (GTW-5) | Gﾘﾝｸﾞ |
| 14 | NPLYZ0340FCZZ | AC | DJ | | C | L pulley | Lﾌﾟｰﾘｰ |
| 15 | NPLYZ0292FCZZ | AH | DX | | C | Pulley | ﾌﾟｰﾘｰ |
| 16 | LX-WZ0017FCZZ | AA | DD | | C | Washer (φ8 X T0.5) | ﾜｯｼｬ |
| 17 | CPLTM4599FC01 | AE | DS | | C | Pulley fixing plate | ﾃｲﾌﾟｰﾘｰﾄﾘﾂｹｲﾀ |
| 18 | PCÖVP1276FCZZ | AR | EQ | | C | Dark box cover upper | ｱﾝﾊﾞｺｶﾊﾞｰｳｴ |
| 19 | LX-BZ0320FCZZ | AA | DD | | C | Screw (M4 X 6) | ﾋﾞｽ |
| 20 | RMÖTN0768FCZZ | AZ | FQ | | B | Mirror motor | ﾐﾗｰﾓｰﾀｰ |
| 22 | PGUMS0228FCZZ | AA | DD | | C | Table glass rubber | ﾃﾌﾞﾙｶﾞﾗｽｺﾞﾑ |
| 23 | LPLTM4046FCZZ | AD | DJ | | C | Glass holding plate R | ｶﾞﾗｽｳｹｲﾀR |
| 24 | XBPSD40P06K00 | AA | DD | | C | Screw (M4 X 6K) | ﾋﾞｽ |
| 25 | LPLTM4766FCZZ | AN | EG | | C | OC fixing plate | OCﾄﾘﾂｹﾊﾞﾝ |
| 26 | XHPSD40P08000 | AA | DD | | C | Screw (M4 X 8) | ﾋﾞｽ |
| 27 | PFTA-0110FCZZ | AF | DS | | C | Conector cover (Except U,Kingdom) | ﾗﾃｨｽｺﾈｸﾀｶﾌﾀ |
| 28 | XBBSD30P06000 | AA | DD | | C | Screw (M3 X 6) | ﾋﾞｽ |
| 29 | PGUMS0147FCZZ | AA | DD | | C | Table glass rubber (small) | ﾃｰﾌﾞﾙｶﾞﾗｽｺﾞﾑ(ｼｮｳ) |
| 30 | LPLTM4047FCZZ | AD | DJ | | C | Glass holding plate L | ｶﾞﾗｽｳｹｲﾀL |
| 31 | LPLTM5471FCZZ | AH | DX | N | C | Sub DC PWB fixing plate | ｻﾌﾞDCｷﾊﾞﾝﾄﾘﾂｹｲﾀ |
| 32 | CPLTM4532FC02 | AP | EQ | | C | Tip sheet fixing plate | ｾﾝﾀﾝｼｰﾄﾄﾘﾂｹｲﾀ |
| 36 | LX-BZ0335FCZZ | AA | DD | | C | Screw (M4 X 6)(Red) | ﾋﾞｽ |
| 37 | LRALM0116FCZZ | AE | DS | | C | MB-B rail | MB-Bﾚｰﾙ |
| 39 | DHAi-2401FCZZ | BF | GN | | C | Optical main harness A (Japan only) | ｺｳｶﾞｸﾒｲﾝﾊｰﾈｽAJ |
| 39 | DHAi-2400FCZZ | BE | GN | | C | Optical main harness (Except Japan) | ｺｳｶﾞｸﾒｲﾝﾊｰﾈｽEX |
| 40 | PGiDM1539FCZZ | AC | DJ | | C | CL guide | CLｶﾞｲﾄﾞ |
| 41 | CDAiU0506FC01 | BH | GX | | C | Optical base plate | ｺｳｶﾞｸﾀﾞｲﾊﾞﾝ |
| 42 | DHAi-2404FCZZ | AY | FQ | | C | Operation main harness | ｿｳｻﾒｲﾝﾊｰﾈｽ |
| 44 | NSFTZ2133FCZZ | AH | DX | | C | Blancer shaft | ﾊﾞﾗﾝｻｰｼﾞｸ |
| 45 | XBPSD40P30K00 | AA | DD | | C | Screw (M4 X 30) | ﾋﾞｽ |
| 46 | LHLDW1269FCZZ | AC | DJ | | C | Wire holder (WWS-A-2-01) | ﾜｲﾔｰﾎﾙﾀﾞｰ |
| 48 | XRESP50-06000 | AA | DD | | C | E type ring | Eﾘﾝｸﾞ |
| 49 | NBRGC0387FCZ1 | AC | DJ | | B | Bearing | ﾍﾞｱﾘﾝｸﾞ |
| 50 | NBRGC0504FCZZ | AC | DJ | | C | Bearing (F8 X 12 X 5 16X) | ｼﾞｸｳｹ |
| 54 | XBPSD40P08KS0 | AA | DD | | C | Screw (4 X 8KS) | ﾋﾞｽ |
| 55 | LBNDJ0013FCZ1 | AA | DJ | | C | Wire band | ｹｯｿｸﾊﾞﾝﾄﾞ |
| 56 | PSHEP3907FCZZ | AD | DJ | | C | Dark box cover upper sheet | ｱﾝﾊﾞｺｶﾊﾞｰｳｴｼｰﾄ |
| 58 | LPLTM5029FCZZ | AG | DX | | C | Connector protect plate (U,Kindgom only) | ｺﾈｸﾀｰﾎｺﾞｲﾀ |
| 59 | TLABH3805FCZZ | AF | DS | | C | Electric shock caution label | ｶﾝﾃﾞﾝﾁｭｳｲﾗﾍﾞﾙ |
| 60 | TCAUH1001FCZZ | AF | DS | | C | Copy lamp caution label (USA) | ｺﾋﾟｰﾗﾝﾌﾟﾁｭｳｲﾗﾍﾞﾙ U |
| 60 | TCAUH1002FCZZ | AH | DX | | C | Copy lamp caution label (CANADA) | ｺﾋﾟｰﾗﾝﾌﾟﾁｭｳｲﾗﾍﾞﾙ E4 |
| 61 | RCÖRF0026FCZZ | AL | EB | | C | Core (TFC-16813)(200V Series) | ｺｱｰ |
| 62 | LHLDW2135SCZZ | AB | DD | | C | PWB holder (KGLS-6RT) | ｷﾊﾞﾝﾎﾙﾀﾞｰ |
| 63 | XHBSD30P08000 | AA | DD | | C | Screw (3 X 8) | ﾋﾞｽ |
| 64 | XHBSE40P10000 | AA | DD | | C | Screw (4 X 10) | ﾋﾞｽ |
| 65 | CPWBF1302FC51 | BB | GD | N | E | Sub DC PWB (100V Series) | ｻﾌﾞDCｷﾊﾞﾝ |
| 65 | CPWBF1302FC52 | BB | FX | N | E | Sub DC PWB (200V Series) | ｻﾌﾞDCｷﾊﾞﾝ |

## 6 光学ﾕﾆｯﾄ 1(Optical unit 1)



## 7 光学ﾕﾆｯﾄ 2(Optical unit 2)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION | |
|---|---|---|---|---|---|---|---|
| | | Ex. | Ja. | | | | |
| 1 | LX-BZ0335FCZZ | AA | DD | | C | Screw (M4 X 6)(Red) | ﾋﾞｽ |
| 2 | LPLTM4562FCZZ | AA | DJ | | C | Lens drive shaft fixing plate | ﾚﾝｽﾞｸﾄﾞｳｼﾞｸﾄﾘｯｹﾊﾞﾝ |
| 3 | NSFTZ2132FCZZ | AF | DS | | C | 4th, 5th drive shaft | 4,5ｸﾄﾞｳｼﾞｸ |
| 4 | CHLDZ1235FC31 | BF | GN | | E | 4th, 5th mirror holder unit | 4,5ﾐﾗｰﾎﾙﾀﾞｰﾕﾆｯﾄ |
| 5 | MSPRT2285FCZZ | AC | DJ | | C | 4th, 5th drive spring | 4,5ｸﾄﾞｳｽﾌﾟﾘﾝｸﾞ |
| 6 | CDAiU0506FC01 | BH | GX | | C | Optical base plate | ｺｳｶﾞｸﾀﾞｲﾊﾞﾝ |
| 7 | LX-BZ0753FCZZ | AC | DD | | C | Screw | ﾋﾞｽ |
| 8 | NPLYZ0340FCZZ | AC | DJ | | C | L pulley | L ﾌﾟｰﾘｰ |
| 9 | XBPSD40P06K00 | AA | DD | | C | Screw (M4 X 6K)(Japan only) | ﾋﾞｽ |
| ⚠ 10 | CR-WZ0460FC01 | AY | FQ | | B | Dry heater (Japan only) | ｼﾞｮｼﾂﾃｲｺｳJ HVER |
| 11 | PSHEP3747FCZZ | AE | DJ | | C | 6th mirror shield sheet | ﾀﾞｲ6ﾐﾗｰｼｬｺｳｼｰﾄ |
| 12 | XBTSC40P04000 | AA | DD | | C | Screw (M4 X 4) | ﾋﾞｽ |
| 13 | PCÖVP1277FCZZ | AN | EQ | | C | Dark box cover lower | ｱﾝﾊﾞｺｶﾊﾞｰｼﾀ |
| 14 | PGLSP0072FCZ1 | AN | EG | | B | Protection glass | ﾎﾞｳｼﾞﾝｶﾞﾗｽ |
| 15 | LFiX-0409FCZZ | AB | DD | | C | Lens shaft fixing plate | ﾚﾝｽﾞｼﾞｸｵｻｴ |
| 16 | NSFTD1597FCZZ | AP | EQ | | C | Lens drive shaft | ﾚﾝｽﾞｸﾄﾞｳｼﾞｸ |
| ⚠ | CR-WZ0457FC01 | AU | FG | | B | Dry heater (Japan only) | ｼﾞｮｼﾂﾃｲｺｳ J |
| ⚠ 17 | CR-WZ0458FC01 | AU | FG | | B | Dry heater (100V series··Except Japan) | ｼﾞｮｼﾂﾃｲｺｳ100 |
| ⚠ | CR-WZ0459FC01 | AU | FG | | B | Dry heater (200V series··Except Europe) | ｼﾞｮｼﾂﾃｲｺｳ200 |
| 18 | PMiR-0127FCZZ | AT | EZ | | B | 6th mirror | ﾀﾞｲ6ﾐﾗｰ |
| 19 | LFiX-0408FCZZ | AB | DD | | C | 6th mirror fixing plate | ﾀﾞｲ6ﾐﾗｰｵｻｴ |
| 20 | LFiX-0284FCZZ | AC | DD | | C | 4th 5th mirror holder F | ﾀﾞｲ4.5ﾐﾗｰｵｻｴ F |
| 21 | LX-BZ0637FCZZ | AC | DJ | | C | Screw (Red) | 6ﾐﾗｰﾁｮｳｾｲﾋﾞｽ |
| 22 | LX-WZ0050FCZ1 | AA | DD | | C | Washer (M4) | ﾅﾐﾜｯｼｬ |
| 23 | LX-WZ0134FCZZ | AA | DD | | C | Washer | ﾜｯｼｬ |
| 24 | XNESF40-32000 | AA | DD | | C | Nut (M4) | ﾅｯﾄ |
| 25 | LRALM0119FCZZ | AK | EB | | C | MB rail R | MBﾚｰﾙR |
| 26 | VHPGP1A22LC-1 | AK | EB | | B | Photo sensor (GP1A22LC)(MHPD) | ﾌｫﾄｾﾝｻｰ |
| 27 | XBBSD40P10000 | AA | DD | | C | Screw (M4 X 10) | ﾋﾞｽ |
| 28 | PDUC-0061FCZZ | AM | EG | | C | CFM duct | CFMﾀﾞｸﾄ |
| 29 | XBPSD40P06K00 | AA | DD | | C | Screw (M4 X 6K)(Except Europe) | ﾋﾞｽ |
| 30 | NFANP0043FCZZ | AZ | FQ | | B | CFM | CFM |
| 31 | XEPSD40P30000 | AA | DD | | C | Screw (M4 X 30) | ﾋﾞｽ |
| 32 | PFiLD0186FCZZ | AF | DS | | B | Fan filter | ﾌｧﾝﾌｨﾙﾀｰ |
| 33 | DHAi-2401FCZZ | BF | GN | | C | Optical main harness A (Japan only) | ｺｳｶﾞｸﾒｲﾝﾊｰﾈｽAJ |
| | DHAi-2400FCZZ | BE | GN | | C | Optical main harness (Except Japan) | ｺｳｶﾞｸﾒｲﾝﾊｰﾈｽEX |
| 36 | LX-BZ0266FCZZ | AB | DD | | C | Screw | ﾋﾞｽ |
| 37 | XHPSD40P08000 | AA | DD | | C | Screw (M4 X 8) | ﾋﾞｽ |
| 38 | DHAi-2404FCZZ | AY | FQ | | C | Operation main harness | ｿｳｻﾒｲﾝﾊｰﾈｽ |
| 39 | LHLDW1287FCZZ | AD | DJ | | C | Clamp (Japan only) | ｽﾋﾟｰﾄﾞｸﾗﾝﾌﾟ |
| 40 | PSHEP4593FCZZ | AF | DS | N | C | Cover fixing sheet | ｶﾊﾞｰｵｻｴﾏｲﾗｰ |

## 7 光学ﾕﾆｯﾄ 2(Optical unit 2)



## 8 ﾚﾝｽﾞ駆動ﾕﾆｯﾄ(Lens drive unit)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION | |
|---|---|---|---|---|---|---|---|
| | | Ex. | Ja. | | | | |
| 1 | PLNS-0043FCZ1 | BK | HL | | C | Lens | ﾚﾝｽﾞ |
| 2 | PSHEG2817FCZ1 | AC | DJ | | C | Lens lock sheet | ﾚﾝｽﾞﾛｯｸｼｰﾄ |
| 3 | NBRGC2029SCZZ | AB | DD | | B | Bearing (F3 X 6 X 4.7 X 1) | ﾍﾞｱﾘﾝｸﾞ |
| 4 | XRESP20-03000 | AA | DD | | C | E type ring (2mm) | Eﾘﾝｸﾞ |
| 5 | PSHEP2335FCZZ | AA | DD | | C | Shield sheet | ﾋｶﾘｼﾞｸｼｬｺｳｼｰﾄ |
| 6 | PSHEP2751FCZZ | AC | DD | | C | Lens shield sheet side | ﾚﾝｽﾞｼｬｺｳｼｰﾄﾖｺ |
| 7 | PSHEP4059FCZZ | AK | EB | | C | Lens upper sheet | ﾚﾝｽﾞｳｴｼｰﾄN |
| 8 | MSPRC2704FCZZ | AD | DJ | | C | SWL Drive wire spring | SWLｸﾄﾞｳﾜｲﾔｰｽﾌﾟﾘﾝｸﾞ |
| 9 | PWiR-0174FCZZ | AU | EZ | | C | Lens wire | ﾚﾝｽﾞﾜｲﾔｰ |
| 10 | LDAiU0507FCZZ | AR | EQ | | C | Zoom base | ｽﾞｰﾑﾍﾞｰｽ |
| 11 | NPLYZ0340FCZZ | AC | DJ | | C | L pulley | Lﾌﾟｰﾘｰ |
| 12 | LX-BZ0753FCZZ | AC | DD | | C | Screw | ﾋﾞｽ |
| 13 | NPLYZ0298FCZZ | AH | DX | | C | L drive pulley | Lｸﾄﾞｳﾌﾟｰﾘｰ |
| 14 | NGERH1036FCZZ | AF | DS | | C | 4th, 5th drive gear | 4,5ｸﾄﾞｳｷﾞﾔ |
| 15 | XRESP30-04000 | AA | DD | | C | E type ring (3mm) | Eﾘﾝｸﾞ |
| 17 | CPWBF1093FC31 | AV | FG | | E | Optical PWB | ｺｳｶﾞｸｷﾊﾞﾝ |
| 18 | RMOTP0766FCZ1 | AX | FG | N | B | Lens drive motor | ﾚﾝｽﾞｸﾄﾞｳﾓｰﾀ |
| 19 | XEPSD30P08000 | AA | DD | | C | Screw (M3 X 8) | ﾋﾞｽ |
| 20 | NGERH1037FCZZ | AG | DX | | C | Cam drive gear | ﾍﾝﾊﾞｲｶﾑｸﾄﾞｳｷﾞﾔ |
| 21 | NBRGC0537FCZZ | AG | DX | | C | Bearing | ﾍﾝﾊﾞｲｶﾑﾍﾞｱﾘﾝｸﾞ |
| 22 | MCAMM0093FCZZ | AF | DS | | C | Cam | ﾍﾝﾊﾞｲｶﾑ |
| 23 | LX-BZ0713FCZZ | AB | DD | | C | Screw (M4 X 6) | ﾋﾞｽ |
| 24 | LX-BZ0786FCZZ | AC | DD | | C | Screw | ﾘﾝｸﾀﾞﾝﾋﾞｽ |
| 25 | NBRGC0531FCZZ | AC | DJ | | C | Bearing (B-S6-4) | ｼﾞｸｳｹ |
| 26 | NGERR1038FCZZ | AF | DS | | C | Rack gear | ﾍﾝﾊﾞｲﾗｯｸ |
| 27 | XBPSD30P06000 | AA | DD | | C | Screw (M3 X 6) | ﾋﾞｽ |
| 28 | LHLDZ1232FCZZ | AH | DX | | C | Collar holder | ｺﾛﾎﾙﾀﾞｰ |
| 29 | PCLR-0351FCZZ | AB | DD | | C | MB bearing collar M5 | MBｼﾞｸｳｹｶﾗｰM5 |
| 30 | NBRGP0426FCZZ | AB | DD | | C | MB bearing M5 | MBｼﾞｸｳｹ M5 |
| 31 | NSFTZ2134FCZZ | AG | DX | | C | Collar holder drive shaft | ｺﾛﾎﾙﾀﾞｰｸﾄﾞｳｼﾞｸ |
| 38 | NBRGC0307FCZZ | AC | DJ | | C | Bearing (φ10) | ｼﾞｸｳｹ |
| 39 | NBRGC0401FCZZ | AC | DD | | C | Bearing | ｼﾞｸｳｹ |
| 40 | LX-WZ0424FCZZ | AC | DD | | C | Washer | ｼﾞｸｳｹﾖｳﾜｯｼｬ |
| 41 | LX-BZ0840FCZZ | AC | DD | | C | Screw | ﾋﾞｽ |
| 42 | PSHEP4067FCZZ | AD | DJ | | C | Zoom base sheet | ｽﾞｰﾑﾍﾞｰｽﾏｲﾗｰ |
| 43 | PSHEP4058FCZZ | AC | DJ | | C | Lens sheet R | ﾚﾝｽﾞﾏｲﾗｰ R |
| 44 | NGERR1283FCZZ | AD | DJ | | C | Rack gear | ﾍﾝﾊﾞｲﾗｯｸ |

## 8 ﾚﾝｽﾞ駆動ﾕﾆｯﾄ(Lens drive unit)



## 9 ﾐﾗｰﾎﾙﾀﾞｰﾕﾆｯﾄ (Mirror holder unit)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION | |
|---|---|---|---|---|---|---|---|
| | | Ex. | Ja. | | | | |
| 1 | XEPSD40P06000 | AA | DD | | C | Screw (M4 X 6) | ﾋﾞｽ |
| 2 | CSLi-0103FC31 | AF | DS | | E | Slider (4pcs/set) | ｽﾍﾞﾘｻﾞｲ(X4) |
| 3 | LFiX-0284FCZZ | AC | DD | | C | 4th 5th mirror holder F | ﾀﾞｲ4.5ﾐﾗｰｵｻｴ F |
| 4 | PMiR-0128FCZZ | AU | EZ | | B | 2nd mirror | ﾀﾞｲ2ﾐﾗｰ |
| 5 | PMiR-0129FCZZ | AY | FQ | | B | 3rd mirror | ﾀﾞｲ3ﾐﾗｰ |
| 6 | NPLYZ0276FCZZ | AG | DX | | C | W pulley | Wﾌﾟｰﾘｰ |
| 7 | LX-BZ0618FCZZ | AA | DD | | C | Screw (M4 X 4) | ﾋﾞｽ |
| 8 | PCUSS0201FCZZ | AA | DD | | C | MB-B cushion | MB-Bﾖｳｸｯｼｮﾝ |
| 21 | LX-BZ0320FCZZ | AA | DD | | C | Screw (M4 X 6) | ﾋﾞｽ |
| 22 | NGERR1039FCZZ | AG | DX | | C | 4th, 5th drive rack gear | 4,5ｸﾄﾞｳﾗｯｸ |
| 23 | XBPSD40P06000 | AA | DD | | C | Screw (M4 X 6) | ﾋﾞｽ |
| 24 | LHLDZ1236FCZZ | AR | EQ | | C | 4th, 5th drive holder | 4,5ｸﾄﾞｳﾎﾙﾀﾞｰ |
| 25 | LFiX-0284FCZZ | AC | DD | | C | 4th, 5th mirror holder F | ﾀﾞｲ4,5ﾐﾗｰｵｻｴ F |
| 26 | LFiX-0438FCZZ | AD | DJ | | C | Mirror fixing plate F | ﾐﾗｰｵｻｴF |
| 27 | PMiR-0131FCZZ | AS | EQ | | B | 5th mirror | ﾀﾞｲ5ﾐﾗｰ |
| 28 | PMiR-0130FCZZ | AW | FG | | B | 4th mirror | ﾀﾞｲ4ﾐﾗｰ |
| 29 | LX-BZ0725FCZZ | AB | DD | | C | Screw | ﾋﾞｽ |
| 30 | PCLR-0402FCZZ | AE | DJ | | C | Collar | ﾍﾝｼﾝｶﾗｰ |
| 31 | LX-WZ0139FCZZ | AA | DD | | C | Washer | ﾜｯｼｬ |
| 32 | LX-WZ0413FCZZ | AA | DD | | C | Washer | ﾜｯｼｬ |
| 33 | XNESF40-32000 | AA | DD | | C | Nut (M4) | ﾅｯﾄ |
| 34 | LHLDZ1235FCZZ | AM | EG | | C | 4th, 5th mirror holder | 4,5ﾐﾗｰﾎﾙﾀﾞｰ |
| 35 | XBPSD30P18000 | AC | DD | | C | Screw (M3 X 18) | ﾋﾞｽ |
| 36 | LPLTM5015FCZZ | AE | DJ | | C | 4th, 5th, reinforce plate | 4,5ﾎｷｮｳﾌﾟﾚｰﾄ |
| 37 | LX-WZ5028BCZZ | AA | DD | | C | Washer | ﾎﾟﾘｽﾗｲﾀﾞｰ |
| 41 | XWUSD50-06100 | AA | DD | | C | Washer | ﾊﾂｷﾜｯｼｬ |
| 501 | CHLDZ1234FC31 | BH | GX | | E | 2nd, 3rd mirror holder unit | 2,3ﾐﾗｰﾎﾙﾀﾞｰﾕﾆｯﾄ |
| 502 | CHLDZ1235FC31 | BF | GN | | E | 4th, 5th mirror holder unit | 4,5ﾐﾗｰﾎﾙﾀﾞｰﾕﾆｯﾄ |

## 9 ﾐﾗｰﾎﾙﾀﾞｰﾕﾆｯﾄ (Mirror holder unit)



## 10 上ﾌﾚｰﾑ 1(Upper frame 1)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION | |
|---|---|---|---|---|---|---|---|
| | | Ex. | Ja. | | | | |
| 1 | XHBSE40P08000 | AA | DD | | C | Screw (M4 X 8) | ﾋﾞｽ |
| 2 | LX-BZ0663FCZZ | AD | DJ | | C | Screw | ﾋﾞｽ |
| 3 | MSPRC2368FCZZ | AP | EQ | | C | DV lever spring | DVﾚﾊﾞｰｽﾌﾟﾘﾝｸﾞ |
| 4 | MLEVP0688FCZZ | AH | DX | | C | DV lever (M4 X 6) | DVﾚﾊﾞｰ |
| 5 | JHNDP0128FCZZ | AD | DJ | | C | Transport handle | ﾊﾝｿｳﾄｯﾃ |
| 6 | MLEVF0666FCZZ | AF | DS | | C | Lock release lever | ﾛｯｸｶｲｼﾞｮﾚﾊﾞｰ |
| 7 | XRESP70-08000 | AA | DD | | C | E type ring (7mm) | Eﾘﾝｸﾞ |
| 8 | NSFTZ2186FCZZ | AF | DS | | C | Inter lock switch shaft | ｲﾝﾀｰﾛｯｸSWｼﾞｸ |
| 9 | MSPRC2184FCZZ | AA | DJ | | C | Inter lock switch shaft spring | ｲﾝﾀｰﾛｯｸSWｼﾞｸｽﾌﾟﾘﾝｸﾞ |
| 10 | LHLDZ1201FCZZ | AE | DS | | C | Inter lock switch shaft holder | ｲﾝﾀｰﾛｯｸSWｼﾞｸﾎﾙﾀﾞｰ |
| 11 | XHBSE40P10000 | AA | DD | | C | Screw (M4 X 10) | ﾋﾞｽ |
| 12 | CBŌSZ1610FC01 | AN | EQ | | C | Fulcrum boss | ｼﾃﾝﾎﾞｽ |
| 13 | LFRM-0834FCZ1 | AV | FG | | C | Upper frame F | ｳｴﾌﾚｰﾑF |
| 14 | QSW-C9170QCZZ | AK | EB | | B | Seesaw switch (Power SW) | ｼｰｿｰｽｲｯﾁ |
| 15 | QSW-M0296FCZZ | AM | EG | | B | Microswitch (Power SW) | ﾏｲｸﾛｽｲｯﾁ |
| 16 | DHAi-2916FCZZ | AX | FG | N | C | MSW interface harness H (Japan only) | MSWﾁｭｳｹｲﾊｰﾈｽ H |
| | DHAi-2917FCZZ | AW | FG | N | C | MSW interface harness (100V series･･Except Japan) | MSWﾁｭｳｹｲﾊｰﾈｽ100 |
| | DHAi-2406FC12 | AW | FG | | C | MSW interface harness (200V series･･For Europe) | MSWﾁｭｳｹｲﾊｰﾈｽ200 |
| | DHAi-2918FCZZ | AW | FG | N | C | MSW interface harness (200V Series･･Except Europe) | MSWﾁｭｳｹｲﾊｰﾈｽ200 |
| 17 | XEPSD40P35000 | AA | DD | | C | Screw (M4 X 35) | ﾋﾞｽ |
| 18 | RMŌTP0764FCZZ | AZ | FQ | | B | VFM | VFM |
| 19 | PFiLZ0268FCZZ | AU | EZ | N | B | Delivery filter | ﾊｲｼﾌｨﾙﾀｰ |
| 20 | PDUC-0092FCZZ | AS | EQ | | C | Fan duct | ﾊｲｷﾌｧﾝﾀﾞｸﾄ |
| 21 | XHBSD30P06000 | AA | DD | | C | Screw (M3 X 6) | ﾋﾞｽ |
| 22 | CPWBF1084FC51 | AU | EZ | | E | POD PWB | POD ｷﾊﾞﾝ |
| 24 | LDAiU0505FCZZ | AP | EQ | | C | Fan fixing base | ﾌｧﾝﾄﾘﾂｹﾀﾞｲ |
| 25 | MLEVP0667FCZ1 | AD | DJ | | C | Delivery actuator | ﾊｲｼｱｸﾁｴｰﾀ |
| 26 | LBSHZ0326FCZZ | AC | DJ | | C | Edge protect bushing (L=100) | ｴｯｼﾞﾎｺﾞ |
| 27 | PRNGP0034FCZZ | AA | DD | | C | E type ring (φ10) | Eﾘﾝｸﾞ |
| 28 | XHPSD30P06000 | AA | DD | | C | Screw (M3 X 6) | ﾋﾞｽ |
| 29 | LANGT1320FCZZ | AB | DD | | C | TC control angle | TCｲﾁｷﾒｱﾝｸﾞﾙ |
| 30 | LX-BZ0670FCZZ | AC | DD | | C | Screw | ﾋﾞｽ |
| 31 | MSPRC2591FCZZ | AC | DJ | | C | Lock lever spring | ﾛｯｸﾚﾊﾞｰｽﾌﾟﾘﾝｸﾞ |
| 32 | NSFTZ2120FCZ2 | AP | EQ | | C | Lock lever shaft | ﾛｯｸﾚﾊﾞｰｼﾞｸ |
| 33 | MLEVF0374FCZZ | AC | DJ | | C | Lock lever | ﾛｯｸﾚﾊﾞｰ |
| 34 | LFRM-0835FCZ1 | AU | EZ | | C | Upper frame R | ｳｴﾌﾚｰﾑR |
| 36 | NSFTZ1595FCZZ | AD | DJ | | C | Shaft G | ｼｬﾌﾄG |
| 37 | XRESP20-03000 | AA | DD | | C | E type ring (2mm) | Eﾘﾝｸﾞ |
| 38 | XEBSD30P06000 | AA | DD | | C | Screw (3 X 6) | ﾋﾞｽ(Pﾀｲﾄ) |
| 39 | PCŌVP1301FCZZ | AL | EB | | C | DV guide cover A | DVｶﾞｲﾄﾞｶﾊﾞｰA |
| 40 | CGiDH1541FC01 | AX | FG | | C | DV guide | DVｶﾞｲﾄﾞ |
| 41 | CPLTM2632FC01 | AE | DJ | | C | DV plate A | DVﾘｾﾂﾌﾟﾚｰﾄ A |
| 42 | CPLTM2415FC01 | AG | DS | | C | DV plate A | DVﾘｾﾂﾌﾟﾚｰﾄ A |
| 43 | XRESP30-05000 | AA | DD | | C | E type ring (3mm) | Eﾘﾝｸﾞ |
| 44 | XRESP40-06000 | AA | DD | | C | 4E-Type ring (4mm) | Eﾘﾝｸﾞ |
| 45 | MSPRT1203FCZZ | AA | DD | | C | DV spring | DVﾘｾﾂ ｽﾌﾟﾘﾝｸﾞ |
| 46 | LPLTM3718FCZZ | AG | DS | | C | Plate DVG | ﾌﾟﾚｰﾄDVG |
| 47 | LPLTP4890FCZZ | AL | EB | | C | Plate DVH | ﾌﾟﾚｰﾄDVH |
| 48 | CPWBF1089FC32 | AR | EQ | | E | PID PWB | PIDｷﾊﾞﾝ |
| 49 | XHBSD40P08000 | AA | DD | | C | Screw (4 X 8) | ﾋﾞｽ |
| 50 | DHAi-2414FCZZ | AK | EB | | C | PID PWB harness | PIDｷﾊﾞﾝﾊｰﾈｽ |
| 51 | PGiDM1543FCZZ | AR | EQ | | C | DV lower paper guide | DVｼﾀﾍﾞｰﾊﾞｰｶﾞｲﾄﾞ |
| 52 | MSPRT2277FCZZ | AC | DJ | | C | PS front collar pressure spring | PSﾏｴｺﾛｶｱｯｽﾌﾟﾘﾝｸﾞ |
| 53 | LHLDZ1268FCZZ | AE | DS | | C | Collar shaft holder | ｺﾛｼﾞｸﾎﾙﾀﾞｰ |
| 54 | NRŌLP1060FCZZ | AF | DS | | C | U-turn roller | Uﾀｰﾝﾛｰﾗｰ |
| 55 | NSFTZ2127FCZZ | AM | EG | | C | PS front collar shaft | PSﾏｴｺﾛｼﾞｸ |
| 56 | XEBSD40P12000 | AA | DD | | C | Screw (M4 X 12) | ﾋﾞｽ |
| 57 | MSPRC2282FCZZ | AC | DJ | | C | PS roller upper pressure spring | PSﾛｰﾗｰｳｴｶｱｯｽﾌﾟﾘﾝｸﾞ |
| 58 | NBRGP0509FCZ1 | AG | DS | | C | PS bearing | PSｼﾞｸｳｹ |
| 59 | NRŌLM1053FCZ1 | AY | FQ | | C | PS roller upper | PSﾛｰﾗｰｳｴ |
| 60 | PSHEP3741FCZZ | AF | DS | | C | PS front guide sheet | PSﾏｴｶﾞｲﾄﾞﾏｲﾗｰ |
| 61 | PSEL-0669FCZZ | AD | DJ | | C | PG seal 2 | PGｼｰﾙ 2 |
| 62 | XBPSD40P08ES0 | AA | DD | | C | Screw (4 X 8ES) | ﾋﾞｽ |
| 63 | LBSHZ0324FCZZ | AC | DJ | | C | Edge protector | ｴｯｼﾞﾎｺﾞ |
| 64 | PSHEP4068FCZ1 | AE | DJ | | C | Filter fixing sheet | ﾌｨﾙﾀｰｵｻｴﾏｲﾗｰ |

## 10 上ﾌﾚｰﾑ 1(Upper frame 1)



## 11 上ﾌﾚｰﾑ 2(Upper frame 2)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION | |
|---|---|---|---|---|---|---|---|
| | | Ex. | Ja. | | | | |
| 1 | CFRM-0836FC75 | BT | NE | | E | Drive frame unit (USA,CANADA,Hong Kong) | ｸﾄﾞｳﾌﾚｰﾑﾕﾆｯﾄ(ｽｹA) |
| | CFRM-0836FC76 | BT | NE | | E | Drive frame unit (Japan,Russia) | ｸﾄﾞｳﾌﾚｰﾑﾕﾆｯﾄ(ｽｹB) |
| | CFRM-0836FC74 | BT | NE | | E | Drive frame unit (For Europe,Australia,New Zealand,U,Kingdom) | ｸﾄﾞｳﾌﾚｰﾑﾕﾆｯﾄ(ｽｹB) |
| | CFRM-0836FC77 | BX | RR | N | E | Drive frame unit (Taiwan) | ｸﾄﾞｳﾌﾚｰﾑﾕﾆｯﾄ(ｽｹA) |
| 2 | XHBSE40P08000 | AA | DD | | C | Screw (M4 X 8) | ﾋﾞｽ |
| 3 | NBLTH0245FCZZ | AN | EQ | | B | Paper feeding drive belt | ｷｭｳｼｸﾄﾞｳﾍﾞﾙﾄ |
| 4 | LPLTM4757FCZZ | AL | EB | | C | Drive assistance plate | ｸﾄﾞｳﾎｼﾞｮｲﾀ |
| 5 | XRESP70-08000 | AA | DD | | C | E type ring (7mm) | Eﾘﾝｸﾞ |
| 6 | LPiNS0155FCZZ | AA | DD | | C | Pin (φ3-10) | ﾍｲｺｳﾋﾟﾝ |
| 7 | NSFTZ2121FCZ1 | AK | EB | | C | Paper feeding drive shaft | ｷｭｳｼｸﾄﾞｳｼﾞｸ |
| 8 | NPLYZ0285FCZ1 | AE | DS | | C | Transport drive pulley 32T | ﾊﾝｿｳｸﾄﾞｳﾌﾟｰﾘｰ32T |
| 9 | NBRGC0133FCZ1 | AC | DJ | | C | PF bearing (φ8)(B-F8-26) | PFｼﾞｸｳｹ |
| 10 | NGERH1046FCZZ | AE | DJ | | C | 27T gear | 27Tｷﾞﾔ |
| 11 | NBRGC0536FCZZ | AF | DS | | C | Joint arm bearing | ﾚﾝｹﾂｱｰﾑｼﾞｸｳｹ |
| 12 | XRESP50-06000 | AA | DD | | C | E type ring (5mm) | Eﾘﾝｸﾞ |
| 13 | NGERH1015FCZZ | AD | DJ | | C | PS joint gear 25T | PSﾚﾝｹﾂｷﾞﾔｰ25T |
| 14 | CARMM0192FC01 | AE | DS | | C | Joint arm | ﾚﾝｹﾂｱｰﾑ |
| 15 | PRNGP0049FCZZ | AA | DD | | C | Ring (φ12) | ﾘﾝｸﾞ |
| 16 | NGERH1078FCZZ | AD | DJ | | C | 21T gear | 21ｷﾞﾔｰ |
| 17 | LBSHZ0325FCZZ | AD | DJ | | C | Edge protect bushing (L=45) | ｴｯｼﾞﾎｺﾞ |
| 18 | QSW-W9030QSZZ | AV | FG | | B | Heater switch (LLA15L2)(Japan only) | ﾋｰﾀｰｽｲｯﾁ |
| 19 | DHAi-2510FCZZ | AH | DX | | C | DH switch harness (Japan only) | DHｽｲｯﾁﾊｰﾈｽ |
| 20 | LHLDW1269FCZZ | AC | DJ | | C | Wire holder (WWS-A-2-01) | ﾜｲﾔｰﾎﾙﾀﾞｰ |
| 21 | LX-BZ0589FCZZ | AA | DD | | C | Screw | ﾋﾞｽ |
| 22 | NCPL-0007FCZZ | AC | DD | | C | DV cup ring | DVｶｯﾌﾟﾘﾝｸﾞ |
| 23 | MSPRC2319FCZZ | AC | DJ | | C | DV drive spring | DVﾄﾞﾗｲﾌﾞｽﾌﾟﾘﾝｸﾞ |
| 24 | LX-WZ0186FCZZ | AA | DD | | C | Washer (φ6) | ﾎﾞﾘｽﾗｲﾀﾞｰ |
| 25 | NSFTZ2126FCZZ | AN | EG | | C | DV drive shaft | DVｸﾄﾞｳｼﾞｸ |
| 26 | NBRGC0080FCZ1 | AD | DJ | | B | Bearing | DFCﾖｳｼﾞｸｳｹN |
| 27 | NGERH0111FCZZ | AD | DJ | | C | Gear 24T | ｷﾞﾔｰ 24T |
| 28 | XHPSD30P06000 | AA | DD | | C | Screw (M3 X 6) | ﾋﾞｽ |
| 29 | RMÖTD0619FCZZ | AR | EZ | | B | Main motor | ﾄﾅｰﾓｰﾀｰ |
| 30 | CFRM-0687FC02 | AL | EB | | C | DV drive frame | DVｸﾄﾞｳﾌﾚｰﾑ |
| 31 | DHAi-2920FCZZ | AS | EQ | N | C | DV interface harness | DVﾁｭｳｹｲﾊｰﾈｽ |
| 32 | LX-BZ0583FCZZ | AB | DD | | C | Screw | ﾋﾞｽ |
| 33 | MSPRC1534FCZZ | AA | DD | | C | DV drive spring | DVﾄﾞﾗｲﾌﾞｽﾌﾟﾘﾝｸﾞ |
| 34 | LX-BZ0581FCZZ | AB | DD | | C | Screw | ﾋﾞｽ |
| 35 | MSPRC1299FCZZ | AA | DD | | C | DV drive spring | DV ｸﾄﾞｳ ｽﾌﾟﾘﾝｸﾞ |
| 36 | MSPRC2295FCZZ | AC | DJ | | C | Joint arm spring | ﾚﾝｹﾂｱｰﾑｽﾌﾟﾘﾝｸﾞ |
| 37 | LX-BZ0771FCZZ | AC | DD | | C | Screw | ﾋﾞｽ |
| 38 | LPLTM4759FCZZ | AK | DX | | C | Main PWB fixing plate | ﾒｲﾝｷﾊﾞﾝﾄﾘﾂｹｲﾀ |
| 39 | CPWBN1301FC51 | BV | RB | N | E | Main PWB (Japan,100V series) | ﾒｲﾝｷﾊﾞﾝ |
| | CPWBN1301FC52 | BV | RB | N | E | Main PWB (200V series) | ﾒｲﾝｷﾊﾞﾝ |
| 40 | XBPSD40P06K00 | AA | DD | | C | Screw (M4 X 6K) | ﾋﾞｽ |
| 41 | DHAi-2401FCZZ | BF | GN | | C | Optical main harness A (Japan only) | ｺｳｶﾞｸﾒｲﾝﾊｰﾈｽAJ |
| | DHAi-2400FCZZ | BE | GN | | C | Optical main harness (Except Japan) | ｺｳｶﾞｸﾒｲﾝﾊｰﾈｽEX |
| 42 | DHAi-2404FCZZ | AY | FQ | | C | Operation main harness | ｿｳｻﾒｲﾝﾊｰﾈｽ |
| 43 | DHAi-2905FCZZ | BA | FX | N | C | Lower unit main harness (Japan only) | ｼﾀUNﾒｲﾝﾊｰﾈｽ |
| | DHAi-2905FC11 | AZ | FX | N | C | Lower unit main harness (100V series··Except Japan) | ｼﾀUNﾒｲﾝﾊｰﾈｽ |
| | DHAi-2905FC12 | BA | FX | N | C | Lower unit main harness (200V series··Except Europe) | ｼﾀUNﾒｲﾝﾊｰﾈｽ |
| | DHAi-2905FC13 | BA | FX | N | C | Lower unit main harness (200V series··For Europe) | ｼﾀUNﾒｲﾝﾊｰﾈｽ |
| 44 | DHAi-2788FCZZ | AS | EQ | | C | High voltage harness | ｺｳｱﾂﾊｰﾈｽ |
| 45 | RTRNZ0535FCZZ | BS | MJ | N | B | High voltage transformer | ｺｳｱﾂﾄﾗﾝｽ |
| 46 | LSUPP0095FCZZ | AC | DJ | | C | PWB suppoter (LCBS-22N) | ｷﾊﾞﾝｻﾎﾟｰﾀｰ |
| 47 | LSUPP0086FCZZ | AB | DJ | | C | PWB suppoter (LCBS-6N) | ｷﾊﾞﾝｻﾎﾟｰﾀｰ |
| 48 | LSUPP0094FCZZ | AC | DJ | | C | PWB supporter (LCBS-20) | ｷﾊﾞﾝｻﾎﾟｰﾀｰ |
| 49 | LFRM-0835FCZ1 | AU | EZ | | C | Upper frame R | ｳｴﾌﾚｰﾑR |
| 51 | LSTPP0320FCZZ | AC | DJ | | C | Arm stopper | ｱｰﾑｽﾄｯﾊﾟｰ |
| 53 | DHAi-2568FCZZ | AP | EQ | | C | MM interface harness | MMﾁｭｳｹｲﾊｰﾈｽ |
| 55 | PSHEZ3909FCZZ | AE | DS | | C | Insulator sheet | ｾﾞｯｴﾝｼｰﾄ |
| 56 | RCÖRF6661RCZZ | AK | EB | N | C | Feright core (SFC-4)(200V series) | ﾌｪﾗｲﾄｺｱ |
| 57 | LBNDJ0013FCZ1 | AA | DJ | | C | Wire band | ｹｯｿｸﾊﾞﾝﾄﾞ |
| 58 | LBNDJ0015FCZZ | AA | DD | | C | Wire band (N-108) | ﾜｲﾔｰﾊﾞﾝﾄﾞ |

## 11 上ﾌﾚｰﾑ 2(Upper frame 2)




FCP02633

## 12 ｺﾋﾟｰﾗﾝﾌﾟﾕﾆｯﾄ (Copy lamp unit)

| NO. | PARTS CODE | PRICE RANK Ex. | PRICE RANK Ja. | NEW MARK | PART RANK | DESCRIPTION | |
|---|---|---|---|---|---|---|---|
| 1 | LPLTM4124FCZZ | AC | DJ | | C | Control plate | ﾁｮｳｺｳﾊﾞﾝ |
| 2 | PREFL0145FCZZ | AT | FG | | C | Main reflector | ﾘﾌﾚｸﾀｰ |
| ⚠ 3 | RLMPU0494FCZ1 | BC | GN | | B | Copy lamp (Japan, 100V series) | ｺﾋﾟｰﾗﾝﾌﾟ |
| ⚠ 3 | RLMPU0495FCZ1 | BC | GN | | B | Copy lamp (200V series) | ｺﾋﾟｰﾗﾝﾌﾟ |
| 4 | MSPRP2354FCZZ | AG | DX | | C | Lamp spring F | ﾗﾝﾌﾟﾊﾞﾈF |
| ⚠ 5 | CFS-T0104FC31 | AQ | EQ | | A | Temperature fuse | ｵﾝﾄﾞﾋｭｰｽﾞ |
| 6 | LPLTM4966FCZZ | AR | EQ | | C | Terminal plate | ﾀﾝｼﾊﾞﾝ |
| 7 | LPLTP4964FCZZ | AP | EQ | | C | Side plate F | ｿｸﾊﾞﾝF |
| 8 | PCUSS0327FCZZ | AD | DJ | | C | Cushion | ｸｯｼｮﾝ |
| 9 | CSLi-0103FC31 | AF | DS | | E | Slider unit (4pcs/set) | ｽﾍﾞﾘｻﾞｲ |
| 10 | MSPRP2101FCZZ | AC | DJ | | C | Mirror spring | ﾐﾗｰﾊﾞﾈ |
| 11 | PMiR-0076FCZZ | AP | EQ | | B | 1st mirror | ﾀﾞｲ1ﾐﾗｰ |
| 12 | CDAiU0524FC01 | AV | FG | | C | Copy lamp base plate | ｷﾀﾞｲ |
| 13 | LBNDJ0013FCZZ | AA | DD | | C | Wire band | ｹｯｿｸﾊﾞﾝﾄﾞ |
| 14 | DHAi-2503FCZZ | BA | FX | | C | CL harness | CLﾊｰﾈｽ |
| 15 | LPLTP4965FCZZ | AP | EQ | | C | Side plate R | ｿｸﾊﾞﾝR |
| 16 | MSPRP2355FCZZ | AL | EB | | C | Lamp spring R | ﾗﾝﾌﾟﾊﾞﾈR |
| 17 | PCUSF0334FCZZ | AP | EQ | | C | Mirror cushion | ﾐﾗｰｸｯｼｮﾝ |
| 18 | LPLTM4967FCZZ | AE | DS | | C | Fixer plate | ｺﾃｲﾊﾞﾝ |
| 19 | XBPBN30P05K00 | AB | DD | | C | Screw (M3 X 5K) | ﾋﾞｽ |
| 20 | LX-BZ0767FCZZ | AB | DD | | C | Screw | ﾋﾞｽ |
| 21 | XHBSD30P06000 | AA | DD | | C | Screw (M3 X 6) | ﾋﾞｽ |
| 22 | XNESD30-24000 | AA | DD | | C | Nut | ﾅｯﾄ |
| 23 | XEBSF30P06000 | AA | DD | | C | Screw (M3 X 6) | ﾋﾞｽ |
| 24 | MSPRC2369FCZZ | AP | EQ | | C | CL lead fixing spring | CLﾘｰﾄﾞｵｻｴｽﾌﾟﾘﾝｸﾞ |
| | ﾕﾆｯﾄ (Unit) | | | | | | |
| ⚠ 901 | CREFL0145FC35 | BP | LP | | E | Copy lamp unit (Japan, 100V series) | ｺﾋﾟｰﾗﾝﾌﾟﾕﾆｯﾄ |
| ⚠ 901 | CREFL0145FC36 | BP | LP | | E | Copy lamp unit (200V series) | ｺﾋﾟｰﾗﾝﾌﾟﾕﾆｯﾄ |

## 12 ｺﾋﾟｰﾗﾝﾌﾟﾕﾆｯﾄ (Copy lamp unit)



## 13 ﾄﾅｰﾎｯﾊﾟｰﾕﾆｯﾄ (Toner hopper unit)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION | |
|---|---|---|---|---|---|---|---|
| | | Ex. | Ja. | | | | |
| 1 | PCOVP1465FCZZ | AQ | EQ | N | C | Hopper cover SP | ﾎｯﾊﾟｰｶﾊﾞｰSP |
| 3 | PSEL-0446FCZZ | AA | DD | | C | Seal T1 | ｼｰﾙT1 |
| 4 | PMLT-0834FCZZ | AB | DD | | C | Cushion TB | ﾓﾙﾄTB |
| 6 | XEBSD30P08000 | AA | DD | | C | Screw (M3 X 8) | ﾋﾞｽ |
| 7 | PMLT-0836FCZZ | AB | DD | | C | Cushion TD | ﾓﾙﾄTD |
| 8 | PMLT-0835FCZZ | AA | DD | | C | Cushion TC | ﾓﾙﾄTC |
| 10 | PSEL-0660FCZZ | AG | DX | | C | Toner hold seal | ﾄﾅｰｳｹｼｰﾙ |
| 11 | PCOVP1466FCZZ | AN | EG | N | C | Toner cover SP | ﾄﾅｰｶﾊﾞｰSP |
| 12 | PSHEP4569FCZZ | AC | DJ | N | C | Toner cover sheet | ﾄﾅｰｶﾊﾞｰﾏｲﾗｰ |
| 13 | NSFTZ2497FCZZ | AG | DS | N | C | Cover lock shaft | ｶﾊﾞｰﾛｯｸｼﾞｸ |
| 14 | MSPRC2697FCZZ | AC | DJ | N | C | Lock pawl spring | ﾛｯｸﾂﾒｽﾌﾟﾘﾝｸﾞ |
| 15 | LSTPP0347FCZZ | AD | DJ | N | C | Pawl stopper | ﾂﾒｽﾄｯﾊﾟｰ |
| 16 | PTME-0270FCZZ | AE | DS | N | C | Cover lock pawl | ｶﾊﾞｰﾛｯｸﾂﾒ |
| 17 | PGiDM1834FCZ1 | AE | DS | N | C | Cartridge guide SPB (Japan,Australia,Europe,U,Kingdom,Russia, New Zealand) | ｶｰﾄﾘｯｼﾞｶﾞｲﾄﾞSPB |
| | PGiDM1834FCZZ | AE | DS | N | C | Cartridge guide SPA (USA,CANADA,Hong Kong,Taiwan) | ｶｰﾄﾘｯｼﾞｶﾞｲﾄﾞSPA |
| 18 | XRESP20-03000 | AA | DD | | C | E type ring | Eﾘﾝｸﾞ |
| 21 | JHNDP0109FCZZ | AD | DJ | | C | Handle TH | ﾊﾝﾄﾞﾙTH |
| 22 | LX-WZ0225FCZZ | AA | DD | | C | Washer (φ5-φ16) | ﾜｯｼｬ |
| 23 | XUBSD30P05000 | AA | DD | | C | Screw (M3 X 5) | ﾋﾞｽ |
| 24 | XEBSF30P08000 | AA | DD | | C | Screw (M3 X 8) | ﾋﾞｽ |
| 25 | XBBSD40P08000 | AA | DD | | C | Screw (M4 X 8) | ﾋﾞｽ |
| 26 | XEBSD40P08000 | AA | DD | | C | Screw (M4 X 8) | ﾋﾞｽ |
| 27 | PSHEP3955FCZZ | AD | DJ | | C | DV blade sheet | DVﾌﾞﾚｰﾄﾞｼｰﾄ |
| 28 | NROLS0848FCZZ | AP | EQ | | C | Toner roller | ﾄﾅ－ﾛｰﾗ－ |
| 29 | MARMP0120FCZZ | AE | DS | | C | Toner transport arm | ﾄﾅ－ﾊﾝｿｳｱｰﾑ |
| 30 | MSPRT1640FCZZ | AC | DD | | C | Toner stirring spring A | ﾄﾅｰｶｸﾊﾝｽﾌﾟﾘﾝｸﾞ A |
| 31 | NSFTZ1628FCZZ | AF | DS | | C | Shaft TB | ｼｬﾌﾄTB |
| 32 | MARMP0139FCZZ | AE | DS | | C | Arm TA | ｱｰﾑTA |
| 33 | NSFTZ1627FCZZ | AG | DS | | C | Shaft TA | ｼｬﾌﾄTA |
| 34 | NBRGP0299FCZZ | AC | DJ | | B | DV bearing (φ5) | DVｼﾞｸｳｹ |
| 35 | LPiNS0089FCZZ | AA | DD | | C | Spring pin | ｽﾌﾟﾘﾝｸﾞﾋﾟﾝ |
| 36 | NGERH0314FCZZ | AC | DD | | C | Toner transport gear 16T | ﾄﾅｰﾊﾝｿｳｷﾞﾔｰ 16T |
| 37 | XRESP40-06000 | AA | DD | | C | 4E-Type ring (4mm) | Eﾘﾝｸﾞ |
| 38 | NGERH0623FCZZ | AB | DD | | C | Stirring gear | ｶｸﾊﾝｷﾞﾔｰ |
| 39 | XWHSD30-05080 | AA | DD | | C | Washer (3W) | ﾜｯｼｬ |
| 40 | NGERH0626FCZZ | AC | DD | | C | Toner drive gear 16T | Tｸﾄﾞｳｷﾞﾔｰ 16T |
| 41 | PSEL-0433FCZZ | AB | DD | | C | Seal THB | ｼｰﾙTHB |
| 42 | PSEL-0432FCZZ | AA | DD | | C | Seal THA | ｼｰﾙTHA |
| 43 | PSHEP2917FCZZ | AB | DD | | C | Sheet MS | ｼｰﾄMS |
| 44 | PBOX-0086FCZZ | AN | EQ | | D | Box TH | ﾄﾅｰﾎﾞｯｸｽ TH |
| 45 | PSHEP3958FCZZ | AD | DJ | | C | Sheet T1 | ｼｰﾄT1 |
| 47 | PMLT-1023FCZZ | AB | DJ | | C | TH side cushion | THｻｲﾄﾞﾓﾙﾄ |
| | ﾕﾆｯﾄ (Unit) | | | | | | |
| 901 | CBOX-0086FC67 | BK | HC | N | E | Toner hopper unit (Japan,Australia,Europe,U,Kingdom,Russia, New zealand) | ﾄﾅｰﾎｯﾊﾟｰﾕﾆｯﾄ(ｽｹB) |
| | CBOX-0086FC66 | BK | HC | N | E | Toner hopper unit (USA,CANADA,Hong Kong,Taiwan) | ﾄﾅｰﾎｯﾊﾟｰﾕﾆｯﾄ(ｽｹA) |

13 ﾄﾅｰﾎｯﾊﾟｰﾕﾆｯﾄ (Toner hopper unit)



## 14 ﾄﾞﾗﾑﾌﾚｰﾑﾕﾆｯﾄ (Drum frame unit)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION | |
|---|---|---|---|---|---|---|---|
| | | Ex. | Ja. | | | | |
| 1 | LFRM-0844FCZZ | AS | EQ | | C | DR frame upper | DRﾌﾚｰﾑｳｴ |
| 2 | PSHEP3824FCZZ | AF | DS | | C | Shield sheet DL | ｼｬｺｳｼｰﾄDL |
| 3 | LX-BZ0300FCZZ | AB | DD | | C | Screw | ﾋﾞｽ |
| 4 | CPWBF1098FC51 | BB | GD | | E | DL PWB | DLｷﾊﾞﾝ |
| 5 | CPWBF1094FC51 | BG | GT | | E | BL PWB | BLｷﾊﾞﾝ |
| 6 | XEPSD30P08000 | AA | DD | | C | Screw (M3 X 8) | ﾋﾞｽ |
| 7 | LPLTM4765FCZZ | AD | DJ | | C | BL adjusting plate | BLﾁｮｳｾｲﾊﾞﾝ |
| 8 | XBPSD30P06000 | AA | DD | | C | Screw (M3 X 6) | ﾋﾞｽ |
| 9 | LBNDJ0013FCZ1 | AA | DJ | | C | Wire band | ｹｯｿｸﾊﾞﾝﾄﾞ |
| 10 | CPWBF1092FC51 | AS | EQ | | E | Mark sensor PWB | ﾏｰｸｾﾝｻｰｷﾊﾞﾝ |
| 11 | XUPSD30P04000 | AA | DD | | C | Screw (M3 X 4) | ﾋﾞｽ |
| 12 | LX-BZ0426FCZZ | AA | DD | | C | Screw (M4 X 10)(Blue) | ﾋﾞｽ |
| 13 | PSHEZ4015FCZZ | AC | DJ | | C | Black sheet A | ｸﾛｼｰﾄA |
| 21 | CYOK-0048FC31 | AL | EB | | D | Waste toner bottle unit | ﾊｲﾄﾅｰﾎﾞﾄﾙﾕﾆｯﾄ |
| 23 | NBRGP0534FCZ1 | AD | DJ | | C | Waste toner bearing 2 | ﾊｲﾄﾅｰｼﾞｸｳｹ2 |
| 24 | NGERH1044FCZZ | AF | DS | | C | Gear 87T | ｷﾞﾔ87T |
| 25 | MSPRC2288FCZZ | AC | DJ | | C | Waste toner spring | ﾊｲﾄﾅｰｽﾌﾟﾘﾝｸﾞ |
| 26 | LX-BZ0334FCZZ | AA | DD | | C | Screw (M4 X 8KS)(Blue) | ﾋﾞｽ |
| 27 | UCLEZ0108FCZ1 | AV | FG | | C | Cleaning blade (FB30N) | ｸﾘｰﾆﾝｸﾞﾌﾞﾚｰﾄﾞ |
| 28 | XEBSD30P08000 | AA | DD | | C | Screw (M3 X 8) | ﾋﾞｽ |
| 29 | LPLTM4764FCZZ | AP | EQ | | C | Blade fixing plate | ﾌﾞﾚｰﾄﾞﾄﾘﾂｹｲﾀ |
| 30 | NGERH1045FCZZ | AD | DJ | | C | Gear 16T | ｷﾞﾔ16T |
| 31 | NBRGC0080FCZZ | AD | DJ | | B | Bearing | DFCﾖｳﾍﾞｱﾘﾝｸﾞ |
| 32 | XRESP70-08000 | AA | DD | | C | E type ring (7mm) | Eﾘﾝｸﾞ |
| 33 | MSPRC1811FCZZ | AA | DD | | C | Separator lever spring | ﾊｸﾘﾚﾊﾞｰ ﾖｳｽﾌﾟﾘﾝｸﾞ |
| 34 | MLEVP0672FCZZ | AH | DX | | C | Separator pawl lever | ﾊｸﾘﾂﾒﾚﾊﾞｰ |
| 35 | XRESP40-06000 | AA | DD | | C | 4E-Type ring (4mm) | Eﾘﾝｸﾞ |
| 36 | XEBSD30P20000 | AA | DD | | C | Screw (M3 X 20) | ﾋﾞｽ |
| 37 | NGERH1043FCZZ | AF | DS | | C | Gear 44T | ｷﾞﾔ44T |
| 38 | PRNGP0025FCZZ | AA | DD | | C | G type ring (GTW-5) | Gﾘﾝｸﾞ |
| 39 | NGERH1074FCZZ | AD | DJ | | C | Waste toner gear | ﾊｲﾄﾅｰｷﾞﾔ |
| 40 | LPiNS0297FCZZ | AB | DJ | | C | Pin (φ2 X 6) | ﾏﾙ2X6ﾋﾟﾝ |
| 41 | NBRGY2122SCZZ | AB | DD | | C | Bearing | ｼﾞｸｳｹ |
| 42 | LPLTM4763FCZZ | AC | DJ | | C | Screw reinforce plate | ｽｸﾘｭｰﾎｷｮｳｲﾀ |
| 43 | NGERH1042FCZZ | AD | DJ | | C | Gear 19T | ｷﾞﾔ19T |
| 44 | PMLT-0999FCZZ | AC | DJ | | C | Blade sheet | ﾌﾞﾚｰﾄﾞﾖｳﾓﾙﾄ |
| 45 | PMLT-0985FCZ1 | AF | DS | | C | Toner cushion R | ﾄﾅｰﾓﾙﾄR |
| 46 | PMLT-0984FCZ1 | AF | DS | | C | Toner cushion F | ﾄﾅｰﾓﾙﾄF |
| 47 | CPLTM4903FC02 | AU | EZ | | C | Toner sheet plate | Tｳﾚｼｰﾄｲﾀ |
| 48 | NBRGP0535FCZZ | AD | DJ | | C | Pipe bearing | ﾊﾟｲﾌﾟｼﾞｸｳｹ |
| 49 | NSRW-0023FCZZ | AS | EZ | | C | Toner transport screw | ﾄﾅｰﾊﾝｿｳｽｸﾘｭ |
| 50 | MSPRC2287FCZ2 | AL | EB | | C | Waste toner transport spring | ﾊｲﾄﾅｰﾊﾝｿｳｽﾌﾟﾘﾝｸﾞ |
| 51 | CPiPP0182FC04 | AM | EG | | C | Toner transport pipe | ﾄﾅｰﾊﾝｿｳﾊﾟｲﾌﾟ |
| 52 | NBRGP0533FCZZ | AG | DX | | C | Waste toner bearing 1 | ﾊｲﾄﾅｰｼﾞｸｳｹ1 |
| 53 | XEBSD40P10000 | AA | DD | | C | Screw (M4 X 10) | ﾋﾞｽ |
| 54 | PGiDM1602FCZZ | AG | DX | | C | Waste toner guide | ﾊｲﾄﾅｰｶﾞｲﾄﾞ |
| 55 | XEBS230P08000 | AA | DD | | C | Screw (M3 X 8)(Blue) | ﾋﾞｽ |
| 56 | LFRM-0843FCZZ | AY | FQ | | C | DR frame lower | DRﾌﾚｰﾑｼﾀ |
| 57 | LHLDZ1274FCZZ | AF | DS | | C | Sensor holder | ｾﾝｻｰﾎﾙﾀﾞｰ |
| 58 | CPWBF0976FC53 | AR | EQ | | E | Process control PWB | ﾌﾟﾛｾｽｺﾝﾄﾛｰﾙｷﾊﾞﾝ |
| 59 | PCOVP1184FCZ1 | AC | DJ | | C | DR sensor cover | DRｾﾝｻｰｶﾊﾞｰ |
| 60 | LX-WZ0310FCZZ | AB | DD | | C | Washer | ﾜｯｼｬ |
| 61 | MSPRC2025FCZZ | AA | DD | | C | Separator pawl spring | ﾊｸﾘﾂﾒｽﾌﾟﾘﾝｸﾞ |
| 62 | PTME-0211FCZ1 | AG | DX | | C | DR separator pawl | DRﾊｸﾘﾂﾒ |
| 63 | LPiNS0298FCZZ | AA | DJ | | C | Pawl shaft pin | ﾂﾒｼﾞｸﾋﾟﾝ |
| 64 | LX-WZ0285FCZZ | AA | DD | | C | Washer | ﾜｯｼｬ |
| 65 | LPLTM4982FCZZ | AC | DJ | | C | Tap plate | ﾀｯﾌﾟﾌﾟﾚｰﾄ |
| 66 | PRNGP0026FCZZ | AA | DD | | C | G type ring (GTW-3) | Gﾘﾝｸﾞ |
| 68 | PSHEP3929FCZZ | AD | DJ | | C | Blade sheet | ﾌﾞﾚｰﾄﾞﾏｲﾗｰ |
| 69 | PSHEZ3899FCZ1 | AC | DJ | | C | Pipe sheet | ﾊﾟｲﾌﾟｼｰﾄ |
| 70 | LX-BZ0656FCZZ | AD | DJ | | C | Screw | ﾋﾞｽ |
| 71 | XRESP50-06000 | AA | DD | | C | E type ring (5mm) | Eﾘﾝｸﾞ |
| 72 | PSHEP3930FCZ1 | AD | DJ | | C | Blade sheet F | ﾌﾞﾚｰﾄﾞﾏｲﾗｰF |
| 73 | PMLT-0991FCZZ | AA | DJ | | C | Side cushion | ｻｲﾄﾞﾓﾙﾄ |
| 74 | PSHEP3931FCZZ | AD | DJ | | C | Blade sheet R | ﾌﾞﾚｰﾄﾞﾏｲﾗｰR |
| 75 | PMLT-1012FCZZ | AA | DJ | | C | Screw cushion | ｽｸﾘｭｰﾓﾙﾄ |
| 76 | DHAi-2508FCZZ | AP | EQ | | C | Process interface harness | ﾌﾟﾛｾｽﾁｭｳｹｲﾊｰﾈｽ |
| 77 | PMLT-1025FCZZ | AE | DS | | C | Waste toner cushion A | ﾊｲﾄﾅｰﾓﾙﾄ A |
| 78 | PMLT-1026FCZZ | AF | DS | | C | Waste toner cushion B | ﾊｲﾄﾅｰﾓﾙﾄ B |
| 79 | PSHEP4019FCZZ | AC | DJ | | C | Process sheet | ﾌﾟﾛｾｽｼｰﾄ |
| 81 | CPLTM4027FC09 | AL | EB | | C | Drum control plate F A | ﾄﾞﾗﾑｲﾁｷﾞﾒｲﾀF A |
| 82 | CCOVP1281FC01 | AQ | EQ | | D | Process cover(This includes NO84) | ﾌﾟﾛｾｽｶﾊﾞｰ(NO84ﾌｸﾑ) |
| 83 | TCAUH0819FCZZ | AA | DD | | C | High voltage caution label (Japan only) | ｺｳｱﾂﾁｭｳｲﾗﾍﾞﾙJ |
| | TCAUH0974FCZZ | AB | DJ | | C | High voltage caution label (Australia,New Zealand,U,Kingdom) | ｺｳｱﾂﾁｭｳｲﾗﾍﾞﾙU-N |
| | TCAUH1039FCZZ | AC | DJ | | C | High voltage caution label (USA,CANADA,Europe) | ｺｳｱﾂﾁｭｳｲﾗﾍﾞﾙ E4 |
| | TCAUH0821FCZZ | AA | DD | | C | High voltage caution label (Other countries) | ｺｳｱﾂﾁｭｳｲﾗﾍﾞﾙE |
| 84 | PMLT-1005FCZZ | AC | DJ | | C | Pipe fixing cushion | ﾊﾟｲﾌﾟｵｻｴﾓﾙﾄ |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |

## 14 ﾄﾞﾗﾑﾌﾚｰﾑﾕﾆｯﾄ (Drum frame unit)



## 15 現像ﾕﾆｯﾄ (Developer unit)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION | |
|---|---|---|---|---|---|---|---|
| | | Ex. | Ja. | | | | |
| 1 | LPLTM3772FCZ1 | AU | EZ | | C | Plate DN | ﾌﾟﾚｰﾄDN |
| 2 | PSHEZ3910FCZZ | AB | DJ | | C | Doctor sheet | ﾄﾞｸﾀｰｽｪｰﾄﾞ |
| 3 | XBPSD30P08KS0 | AA | DD | | C | Screw (M3 X 8KS) | ﾋﾞｽ |
| 4 | NGERH1040FCZZ | AD | DJ | | C | Gear DV1 | ｷﾞﾔDV1 |
| 5 | CCLR-0403FC01 | AH | DX | | C | DSD collar | DSDｶﾗｰ |
| 6 | XRESP50-06000 | AA | DD | | C | E type ring (5mm) | Eﾘﾝｸﾞ |
| 7 | NBRGC0136FCZ1 | AC | DJ | | B | Toner box bearing (φ6) | ﾄﾅｰﾎﾞｯｸｽﾖｳ ｼﾞｸｳｹ |
| 8 | PRNGP0050FCZZ | AE | DS | | C | V ring (φ6) | Vﾘﾝｸﾞ |
| 9 | PSEL-0443FCZZ | AA | DD | | C | Seal MF | ｼｰﾙMF |
| 10 | NROLM1061FCZ1 | BD | GN | N | C | Magnet roller | MGﾛｰﾗｰ |
| 11 | PRNGP0019FCZZ | AA | DD | | C | G ring (GTW-6) | Gﾘﾝｸﾞ |
| 12 | LPLTM3877FCZZ | AD | DJ | | C | Plate DVR | ﾌﾟﾚｰﾄDVR |
| 13 | XRESP40-06000 | AA | DD | | C | 4E-Type ring (4mm) | Eﾘﾝｸﾞ |
| 14 | LX-WZ0294FCZZ | AA | DD | | C | Washer | ﾜｯｼｬ |
| 15 | CGERH1041FC01 | AG | DS | | C | Gear DVA | ｷﾞﾔDVA |
| 16 | NGERH1056FCZZ | AE | DJ | | C | Gear DV2 | ｷﾞﾔDV2 |
| 17 | NGERH1057FCZZ | AE | DJ | | C | Gear DV3 | ｷﾞﾔDV3 |
| 18 | XEBSD30P10000 | AA | DD | | C | Screw (M3 X 10) | ﾋﾞｽ |
| 19 | DHAi-2919FCZZ | AQ | EQ | N | C | DV harness | DVﾊｰﾈｽ |
| 20 | XBBSD30P18000 | AA | DD | | C | Screw (M3 X 18) | ﾋﾞｽ |
| 21 | NROLP0845FCZ1 | AR | EQ | | C | Roller MX | ﾛｰﾗｰMX |
| 22 | PSEL-0676FCZZ | AC | DJ | | C | Seal DER | ｼｰﾙDER |
| 23 | PSEL-0675FCZZ | AC | DJ | | C | Seal DEF | ｼｰﾙDEF |
| 24 | PSEL-0652FCZZ | AC | DJ | | C | AG seal | AGｼｰﾙ |
| 25 | LHLDZ1237FCZZ | AC | DJ | | C | Holder | ﾎﾙﾀﾞｰM |
| 26 | LPLTM2430FCZZ | AC | DD | | C | Magnet adjusting plate | MGﾁｮｳｾｲｲﾀ |
| 27 | LX-BZ0529FCZZ | AA | DD | | C | Screw | ﾋﾞｽ |
| 28 | LSTPF0262FCZZ | AC | DD | | C | Stopper DV | ｽﾄｯﾊﾟｰ DV |
| 29 | CBOX-0085FC02 | AY | FQ | | C | DV box | DVﾎﾞｯｸｽ |
| 30 | RDTCT0117FCZ1 | AY | FQ | N | B | ATC (SF-2216/SF-2218) | ATC |
| 31 | XEBSD30P08000 | AA | DD | | C | Screw (M3 X 8) | ﾋﾞｽ |
| 32 | PSHEP2713FCZZ | AC | DD | | C | Sheet TB | ｼｰﾄTB |
| 33 | LPLTM4984FCZZ | AP | EQ | | C | DV scraper | DVｽｸﾚﾊﾟｰ |
| 34 | XBPBW30P06000 | AA | DD | | C | Screw (M3 X 6) | ﾋﾞｽ |
| 35 | PSEL-0670FCZZ | AC | DJ | | C | AG seal 2 | AGｼｰﾙ 2 |
| 36 | NBRGC0580FCZZ | AG | DS | | B | Bearing (φ6) | ｼﾞｸｳｹ |
| | ﾕﾆｯﾄ (Unit) | | | | | | |
| 901 | CBOX-0085FC69 | BU | NN | N | E | Developer unit | ｹﾞﾝｿﾞｳﾕﾆｯﾄ |

## 15 現像ﾕﾆｯﾄ (Developer unit)



## 16 定着ﾕﾆｯﾄ(Fusing unit)

| NO. | PARTS CODE | PRICE RANK Ex. | PRICE RANK Ja. | NEW MARK | PART RANK | DESCRIPTION | |
|---|---|---|---|---|---|---|---|
| 1 | XHBSD30P06000 | AA | DD | | C | Screw (M3 X 6) | ﾋﾞｽ |
| 2 | PCOVQ1278FCZZ | BA | FX | | D | Fusing cover | ﾃｲﾁｬｸｶﾊﾞｰ |
| 3 | TCAUH1018FCZZ | AG | DX | | C | High temperature caution label (Japan only) | ｺｳｵﾝﾁｭｳｲﾗﾍﾞﾙJ |
| | TCAUH0999FCZZ | AE | DJ | | C | High temperature caution label (Australia,New Zealand,U,Kingdom) | ｺｳｵﾝﾁｭｳｲﾗﾍﾞﾙU |
| | TCAUH1000FCZZ | AE | DJ | | C | High temperature caution label (Other countries) | ｺｳｵﾝﾁｭｳｲﾗﾍﾞﾙ E4 |
| 4 | XHBSD30P04000 | AA | DD | | C | Screw (M3 X 4) | ﾋﾞｽ |
| 5 | XWHSD30-05080 | AA | DD | | C | Washer (3W) | ﾜｯｼｬ |
| ⚠6 | RTHM-0014FCZZ | AM | EG | | B | Thermostat (Japan only) | ｻｰﾓｽﾀｯﾄ |
| ⚠6 | RTHM-0009FCZZ | AK | EB | | B | Thermostat (Except Japan) | ｻｰﾓｽﾀｯﾄ |
| 7 | XHBSD30P10000 | AA | DD | | C | Screw (M3 X 10) | ﾋﾞｽ |
| 8 | RDTCT0116FCZZ | AR | EQ | | B | Thermistor | ｻｰﾐｽﾀ |
| 9 | MSPRT1324FCZ1 | AA | DJ | | C | Delivery spring | ﾊｲｼｽﾌﾟﾘﾝｸﾞ |
| 10 | NROLR1112FCZZ | AG | DX | | C | Delivery upper roller A | ﾊｲｼｭﾂﾛｰﾗｰ A |
| 11 | LHLDZ1191FCZZ | AC | DJ | | C | Lamp holder | ﾗﾝﾌﾟﾎﾙﾀﾞｰ |
| 12 | XEPSD30P08X00 | AA | DD | | C | Screw (M3 X 8X) | ﾋﾞｽ |
| 13 | LFRM-0842FCZ1 | AP | EQ | | C | Fusing upper frame | ﾃｲﾁｬｸｳｴﾌﾚｰﾑ |
| 14 | PBRSR0140FCZ1 | AH | DX | | B | Discharge brush | ｼﾞｮﾃﾞﾝﾌﾞﾗｼ |
| 15 | MSPRC2348FCZZ | AB | DJ | | C | Separator pawl spring | ﾊｸﾘｿﾞﾒｽﾌﾟﾘﾝｸﾞ |
| 16 | PTME-0168FCZZ | AF | DX | | S | Upper separator pawl | ｳｴﾊｸﾘｿﾒ |
| 17 | LDAiU0488FCZZ | AB | DJ | | C | Paper guide block R | P/GﾀｶｻﾌﾞﾛｯｸR |
| 18 | MSPRT2286FCZZ | AC | DJ | | C | Fusing front paper guide spring | ﾃｲﾁｬｸﾏｴﾍﾟｰﾊﾟｰｶﾞｲﾄﾞｽﾌﾟﾘﾝｸﾞ |
| 19 | PGiDH1548FCZZ | AG | DX | | C | Fusing front paper guide | ﾃｲﾁｬｸﾏｴﾍﾟｰﾊﾟｰｶﾞｲﾄﾞ |
| 20 | LDAiU0487FCZZ | AB | DJ | | C | Paper guide block F | P/GﾀｶｻﾌﾞﾛｯｸF |
| 21 | LX-BZ0342FCZZ | AB | DD | | C | Screw | ﾋﾞｽ |
| 22 | CBRGP0525FC02 | AN | EG | | B | Fusing bearing F | ﾃｲﾁｬｸｼﾞｸｳｹ F |
| 23 | NROLT1063FCZ2 | BD | GN | | C | Upper heat roller | ｳｴﾋｰﾄﾛｰﾗｰ |
| 24 | LSTPF0172FCZ1 | AA | DJ | | C | Roller stopper | ﾛｰﾗｰｽﾄｯﾊﾟｰ |
| 25 | CBRGP0528FC02 | AN | EG | | B | Fusing bearing R | ﾃｲﾁｬｸｼﾞｸｳｹ R |
| 26 | NGERH1214FCZZ | AP | EQ | | C | Fusing gear | ﾃｲﾁｬｸｷﾞｱ |
| ⚠27 | RLMPU0546FCZZ | BD | GJ | | B | Heater lamp (100V) | ﾋｰﾀｰﾗﾝﾌﾟ |
| ⚠27 | RLMPU0547FCZZ | BD | GJ | | B | Heater lamp (110V) | ﾋｰﾀｰﾗﾝﾌﾟ |
| ⚠27 | RLMPU0548FCZZ | BD | GJ | | B | Heater lamp (120V) | ﾋｰﾀｰﾗﾝﾌﾟ |
| ⚠27 | RLMPU0551FCZZ | BD | GJ | | B | Heater lamp (220V) | ﾋｰﾀｰﾗﾝﾌﾟ |
| ⚠27 | RLMPU0552FCZZ | BD | GJ | | B | Heater lamp (220V/230V··For Europe,U,Kingdom) | ﾋｰﾀｰﾗﾝﾌﾟ |
| ⚠27 | RLMPU0553FCZZ | BD | GJ | | B | Heater lamp (230V/240V··Australia,New Zealand) | ﾋｰﾀｰﾗﾝﾌﾟ |
| 28 | PTUBG0100FCZZ | AC | DD | | C | Fusing protect tube | ﾃｲﾁｬｸﾎｺﾞﾃｰﾌﾟ |
| 29 | LPLTM5010FCZZ | AD | DJ | | C | Delivery guide plate | ﾊｲｼｶﾞｲﾄﾞｲﾀ |
| 30 | PWiR-0176FCZZ | AP | EQ | | C | Fusing wire | ﾃｲｲﾁｬｸﾜｲﾔｰ |
| 31 | NROLR1113FCZZ | AG | DX | | C | Delivery upper roller B | ﾊｲｼｭﾂﾛｰﾗｰ B |
| 32 | LPLTM5036FCZZ | AD | DJ | | C | Delivery coller guide plate | ﾊｲｼｭﾂﾛｶﾞｲﾄﾞｲﾀ |
| 33 | LPLTM5156FCZZ | AE | DJ | | C | PG height adjustment plate | PGﾀｶｻﾁｮｳｾｲｲﾀ |
| 34 | XXXSP30L15000 | AB | DD | | C | Screw | ﾋﾞｽ |
| 35 | PGiDH1765FCZZ | AD | DJ | | C | Fusing actuator guide | ﾃｲﾁｬｸｱｸﾁｴｰﾀｰｶﾞｲﾄﾞ |
| 36 | PSHEZ4449FCZZ | AC | DJ | | C | Fusing guide sheet | ﾃｲﾁｬｸｶﾞｲﾄﾞｼｰﾄ |
| 37 | PSHEP4400FCZZ | AD | DJ | | C | Fusing sheet | ﾃｲﾁｬｸｼｰﾄ |
| 38 | LSTPP0279FCZZ | AB | DD | | C | Stopper | ｽﾄｯﾊﾟｰ |
| | ﾕﾆｯﾄ (Unit) | | | | | | |
| ⚠901 | DUNTW6740FC70 | BU | NN | | E | Fusing unit (100V) | ﾃｲﾁｬｸﾕﾆｯﾄ |
| ⚠901 | DUNTW6740FC61 | BU | NN | | E | Fusing unit (110V) | ﾃｲﾁｬｸﾕﾆｯﾄ |
| ⚠901 | DUNTW6740FC63 | BU | NN | | E | Fusing unit (120V) | ﾃｲﾁｬｸﾕﾆｯﾄ |
| ⚠901 | DUNTW6740FC65 | BU | NN | | E | Fusing unit (220V) | ﾃｲﾁｬｸﾕﾆｯﾄ |
| ⚠901 | DUNTW6740FC66 | BU | NN | | E | Fusing unit (230V/240V··Australia,New Zealand) | ﾃｲﾁｬｸﾕﾆｯﾄ |
| ⚠901 | DUNTW6740FC68 | BU | NN | | E | Fusing unit (220V/230V··For Europe) | ﾃｲﾁｬｸﾕﾆｯﾄ |
| ⚠901 | DUNTW6740FC69 | BU | NN | | E | Fusing unit (220V/230V··U,Kingdom) | ﾃｲﾁｬｸﾕﾆｯﾄ |

## 16 定着ﾕﾆｯﾄ (Fusing unit)




FCP02638

## 17 給紙ﾕﾆｯﾄ(Paper feeding unit)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION | |
|---|---|---|---|---|---|---|---|
| | | Ex. | Ja. | | | | |
| 1 | XRESP70-08000 | AA | DD | | C | E type ring (7mm) | Eﾘﾝｸﾞ |
| 2 | PSHEP2348FCZZ | AB | DD | | C | Flange sheet DL | ﾌﾗﾝｼﾞﾏｲﾗｰDL |
| 3 | NPLYZ0295FCZ1 | AM | EG | | C | Transport roller pulley | ﾊﾝｿｳﾛｰﾗｰﾖｳﾌﾟｰﾘｰ |
| 4 | NBRGP0510FCZZ | AC | DJ | | C | Roller bearing | ﾛｰﾗｰｼﾞｸｳｹ |
| 5 | NRŌLR1059FCZ1 | AS | EZ | | C | PS front roller | PSﾏｴﾛｰﾗｰ |
| 6 | MLEVP0669FCZZ | AE | DJ | | C | PPD actuator | PPDｱｸﾁｴｰﾀ |
| 7 | CPWBF1086FC32 | AP | EQ | | E | DPPD1 PWB | DPPD1 ｷﾊﾞﾝ |
| 8 | CPWBF1088FC31 | AU | FG | | E | Paper feeding interface PWB | ｷｭｳｼﾁｭｳｹｲｷﾊﾞﾝ |
| 9 | XEPSD40P10000 | AA | DD | | C | Screw (M4 X 10) | ﾋﾞｽ |
| 10 | CGERH0406FC01 | AE | DS | | C | DV idler gear 24T | DV ｱｲﾄﾞﾗｷﾞﾔｰ24T |
| 11 | PCLC-0270FCZZ | AW | FG | | B | 22T electromagnetic spring clutch | 22Tﾃﾞﾝｼﾞｽﾌﾟﾘﾝｸﾞｸﾗｯﾁ |
| 12 | PCLR-0401FCZZ | AD | DJ | | C | Joint collar 25.3 | ﾚﾝｹﾂｶﾗｰ25.3 |
| 13 | NBRGC2019SCZZ | AC | DJ | | C | Bearing (φ8) | ﾍﾞｱﾘﾝｸﾞ |
| 14 | PCLC-0237FCZ1 | AX | FG | | B | 30T electromagnetic spring clutch | 30Tﾃﾞﾝｼﾞｽﾌﾟﾘﾝｸﾞｸﾗｯﾁ |
| 15 | NBRGP0191FCZZ | AB | DD | | C | PF bearing (φ8) | PFｼﾞｸｳｹ |
| 16 | CFRM-0841FC01 | AL | EB | | C | Paper feeding drive frame | ｷｭｳｼｸﾄﾞｳﾌﾚｰﾑ |
| 17 | LFRM-0840FCZ1 | AT | EZ | N | C | Paper feeding frame | ｷｭｳｼﾌﾚｰﾑ |
| 18 | MLEVP0670FCZZ | AE | DJ | | C | PID actuator | PIDｱｸﾁｴｰﾀ |
| 19 | LSTPP0314FCZZ | AA | DJ | | C | E3 stopper | E3ｽﾄｯﾊﾟｰ |
| 20 | NRŌLP1060FCZZ | AF | DS | | C | U-turn roller | Uﾀｰﾝﾛｰﾗｰ |
| 21 | NSFTZ2130FCZZ | AF | DS | | C | U-turn roller shaft | Uﾀｰﾝﾛｰﾗｰｼﾞｸ |
| 22 | LHLDZ1204FCZZ | AG | DX | | C | Paper feeding collar holder 250 | ｷｭｳｼｺﾛﾎﾙﾀﾞｰ 250 |
| 23 | NSFTZ2206FCZZ | AK | DX | | C | Roller shaft | ﾖﾋﾞｺﾐﾛｰﾗｼﾞｸ |
| 24 | NRŌLR1049FCZ1 | AU | EZ | | C | Paper feeding roller | ｷｭｳｼﾛｰﾗｰ |
| 25 | LPiNS0133FCZZ | AA | DD | | C | Pin (φ2-10) | ﾍｲｺｳﾋﾟﾝ |
| 26 | NBLTH0235FCZZ | AF | DX | | B | Belt (80MXL3.2) | ﾍﾞﾙﾄ |
| 27 | NPLYZ0106FCZZ | AC | DJ | | C | Pulley 22 | ﾌﾟｰﾘｰ 22 |
| 28 | MSPRC2336FCZZ | AC | DJ | | C | Roller release arm spring | ﾛｰﾗｰｶｲｼﾞｮｱｰﾑｽﾌﾟﾘﾝｸﾞ |
| 29 | MARMP0187FCZZ | AC | DJ | | C | Roller release arm | ﾛｰﾗｰｶｲｼﾞｮｱｰﾑ |
| 30 | MSPRC2335FCZZ | AK | DX | | C | Limiter spring | ﾘﾐｯﾀｰｽﾌﾟﾘﾝｸﾞ |
| 31 | PCLR-0230FCZZ | AD | DJ | | C | Collar | ﾊﾞﾈｳｹ ｶﾗｰ |
| 32 | LPiNS0134FCZZ | AB | DD | | C | Pin (φ2-12) | ﾍｲｺｳﾋﾟﾝ |
| 33 | NSFTZ2129FCZZ | AP | EQ | | C | Paper feeding roller shaft | ｷｭｳｼﾛｰﾗｰｼﾞｸ |
| 34 | LSTPP0279FCZZ | AB | DD | | C | Stopper | ｽﾄｯﾊﾟｰ |
| 35 | NRŌLR0878FCZZ | AM | EG | | C | Roller | ADFﾖﾋﾞｺﾐﾛｰﾗｰ |
| 36 | LBNDJ0043FCZZ | AA | DD | | C | Snap band | ｽﾅｯﾌﾟﾊﾞﾝﾄﾞ |
| 37 | XHBSE40P08000 | AA | DD | | C | Screw (M4 X 8)(Japan only) | ﾋﾞｽ |
| 38 | XEPSD40P10000 | AA | DD | | C | Screw (M4 X 10)(Japan only) | ﾋﾞｽ |
| 39 | LBNDJ0016FCZZ | AA | DD | | C | Wire band (HP-3N)(Japan only) | ﾜｲﾔｰﾊﾞﾝﾄﾞ |
| ⚠ 40 | CR-WZ0461FC01 | AZ | FQ | | B | Paper feeding warm heater (Japan only) | ｷｭｳｼﾎｵﾝﾋｰﾀｰ |
| 41 | PSHEP3906FCZZ | AD | DJ | | C | Edge protect sheet | ｴｯｼﾞﾎｺﾞﾏｲﾗｰ |
| 42 | PMLT-1001FCZZ | AC | DJ | | C | Cushion | ｼｮｳｵﾝﾓﾙﾄ |
| 43 | NBRGC0584FCZZ | AD | DJ | | C | Clutch bearing | ｸﾗｯﾁｼﾞｸｳｹ |
| 44 | XRESP50-06000 | AA | DD | | C | E type ring | Eﾘﾝｸﾞ |
| 45 | PSHEP4115FCZZ | AD | DJ | | C | PF harness protect sheet (Japan only) | ｷｭｳｼﾊｰﾈｽﾎｺﾞｼｰﾄ |
| 46 | LX-BZ0193FCZZ | AB | DD | | C | Screw | ﾋﾞｽ |
| | ﾕﾆｯﾄ (Unit) | | | | | | |
| 901 | CFRM-0841FC32 | BT | NE | | E | Paper feeding unit (Japan only) | ｷｭｳｼﾕﾆｯﾄ |
| | CFRM-0841FC31 | BS | MJ | | E | Paper feeding unit (Except Japan) | ｷｭｳｼﾕﾆｯﾄ |

## 17 給紙ﾕﾆｯﾄ (Paper feeding unit)



## 18 ﾒｲﾝ駆動ﾕﾆｯﾄ(Main drive unit)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION | |
|---|---|---|---|---|---|---|---|
| | | Ex. | Ja. | | | | |
| 1 | XHPSD30P06000 | AA | DD | | C | Screw (M3 X 6) | ﾋﾞｽ |
| 2 | MSPRP1293FCZZ | AB | DD | | C | Electrode spring | ﾃﾞﾝｷｮｸ ｽﾌﾟﾘﾝｸﾞ |
| 3 | LX-NZ0089FCZZ | AA | DD | | C | Nut | ﾅｯﾄ |
| 4 | LPLTM4778FCZZ | AD | DJ | | C | Spring plate for AC | AC ﾖｳSPﾊﾞﾈ |
| 5 | LPLTM4777FCZZ | AD | DJ | | C | Spring plate for TC | TC ﾖｳSPﾊﾞﾈ |
| 7 | DHAi-2788FCZZ | AS | EQ | | C | High voltage harness | ｺｳｱﾂﾊｰ ﾈｽ |
| 8 | LHLDZ1229FCZZ | AN | EQ | | C | High voltage holder | ｺｳｱﾂﾎﾙﾀﾞｰ |
| 9 | XHBSE40P08000 | AA | DD | | C | Screw (M4 X 8) | ﾋﾞｽ |
| 10 | RPLU-0304FCZZ | AN | EQ | | B | Separator solenoid | ﾊｸﾘｿﾚﾉｲﾄﾞ |
| 11 | MLEVP0668FCZZ | AE | DJ | | C | Separator solenoid lever | ﾊｸﾘSOL ﾚﾊﾞｰ |
| 12 | XBPSD20P03000 | AA | DD | | C | Screw (M2 X 3) | ﾋﾞｽ |
| 13 | RMOTN0765FCZZ | BL | HL | | B | Main motor | ﾒｲﾝﾓｰﾀｰ |
| 14 | PSHEG3831FCZ1 | AF | DS | | C | Motor protection sheet | ﾓｰﾀｰﾎﾞｳｼｼｰﾄ |
| 15 | XRESP70-08000 | AA | DD | | C | E type ring (7mm) | Eﾘﾝｸﾞ |
| 16 | NGERH0457FCZZ | AC | DD | | C | DV drive gear R 22T | DVｸﾄﾞｳｷﾞﾔｰ R 22T |
| 17 | PCLR-0401FCZZ | AD | DJ | | C | Joint collar 25.3 | ﾚﾝｹﾂｶﾗｰ25.3 |
| 18 | LPiNS0155FCZZ | AA | DD | | C | Pin (φ3-10) | ﾍｲｺｳﾋﾟﾝ |
| 19 | NBRGC0133FCZ1 | AC | DJ | | C | PF bearing (φ8) | PFｼﾞｸｳｹ |
| 20 | XBBSD30P08000 | AA | DD | | C | Screw (M3 X 8) | ﾋﾞｽ |
| 21 | XRESP50-06000 | AA | DD | | C | E type ring (5mm) | Eﾘﾝｸﾞ |
| 22 | NGERH1031FCZZ | AD | DJ | | C | 20T gear H | 20Tｷﾞﾔ H |
| 23 | LPiNS0094FCZZ | AB | DD | | C | Pin (φ3 X 8) | ﾍｲｺｳﾋﾟﾝ |
| 24 | LFRM-0837FCZZ | AH | DX | | C | Drive frame 2 | ｸﾄﾞｳﾌﾚｰﾑ2 |
| 25 | NBRGC0136FCZZ | AC | DD | | B | Toner box bearing (φ6) | ﾄﾅｰﾎﾞｯｸｽﾖｳ ｼﾞｸｳｹ |
| 26 | NGERH0740FCZZ | AB | DD | | C | Gear 20T | ｷﾞﾔｰ20T |
| 27 | NSFTZ2124FCZ1 | AL | EB | | C | DR drive shaft | DRｸﾄﾞｳｼﾞｸ |
| 28 | CGERH0754FC01 | AK | DX | | C | 28/17T gear | 28/17Tｷﾞﾔ |
| 29 | CGERH0406FC01 | AE | DS | | C | DV idler gear 24T | DV ｱｲﾄﾞﾗｷﾞﾔｰ 24T |
| 30 | CGERH0267FC01 | AF | DS | | C | DV joint gear 19T | DV ﾚﾝｹﾂｷﾞﾔｰ 19T |
| 31 | NGERH0739FCZZ | AB | DD | | C | Gear 27T | ｷﾞﾔｰ 27T |
| 32 | NGERH1030FCZZ | AE | DJ | | C | 18/28T gear H | 18/28Tｷﾞﾔ H |
| 33 | LX-WZ0314FCZZ | AA | DD | | C | Washer | ﾜｯｼｬ |
| 34 | MSPRC2276FCZZ | AB | DJ | | C | Spring | CP ﾖｳｽﾌﾟﾘﾝｸﾞ |
| 35 | PSPAZ0363FCZZ | AA | DD | | C | Spacer | Pｷｬｯﾌﾟｽﾍﾟｰｻｰ |
| 36 | NGERH0742FCZZ | AB | DD | | C | Gear 36T | ｷﾞﾔｰ 36T |
| 37 | XRESP40-06000 | AA | DD | | C | 4E-Type ring (4mm) | Eﾘﾝｸﾞ |
| 38 | NGERH1029FCZZ | AD | DJ | | C | Gear 20T | CP20Tｷﾞﾔ |
| 39 | NSFTZ2122FCZZ | AL | EB | | C | Main drive shaft 1 | Mｸﾄﾞｳｼﾞｸ1 |
| 40 | NGERH1033FCZZ | AF | DS | | C | 24/50T gear H | 24/50Tｷﾞﾔ H |
| 41 | NGERH0349FCZZ | AC | DD | | C | Gear 28T | ｷﾞﾔｰ 28T |
| 42 | LX-WZ0421FCZZ | AA | DD | | C | Washer | ﾜｯｼｬ |
| 43 | CGERH0268FC01 | AE | DS | | C | Idle gear 27T | ｱｲﾄﾞﾙｷﾞﾔｰ 27T |
| 44 | NSFTZ2123FCZZ | AK | DX | | C | Main drive shaft 2 | Mｸﾄﾞｳｼﾞｸ2 |
| 45 | CGERH1032FC01 | AT | EZ | | C | 32/71T gear H | 32/71Tｷﾞﾔ H |
| 46 | NSFTZ2125FCZZ | AK | DX | | C | Fusing drive shaft | ﾃｲﾁｬｸｸﾄﾞｳｼﾞｸ |
| 47 | NGERH0070FCZZ | AD | DJ | | C | DV gear 36T | DV ｷﾞﾔｰ 36T |
| 48 | XBPSD40P12000 | AA | DD | | C | Screw (M4 X 12) | ﾋﾞｽ |
| 49 | VHPGP1A22LC-1 | AK | EB | | B | Photo sensor (GP1A22LC)(MHPD) | ﾌｫﾄｾﾝｻｰ |
| 50 | CFRM-0836FC01 | AW | FG | | C | Drive frame 1 (USA,CANADA,Hong Kong,Taiwan) | ｸﾄﾞｳﾌﾚｰﾑ1(ｽｹA) |
| | CFRM-0836FC02 | AW | FG | | C | Drive frame 1 (Japan,Russia,Europe,U,Kingdom,Australia,New Zealand) | ｸﾄﾞｳﾌﾚｰﾑ1(ｽｹB) |
| 51 | XBPSD40P06000 | AA | DD | | C | Screw (M4 X 6) | ﾋﾞｽ |
| 52 | NPLYZ0258FCZZ | AC | DJ | | C | Pulley 30P-B | ﾌﾟｰﾘｰ30P-B |
| 53 | PCLR-0367FCZZ | AC | DD | | C | Pulley collar | ﾌﾟｰﾘｰｶﾗｰ |
| 54 | QSW-M0431FCZZ | AF | DS | | B | Microswitch | ﾏｲｸﾛｽｲｯﾁ |
| 55 | XHPSD23P10000 | AA | DD | | C | Screw (M2.3 X 10) | ﾋﾞｽ |
| 56 | DHAi-2413FCZZ | AD | DJ | | C | TFD harness | TFDﾊｰ ﾈｽ |
| 57 | XBBSD40P08000 | AA | DD | | C | Screw (4 X 8) | ﾋﾞｽ |
| 58 | PSHEZ4460FCZZ | AC | DJ | | C | Protection sheet A (For Europe,Australia,New Zealand, U,Kingdom,Taiwan) | ﾘｰｸﾎﾞｳｼｼｰﾄ A |
| 59 | PSHEZ4461FCZZ | AC | DJ | | C | Protection sheet B (For Europe,Australia,New Zealand,Taiwan) | ﾘｰｸﾎﾞｳｼｼｰﾄ B |
| 60 | PSHEZ4462FCZZ | AD | DJ | | C | Protection sheet C (For Europe,Australia, New Zealand,U,Kingdom,Taiwan) | ﾘｰｸﾎﾞｳｼｼｰﾄ C |
| | ﾕﾆｯﾄ (Unit) | | | | | | |
| 901 | CFRM-0836FC75 | BT | NE | | E | Drive frame unit (USA,CANADA,Hong Kong) | ｸﾄﾞｳﾌﾚｰﾑﾕﾆｯﾄ(ｽｹA) |
| | CFRM-0836FC76 | BT | NE | | E | Drive frame unit (Japan,Russia) | ｸﾄﾞｳﾌﾚｰﾑﾕﾆｯﾄ(ｽｹB) |
| | CFRM-0836FC74 | BT | NE | | E | Drive frame unit (For Europe,Australia,New Zealand,U,Kingdom) | ｸﾄﾞｳﾌﾚｰﾑﾕﾆｯﾄ(ｽｹB) |
| | CFRM-0836FC77 | BX | RR | N | E | Drive frame unit (Taiwan) | ｸﾄﾞｳﾌﾚｰﾑﾕﾆｯﾄ(ｽｹA) |

## 18 ﾒｲﾝ駆動ﾕﾆｯﾄ (Main drive unit)



## 19 下ﾌﾚｰﾑ 1(Lower frame 1)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION | |
|---|---|---|---|---|---|---|---|
| | | Ex. | Ja. | | | | |
| 1 | NBRGP0593FCZZ | AD | DJ | N | C | Suction bearing (B-F8-65) | ｻｸｼｮﾝｼﾞｸｳｹ |
| 2 | NBLTH0170FCZZ | AH | DX | | B | Suction belt | ｻｸｼｮﾝﾍﾞﾙﾄ |
| 3 | NRÖLP1054FCZ1 | AF | DS | | C | Suction roller A | ｻｸｼｮﾝﾛｰﾗｰA |
| 4 | NBLTH0246FCZZ | AK | DX | | B | PS front drive belt | PSﾏｴｸﾄｳﾍﾞﾙﾄ |
| 5 | XRESP70-08000 | AA | DD | | C | E type ring (7mm) | Eﾘﾝｸﾞ |
| 6 | PSHEP2348FCZZ | AB | DD | | C | Flange sheet DL | ﾌﾗﾝｼﾞﾏｲﾗｰDL |
| 7 | NPLYZ0297FCZZ | AD | DJ | | C | Transport roller pulley | ﾊﾝｿｳﾛｰﾗｰﾌﾟｰﾘｰ |
| 8 | LPiNS0155FCZZ | AA | DD | | C | Pin (φ3-10) | ﾍｲｺｳﾋﾟﾝ |
| 9 | NBRGP0510FCZZ | AC | DJ | | C | Roller bearing | ﾛｰﾗｰｼﾞｸｳｹ |
| 10 | NRÖLR1055FCZ1 | AY | FQ | | C | PS roller lower | PSﾛｰﾗｰｼﾀ |
| 11 | NBRGC0133FCZ1 | AC | DJ | | C | PF bearing (φ8) | PFｼﾞｸｳｹ |
| 12 | PCLC-0250FCZ1 | AX | FG | | B | PS roller clutch | PSﾛｰﾗｰｸﾗｯﾁ |
| 13 | CFRM-0841FC32 | BT | NE | | E | Paper feeding unit (Japan only) | ｷｭｳｼｭﾆｯﾄ |
| | CFRM-0841FC31 | BS | MJ | | E | Paper feeding unit (Except Japan) | ｷｭｳｼｭﾆｯﾄ |
| 14 | XHBSE40P10000 | AA | DD | | C | Screw (M4 X 10) | ﾋﾞｽ |
| 15 | XRESP50-06000 | AA | DD | | C | E type ring (5mm) | Eﾘﾝｸﾞ |
| 16 | NBRGC0188FCZZ | AB | DD | | B | PF bearing | PFｼﾞｸｳｹ |
| 17 | NRÖLR1056FCZ3 | AY | FQ | | C | Delivery roller | ﾊｲｼﾛｰﾗｰ |
| 18 | LPiNS0133FCZZ | AA | DD | | C | Pin (φ2-10) | ﾍｲｺｳﾋﾟﾝ |
| 19 | NGERH0866FCZZ | AC | DD | | C | Gear (22T) | 22Tｷﾞﾔ |
| 20 | XEBSD40P08000 | AA | DD | | C | Screw (M4 X 8) | ﾋﾞｽ |
| 21 | PTME-0244FCZZ | AG | DX | | C | Lower separator pawl | ｼﾀﾊｸﾘﾂﾒ |
| 22 | MSPRT2521FCZZ | AC | DJ | | C | Lower separator pawl spring | ｼﾀﾊｸﾘﾂﾒｽﾌﾟﾘﾝｸﾞ |
| 23 | PGiDH1718FCZZ | AM | EG | | C | Derivery guide PG | ﾊｲｼｶﾞｲﾄﾞPG |
| 24 | NBRGY0513FCZZ | AK | EB | | C | Pressure roller bearing | ｱｯﾁｬｸﾛｰﾗｰｼﾞｸｳｹ |
| 25 | NRÖLR1058FCZ3 | BH | GX | | C | Pressure roller | ｱｯﾁｬｸﾛｰﾗｰ |
| 26 | CFRM-0839FC01 | AZ | FQ | | C | Lower frame F | ｼﾀﾌﾚｰﾑF |
| 27 | CLEVF0766FC01 | AG | DS | N | C | Pressure lever F | ｱｯﾁｬｸﾚﾊﾞｰF |
| 28 | MSPRC2416FCZZ | AD | DJ | | C | Pressure spring | ｶｱｽｽﾌﾟﾘﾝｸﾞ |
| 29 | CLEVF0767FC01 | AG | DS | N | C | Pressure lever R | ｱｯﾁｬｸﾚﾊﾞｰR |
| 30 | XEPSD30P08000 | AA | DD | | C | Screw (M3 X 8) | ﾋﾞｽ |
| 31 | LSTPP0274FCZZ | AA | DD | | C | Reversing roller stopper | ｷﾞｬｸﾃﾝﾛｰﾗｽﾄｯﾊﾟｰ |
| 32 | NGERH1034FCZZ | AF | DS | | C | Suction roller gear 25T | ｻｸｼｮﾝﾛｰﾗｰｷﾞﾔ 25T |
| 33 | CFRM-0838FC01 | BC | GD | | C | Lower frame R | ｼﾀﾌﾚｰﾑR |
| 34 | MSPRC2281FCZZ | AC | DJ | | C | AC earth spring | ACｱｰｽﾖｳｽﾌﾟﾘﾝｸﾞ |
| 35 | MSPRC2280FCZZ | AC | DJ | | C | TC pressure spring | TCｱｯｾﾂｽﾌﾟﾘﾝｸﾞ |
| 36 | PSHEP4594FCZZ | AD | DJ | N | C | PS front sheet F | PSﾏｴｼｰﾄF |
| 37 | PSHEP4595FCZZ | AD | DJ | N | C | PS front sheet R | PSﾏｴｼｰﾄR |
| 38 | CRÖLR1052FC33 | AX | FG | | E | Reversing roller unit | ｷﾞｬｸﾃﾝﾛｰﾗｰﾕﾆｯﾄ |
| 39 | LPLTM4887FCZZ | AY | FQ | | C | W base reinforce plate | Wﾀﾞｲﾊﾞﾝﾎｷｮｳｲﾀ |
| 41 | XHBSD40P12000 | AA | DD | | C | Screw (M4 X 12) | ﾋﾞｽ |
| 42 | MARMP0190FCZ1 | AG | DS | | C | Separator roller release arm | ﾌﾞﾝﾘﾛｰﾗｰｶｲｼﾞｮｱｰﾑ |
| 43 | MSPRC2367FCZZ | AK | EB | | C | Separator roller pressure spring 2 | ﾌﾞﾝﾘﾛｰﾗｰｶｱｽｽﾌﾟﾘﾝｸﾞ 2 |
| 44 | LHLDZ1238FCZ1 | AE | DS | | C | Separator arm holder | ﾌﾞﾝﾘｱｰﾑﾎﾙﾀﾞｰ |
| 45 | LDAiU0515FCZZ | AG | DX | | C | Tray lock block base | ﾄﾚｲﾛｯｸﾌﾞﾛｯｸ |
| 46 | LPLTM4885FCZZ | AG | DX | | C | W base PF reinforce plate | Wﾀﾞｲﾊﾞﾝｷｭｳｼﾎｷｮｳｲﾀ |
| 47 | GLEGG0063FCZZ | AE | DJ | | C | Rubber foot | ｺﾞﾑｱｼ |
| 48 | PSHEP4116FCZZ | AF | DS | | C | PS lower sheet | PSｼﾀｼｰﾄ |
| 52 | GDAi-0166FCZ1 | BN | HZ | | D | Base plate | ﾀﾞｲﾊﾞﾝ |
| 53 | LSTPP0260FCZZ | AB | DD | | C | Blancer stopper | ﾊﾞﾗﾝｻｰｽﾄｯﾊﾟｰ |
| 54 | MSPRB2278FCZZ | AY | FQ | | B | Blancer spring | ﾊﾞﾗﾝｻｰｽﾌﾟﾘﾝｸﾞ |
| 55 | MSPRB2350FCZZ | AY | FQ | | B | Blancer spring | ﾊﾞﾗﾝｻｰｽﾌﾟﾘﾝｸﾞ |
| 56 | NSFTZ2133FCZZ | AH | DX | | C | Blancer shaft | ﾊﾞﾗﾝｻｰｼﾞｸ |
| 57 | XBPSD40P30K00 | AA | DD | | C | Screw (M4 X 30) | ﾋﾞｽ |
| 59 | XHBSE40P10000 | AA | DD | | C | Screw (4 X 10) | ﾋﾞｽ |
| 60 | PMLT-0995FCZZ | AC | DJ | | C | Suction cushion A | ｻｸｼｮﾝﾓﾙﾄA |
| 61 | PDUC-0093FCZZ | AL | EB | | C | Suction duct | ｻｸｼｮﾝﾀﾞｸﾄ |
| 62 | RMÖTE0700FCZZ | AX | FX | | B | Suction Fan | ｻｸｼｮﾝﾌｧﾝ |
| 63 | PFiLZ0267FCZZ | AU | EZ | | B | Suction filter | ｻｸｼｮﾝﾌｨﾙﾀｰ |
| 67 | LPLTM4980FCZZ | AK | EB | | C | Suction duct plate | ｻｸｼｮﾝﾀﾞｸﾄﾊﾞﾝ |
| 68 | XEBSD40P30000 | AA | DD | | C | Screw (M4 X 30) | ﾋﾞｽ |
| 69 | NBRGP0547FCZZ | AD | DJ | | C | Suction bearing | ｻｸｼｮﾝｼﾞｸｳｹ |
| 70 | PSHEP3827FCZZ | AE | DJ | | C | Suction lower sheet | ｻｸｼｮﾝｼﾀｼｰﾄ |
| 71 | XBBSD40P14000 | AA | DD | | C | Screw (4 X 14) | ﾋﾞｽ |
| 72 | MSPRC2370FCZZ | AK | EB | | C | Separator roller pressure spring 3 | ﾌﾞﾝﾘﾛｰﾗｰｶｱｽｽﾌﾟﾘﾝｸﾞ 3 |
| 73 | LX-BZ0193FCZZ | AB | DD | | C | Screw (3 X 4) | ﾑｼﾋﾞｽ |
| 74 | MSPRC2417FCZZ | AD | DJ | | C | TC pressure spring F | TCｱｯｾﾂｽﾌﾟﾘﾝｸﾞ F |
| 75 | XEPSD30P08X00 | AA | DD | | C | Screw (3 X 8X) | ﾋﾞｽ |
| 76 | PSPAZ0695FCZZ | AC | DJ | | C | Base plate frame spacer | ﾀﾞﾝﾊﾞﾝﾌﾚｰﾑｽﾍﾟｰｻｰ |
| 77 | XBPSD30P08K00 | AA | DD | | C | Screw (3 X 8K) | ﾋﾞｽ |
| 78 | XNESD30-24000 | AA | DD | | C | Nut | ﾅｯﾄ |
| 79 | LBNDJ0013FCZ1 | AA | DJ | | C | Wire band | ｹｯｿｸﾊﾞﾝﾄﾞ |
| 80 | DHAi-2511FCZZ | AF | DS | | C | Upper lower joint harness | ｳｴｼﾀﾚﾝｹﾂﾊｰﾈｽ |
| 81 | PBRSS0185FCZZ | AF | DS | | B | Fusing rear PG brush F (Japan only) | ﾃｲﾁｬｸｳｼﾛPGﾌﾞﾗｼ F |
| 82 | PBRSS0186FCZZ | AF | DS | | B | Fusing rear PG brush R (Japan only) | ﾃｲﾁｬｸｳｼﾛPGﾌﾞﾗｼ R |
| 83 | PMLT-1153FCZZ | AC | DJ | | C | Protect cushion | ﾎｺﾞﾓﾙﾄ |
| 84 | PSHEP4456FCZZ | AD | DJ | | C | Gasket fixing sheet (Except Japan) | ｶﾞｽｹｯﾄ ﾄﾘﾂｹｼｰﾄ |
| 85 | PGSK-0012FCZZ | AG | DX | | C | Gasket (Except Japan) | ｶﾞｽｹｯﾄ |
| 86 | XHBSD40P14000 | AA | DD | | C | Screw (4 X 14) | ﾋﾞｽ |
| 87 | LBSHZ2029SCZZ | AB | DD | | C | Bushing (LCBS-3NS) | ﾌﾞｯｼﾝｸﾞ |

19 下フレーム 1(Lower frame 1)



## 20 下ﾌﾚｰﾑ 2(Lower frame 2)

| NO. | PARTS CODE | PRICE RANK Ex. | PRICE RANK Ja. | NEW MARK | PART RANK | DESCRIPTION | |
|---|---|---|---|---|---|---|---|
| 1 | LPLTP4760FCZZ | AQ | EQ | | C | AC PWB fixing plate | ACｷﾊﾞﾝﾄﾘｿｹｲﾀ |
| 2 | CPWBF1215FC54 | BL | HR | | E | AC circuit PWB (Japan only) | ACｶｲﾛｷﾊﾞﾝ |
| 2 | CPWBF1215FC52 | BL | HL | | E | AC circuit PWB (100V series･･Except Japan) | ACｶｲﾛｷﾊﾞﾝ |
| 2 | CPWBF1304FC51 | BN | HZ | N | E | AC circuit PWB (200V series･･For Europe) | ACｶｲﾛｷﾊﾞﾝ200 |
| 2 | CPWBF1215FC53 | BN | HZ | | E | AC circuit PWB (200V series･･Except Europe) | ACｶｲﾛｷﾊﾞﾝ200 |
| 3 | XEPSD40P08000 | AA | DD | | C | Screw (M4 X 8) | ﾋﾞｽ |
| 4 | XBPSD40P25XS0 | AA | DD | | C | Screw (M4 X 25XS) | ﾋﾞｽ |
| 5 | XBPSD40P10KS0 | AA | DD | | C | Screw (M4 X 10KS) | ﾋﾞｽ |
| 6 | LFiX-0016FCZZ | AD | DJ | | C | AC cord holder | ACｺｰﾄﾞｵｻｴ |
| 7 | XBPSD40P08K00 | AA | DD | | C | Screw (M4 X 8K) | ﾋﾞｽ |
| 8 | XBPSD40P06000 | AA | DD | | C | Screw (M4 X 6) | ﾋﾞｽ |
| 9 | LPLTM4761FCZZ | AF | DS | | C | AC PWB plate | ACｷﾊﾞﾝﾌﾟﾚｰﾄ |
| 10 | XHPSD40P08000 | AA | DD | | C | Screw (M4 X 8) | ﾋﾞｽ |
| 11 | XBPSD30P16000 | AA | DD | | C | Screw (M3 X 16)(200V series) | ﾋﾞｽ |
| 12 | QTANN0015FCZZ | AG | DS | | C | 3P terminal base (200V series) | 3Pﾀﾝｼﾀﾞｲ |
| 13 | DHAi-2424FCZZ | AH | DX | | C | 3P terminal base harness (200V series) | 3Pﾀﾝｼﾀﾞｲﾊｰﾈｽ |
| ⚠ 14 | PHOG-0359FCZZ | AA | DD | | C | Plug holder (172076-1)(100V series) | ﾌﾟﾗｸﾞﾎﾙﾀﾞｰ |
| ⚠ 14 | QACCJ1415QCZZ | AS | EZ | | B | AC cord (Japan,Taiwan) | ACｺｰﾄﾞ |
| ⚠ 14 | QCNW-0069FCZZ | AC | DD | | C | Earth wire (Japan only) | ｱｰｽﾜｲﾔｰ |
| ⚠ 14 | QACCD7419QCZZ | AS | EQ | | B | AC cord(UL CSA plug) (USA,CANADA) | ACｺｰﾄﾞ |
| ⚠ 14 | QACCL8421QCZZ | AW | FX | | B | AC cord (Australia,New zealand) | ACｺｰﾄﾞ |
| ⚠ 14 | QACCV6420QCN2 | AU | FQ | | B | AC cord(φ4.8-2P) (For Europe except U,Kingdom,Russia) | ACｺｰﾄﾞ |
| ⚠ 14 | QCNW-0001QCZZ | AN | EQ | | B | AC wire (Hong Kong) | ACﾜｲﾔｰ |
| ⚠ 14 | QACCE7422QCZZ | BB | GD | | B | AC cord (BS Plug) (U,Kingdom) | ACｺｰﾄﾞ |
| ⚠ 14 | PHOG-1023CCZZ | AB | DD | | C | AC plug holder (Hong Kong) | ACﾎｺﾞ |
| ⚠ 14 | QPLGA4171CCZZ | AN | EG | | B | AC plug (Hong Kong) | ACﾌﾟﾗｸﾞ(ﾌﾄﾏﾙ3P) |
| ⚠ 14 | QTANP0088FCZZ | AA | DD | | C | Terminal (170328-1)(100V series) | ﾌｧｽﾄﾝﾀﾝｼ |
| ⚠ 14 | QTANP0176FCZZ | AB | DD | | C | Terminal (V2-M4)(100V series) | ﾀﾝｼ |
| 15 | RCiLF0045FCZZ | AN | EQ | | C | Earth inductor coil (200V series) | ｱｰｽｲﾝﾀﾞｸﾀｰｺｲﾙ |
| ⚠ 16 | RTRNP0536FCZZ | BD | GN | N | B | Power transformer (100V) | ﾃﾞﾝｹﾞﾝﾄﾗﾝｽ |
| ⚠ 16 | RTRNP0537FCZZ | BE | GN | N | B | Power transformer (110V) | ﾃﾞﾝｹﾞﾝﾄﾗﾝｽ |
| ⚠ 16 | RTRNP0538FCZZ | BD | GN | N | B | Power transformer (120V) | ﾃﾞﾝｹﾞﾝﾄﾗﾝｽ |
| ⚠ 16 | RTRNP0540FCZZ | BD | GN | N | B | Power transformer (220V) | ﾃﾞﾝｹﾞﾝﾄﾗﾝｽ |
| ⚠ 16 | RTRNP0541FCZZ | BE | GN | N | B | Power transformer (220V/230V) | ﾃﾞﾝｹﾞﾝﾄﾗﾝｽ |
| ⚠ 16 | RTRNP0542FCZZ | BF | GN | | B | Power transformer (230V/240V) | ﾃﾞﾝｹﾞﾝﾄﾗﾝｽ |
| ⚠ 17 | CPWBF1216FC51 | BL | HL | | E | DC power supply PWB (Japan, 100V series) | DCﾃﾞﾝｹﾞﾝｷﾊﾞﾝ 100 |
| ⚠ 17 | CPWBF1081FC53 | BH | HC | N | E | DC power supply PWB (200V series･･For Europe) | DCﾃﾞﾝｹﾞﾝｷﾊﾞﾝ200 |
| ⚠ 17 | CPWBF1216FC52 | BL | HL | | E | DC power supply PWB (200V series･･Except Europe) | DCﾃﾞﾝｹﾞﾝｷﾊﾞﾝ 200 |
| 18 | LSUPP0084FCZZ | AB | DJ | | C | PWB supporter (LCBS-5) | ｷﾊﾞﾝｻﾎﾟｰﾀｰ |
| 19 | CPWBF1315FC51 | AT | EZ | N | E | CSD PWB | CSDｷﾊﾞﾝ |
| 21 | DHAi-2905FCZZ | BA | FX | N | C | Lower unit main harness (Japan only) | ｼﾀUNﾒｲﾝﾊｰﾈｽ |
| 21 | DHAi-2905FC11 | AZ | FX | N | C | Lower unit main harness (100V series･･Except Japan) | ｼﾀUNﾒｲﾝﾊｰﾈｽ |
| 21 | DHAi-2905FC12 | BA | FX | N | C | Lower unit main harness (200V series･･Except Europe) | ｼﾀUNﾒｲﾝﾊｰﾈｽ |
| 21 | DHAi-2905FC13 | BA | FX | N | C | Lower unit main harness (200V series･･For Europe) | ｼﾀUNﾒｲﾝﾊｰﾈｽ |
| 22 | XHBSD40P08000 | AA | DD | | C | Screw (M4 X 8) | ﾋﾞｽ |
| 23 | CFRM-0838FC01 | BC | GD | | C | Lower frame R | ｼﾀﾌﾚｰﾑR |
| 24 | NGERH0515FCZZ | AC | DD | | C | 27T gear | 27Tｷﾞﾔｰ |
| 25 | XRESP70-08000 | AA | DD | | C | E type ring (7mm) | Eﾘﾝｸﾞ |
| 26 | MSPRT2283FCZZ | AC | DJ | | C | Joint arm spring | ﾚﾝｹﾂｱｰﾑﾖｳｽﾌﾟﾘﾝｸﾞ |
| 27 | CARMM0192FC01 | AE | DS | | C | Joint arm | ﾚﾝｹﾂｱｰﾑ |
| 28 | NGERH1015FCZZ | AD | DJ | | C | PS joint gear 25T | PSﾚﾝｹﾂｷﾞﾔｰ25T |
| 29 | NGERH0205FCZZ | AC | DD | | C | Fusing knob gear 20T | ﾃｲﾁｬｸﾉﾌﾞｷﾞﾔｰ 20T |
| 30 | NGERH0147FCZZ | AF | DS | | C | Gear 56T | ｷﾞﾔｰ56T |
| 31 | NGERH1035FCZZ | AE | DS | | C | 20/40T gear | 20/40Tｷﾞﾔ |
| 32 | XHBSD40P08000 | AA | DD | | C | Screw (M4 X 8) | ﾋﾞｽ |
| 33 | PSHEZ3908FCZZ | AF | DS | | C | AC PWB protect sheet (200V series) | ACｷﾊﾞﾝﾎｺﾞｼｰﾄ |
| 34 | XHBSD40P06000 | AA | DD | | C | Screw (4 X 6)(200V series) | ﾋﾞｽ |
| 35 | PSHEP3953FCZZ | AD | DJ | | C | Lower harness protect sheet | ｼﾀﾊｰﾈｽﾎｺﾞｼｰﾄ |
| 36 | LBSHC0335FCZZ | AC | DJ | | C | Edge protect | ｴｯｼﾞﾎｺﾞ |
| 37 | LHLDW1013FCZZ | AB | DD | | C | Cable holder | ｹｰﾌﾞﾙﾎﾙﾀﾞｰ |
| 38 | PSHEP4047FCZZ | AD | DJ | | C | DC PWB protect sheet | DCｷﾊﾞﾝﾎｺﾞｼｰﾄ |
| 39 | PSHEP4109FCZZ | AD | DJ | | C | AC fixing plate sheet | ACﾄﾘｿｹｲﾀﾏｲﾗｰ |
| 40 | PTPE-0217FCZZ | AC | DJ | | C | Harness fixing tape | ﾊｰﾈｽｵｻｴﾃｰﾌﾟ |
| 41 | LBNDJ0013FCZ1 | AA | DJ | | C | Wire band | ｹｯｿｸﾊﾞﾝﾄﾞ |

## 20 下フレーム 2(Lower frame 2)



## 21 手差しﾏﾙﾁ給紙ﾕﾆｯﾄ・・国内,USA,CANADA,台湾
## (Manual multi paper feeding unit・・Japan,USA,CANADA,Taiwan)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION | |
|---|---|---|---|---|---|---|---|
| | | Ex. | Ja. | | | | |
| 1 | DHAi-2415FCZZ | AH | DX | | C | Manual feed multi harness | ﾃｻｼﾏﾙﾁﾊｰﾈｽ |
| 2 | LX-BZ0771FCZZ | AC | DD | | C | Screw | ﾋﾞｽ |
| 3 | XEPSD40P08000 | AA | DD | | C | Screw (M4 X 8) | ﾋﾞｽ |
| 4 | PGiDH1581FCZZ | AN | EQ | | C | Manual feed multi upper paper guide | ﾏﾙﾁﾃｻｼｳｴﾍﾟｰﾊﾟｰｶﾞｲﾄﾞ |
| 5 | NBRGP0302FCZZ | AB | DD | | C | Bearing C | ﾃｻｼｼﾞｸｳｹﾍﾞｱﾘﾝｸﾞ C |
| 6 | XRESP40-06000 | AA | DD | | C | 4E-Type ring (4mm) | Eﾘﾝｸﾞ |
| 7 | MARMP0116FCZZ | AC | DJ | | C | Manual paper feed arm A | ﾃｻｼｱｰﾑ A |
| 8 | LSTPP0278FCZZ | AC | DD | | C | Manual feed stopper | ﾃｻｼｽﾄｯﾊﾟｰ |
| 9 | MARMP0117FCZ1 | AD | DS | | C | Manual paper feed arm B | ﾃｻｼｱｰﾑ B |
| 10 | PRNGP0081FCZZ | AA | DJ | | C | E4 ring | ｼﾞｭｼE4ﾘﾝｸﾞ |
| 11 | NSFTZ2183FCZ1 | AM | EG | | C | Manual paper feeding shaft | ﾃｻｼｷｭｳｼｼﾞｸ |
| 12 | MSPRT2320FCZZ | AC | DJ | | C | Manual feed arm spring | ﾃｻｼｱｰﾑｽﾌﾟﾘﾝｸﾞ |
| 13 | CRŌLP0921FC01 | AM | EG | | C | Manual feed take-up roller | ﾃｻｼﾖﾋﾟｺﾐﾛｰﾗ |
| 14 | MARMP0194FCZZ | AG | DX | | C | Manual paper feed arm | ﾃｻｼｱｰﾑ |
| 15 | NGERH0892FCZZ | AB | DD | | C | 16T gear | 16Tｷﾞﾔｰ |
| 16 | LPiNS0165FCZZ | AB | DD | | C | Pin (φ2-8) | ﾍｲｺｳﾋﾟﾝ |
| 17 | NGERH0495FCZZ | AC | DD | | C | Gear 20T | ｷﾞﾔｰ 20T |
| 18 | NRŌLR1051FCZZ | AT | EZ | | C | Manual paper feed roller | ﾃｻｼﾛｰﾗｰ |
| 19 | CRŌLR1048FC51 | AV | FG | | E | Reversing roller unit | ｷﾞｬｸﾃﾝﾛｰﾗｰﾕﾆｯﾄ |
| 20 | PGiDM1582FCZ1 | AV | FG | N | C | Manual feed lower paper guide | ﾏﾙﾁﾃｻｼｼﾀﾍﾟｰﾊﾟｰｶﾞｲﾄﾞ |
| 21 | MSPRC2366FCZZ | AC | DJ | | C | Separator roller spring 2 | ﾌﾞﾝﾘﾛｰﾗｰｽﾌﾟﾘﾝｸﾞ 2 |
| 22 | MSPRT2321FCZZ | AB | DJ | | C | Separator roller spring | ﾌﾞﾝﾘﾛｰﾗｰｽﾌﾟﾘﾝｸﾞ |
| 23 | PSHEP3903FCZZ | AC | DJ | | C | Manual feed sheet 1 | ﾃｻｼﾏｲﾗｰ 1 |
| 24 | PSHEZ3945FCZZ | AD | DJ | | C | Manual feed sheet | ﾃｻｼｰﾄ |
| 25 | PSHEP3904FCZZ | AC | DJ | | C | Manual feed sheet 2 | ﾃｻｼﾏｲﾗｰ 2 |
| 26 | XHBSD30P08000 | AA | DD | | C | Screw (M3 X 8) | ﾋﾞｽ |
| 27 | LFRM-0745FCZZ | AE | DJ | | C | Manual feed solenoid frame | ﾃｻｼｿﾚﾉｲﾄﾞﾌﾚｰﾑ |
| 28 | MSPRC1317FCZZ | AA | DD | | C | Spring A | ﾃｻｼｽﾌﾟﾘﾝｸﾞ A |
| 29 | MLEVP0739FCZZ | AD | DJ | | C | Manual paper feeding lever N2 | ﾃｻｼﾗｯﾁ N2 |
| 30 | MLEVP0738FCZZ | AC | DJ | | C | Manual paper feeding lever N | ﾃｻｼﾗｯﾁ N |
| 32 | RPLU-0279FCZZ | AN | EG | | B | Manual feeding solenoid | ﾃｻｼｿﾚﾉｲﾄﾞ |
| 33 | MSPRC1318FCZZ | AA | DD | | C | Spring B | ﾃｻｼｽﾌﾟﾘﾝｸﾞ B |
| 34 | LBŌSZ0979FCZZ | AF | DS | | C | Manual feed clutch boss A | ﾃｻｼｸﾗｯﾁﾎﾞｽ A |
| 35 | PPiPP0109FCZZ | AB | DD | | C | Pipe A | ﾃｻｼｸﾗｯﾁｽﾘｰﾌﾞAﾊﾟｲﾌﾟ |
| 36 | MSPRC1315FCZZ | AD | DJ | | C | Manual feed clutch spring A | ﾃｻｼｸﾗｯﾁｽﾌﾟﾘﾝｸﾞ A |
| 37 | LBŌSZ1124FCZZ | AF | DS | | C | Manual feed CL boss 36T | ﾃｻｼCLﾎﾞｽ 36T |
| 38 | MSPRC1544FCZZ | AE | DS | | C | Manual feed clutch spring | ﾃｻｼｸﾗｯﾁｽﾌﾟﾘﾝｸﾞ |
| 39 | PPiPP0124FCZZ | AB | DD | | C | Manual feed CL sleeve | ﾃｻｼCLｽﾘｰﾌﾞ |
| 40 | LBŌSZ1125FCZZ | AC | DD | | C | Manual feed clutch boss | ﾃｻｼｸﾗｯﾁﾎﾞｽ |
| 41 | XHBSD40P08000 | AA | DD | | C | Screw (M4 X 8) | ﾋﾞｽ |
| 42 | CPLTM4896FC01 | AN | EQ | | C | Manual feed drive plate | ﾃｻｼｸﾄﾞｳｲﾀ |
| 43 | LBSHC0327FCZZ | AC | DJ | | C | Multi bush | ﾏﾙﾁﾖｳﾌﾞｯｼｭ |
| 44 | NGERH1060FCZZ | AE | DJ | | C | 15T gear | 15Tｷﾞﾔ |
| 45 | NGERH1079FCZZ | AE | DJ | | C | 41T gear | 41Tｷﾞﾔ |
| 46 | XRESP50-06000 | AA | DD | | C | E type ring (5mm) | Eﾘﾝｸﾞ |
| 47 | LBNDJ0043FCZ1 | AA | DJ | | C | Snap band | ｽﾅｯﾌﾟﾊﾞﾝﾄﾞ |
| 48 | PSHEP3905FCZZ | AE | DS | | C | Manual feed sheet 3 | ﾃｻｼﾏｲﾗｰ3 |
| 49 | LPLTM5008FCZZ | AE | DS | | C | Manual feed sub plate | ﾃｻｼﾎｷｮｳｲﾀ |
| 50 | PSPAZ0679FCZZ | AC | DJ | | C | Manual feed spacer | ﾃｻｼｽﾍﾟｰｻｰ |
| 51 | XRESP70-08000 | AA | DD | | C | E type ring | E ﾘﾝｸﾞ |
| 52 | PSHEP4345FCZZ | AC | DJ | | C | Manual guide sheet | ﾏﾙﾁｶﾞｲﾄﾞﾏｲﾗｰ |

21 手差しﾏﾙﾁ給紙ﾕﾆｯﾄ・・国内 ,USA,CANADA, 台湾
(Manual multi paper feeding unit ・・ Japan,USA,CANADA,Taiwan)



## 22 手差しﾏﾙﾁ給紙ﾄﾚｲﾕﾆｯﾄ・・国内 ,USA,CANADA, 台湾
(Manual multi paper feeding tray unit ・・ Japan,USA,CANADA,Taiwan)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION | |
|---|---|---|---|---|---|---|---|
| | | Ex. | Ja. | | | | |
| 1 | PGiDM1584FCZZ | AF | DS | | C | Manual feeding guide R | ﾃｻｼｶﾞｲﾄﾞ R |
| 2 | PGiDM1583FCZZ | AF | DS | | C | Manual feeding guide F | ﾃｻｼｶﾞｲﾄﾞ F |
| 3 | MARMP0195FCZZ | AD | DJ | | C | Tray arm | ﾄﾚｲｱｰﾑ |
| 4 | TLABZ3757FCZZ | AK | DX | | C | Manual feed size label (Japan only) | ﾃｻｼｻｲｽﾞﾗﾍﾞﾙ J |
| | TLABZ4011FCZZ | AE | DS | | C | Manual feed size label (Taiwan) | ﾃｻｼｻｲｽﾞﾗﾍﾞﾙ AB |
| | TLABZ3759FCZZ | AK | DX | | C | Manual feed size label (USA,CANADA) | ﾃｻｼｻｲｽﾞﾗﾍﾞﾙ IN |
| 5 | XEBSE30P08000 | AA | DD | | C | Screw (M3 X 8) | ﾋﾞｽ |
| 6 | LSŌU-0141FCZ1 | AR | EQ | | D | Manual feeding tray upper | ﾃｻｼﾄﾚｲ ｳｴ |
| 7 | NGERR0878FCZZ | AD | DJ | | C | Manual feeding gear | ﾃｻｼﾗｯｸ |
| 8 | XWHSD30-05070 | AA | DD | | C | Washer (3HW) | ﾜｯｼｬ |
| 9 | XEBSD30P06000 | AA | DD | | C | Screw (3 X 6) | ﾋﾞｽ(Pﾀｲﾄ) |
| 10 | PSHEZ1760FCZZ | AB | DD | | C | Manual feed gear brake sheet | ﾃｻｼｷﾞﾔｰﾌﾞﾚｰｷｼｰﾄ |
| 11 | NGERH0193FCZZ | AB | DD | | C | UC manual feed gear | UC ﾃｻｼｷﾞﾔｰ |
| 12 | XWHSD30-08100 | AA | DD | | C | Washer (φ3) | ﾜｯｼｬ |
| 13 | LSŌU-0142FCZZ | AQ | EQ | | D | Manual feeding tray lower | ﾃｻｼﾄﾚｲ ｼﾀ |
| 14 | LPLTP4897FCZ1 | AK | DX | | C | Manual feeding slide plate | ﾃｻｼｽﾗｲﾄﾞﾊﾞﾝ |
| 15 | LSŌU-0144FCZZ | AL | EB | | D | Manual feeding tray inner | ﾃｻｼﾄﾚｲ ﾅｶ |
| 21 | LSTPP0315FCZZ | AD | DJ | | C | Tray arm stopper | ﾄﾚｲｱｰﾑｽﾄｯﾊﾟｰ |
| 22 | XHBSE40P08000 | AA | DD | | C | Screw (M4 X 8) | ﾋﾞｽ |
| 23 | LX-WZ0256FCZZ | AA | DD | | C | Washer | ﾎﾟﾘｽﾗｲﾀﾞｰ |
| 24 | PGiDM1582FCZ1 | AV | FG | N | C | Manual feed lower paper guide | ﾏﾙﾁﾃｻｼｼﾀﾍﾟｰﾊﾟｰｶﾞｲﾄﾞ |
| 25 | CPLTP5276FC01 | AG | DX | | C | Manual feeding | ﾃｻｼﾁｮｳｾｲﾊﾞﾝ |
| 26 | PSHEP4026FCZ1 | AC | DJ | | C | Name plate sheet | ﾒｲﾊﾞﾝｼｰﾄ |
| | | | | | | | |
| | | | | | | | |

## 22 手差しﾏﾙﾁ給紙ﾄﾚｲﾕﾆｯﾄ・・国内 ,USA,CANADA, 台湾
(Manual multi paper feeding tray unit ・・ Japan,USA,CANADA,Taiwan)



## 25 MCユニット(MC unit)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION | |
|---|---|---|---|---|---|---|---|
| | | Ex. | Ja. | | | | |
| 1 | LPLTZ5474FCZZ | AH | DX | | C | Grid | ｸﾞﾘｯﾄﾞ |
| 2 | XEPSD30P06000 | AA | DD | | C | Screw (M3 X 6) | ﾋﾞｽ |
| 3 | QSLP-0158FCZ1 | AE | DS | | C | MC grid electrode | MCｸﾞﾘｯﾄﾞﾃﾞﾝｷｮｸ |
| 4 | PCOVP1130FCZZ | AB | DD | | C | MC cover R | MCｶﾊﾞｰR |
| 5 | XBPSD30P10000 | AA | DD | | C | Screw (M3 X 10) | ﾋﾞｽ |
| 6 | LHLDZ1095FCZZ | AD | DJ | | C | MC holder R | MCﾎﾙﾀﾞｰR |
| 7 | QSLP-0157FCZZ | AE | DS | | C | MC electrode | MCﾃﾞﾝｷｮｸ |
| 8 | LPLTM4067FCZZ | AN | EG | | C | MC plate R | MCﾌﾟﾚｰﾄR |
| 9 | CPLTM4129FC01 | AS | EZ | | C | Plate | ﾉｺﾊﾞ |
| 10 | LHLDZ1094FCZZ | AD | DJ | | C | MC holder F | MCﾎﾙﾀﾞｰF |
| 11 | LPLTM4068FCZZ | AM | EG | | C | MC plate L | MCﾌﾟﾚｰﾄL |
| 12 | LHLDZ0932FCYZ | AD | DJ | | C | Grid holder | ｸﾞﾘｯﾄﾞﾎﾙﾀﾞｰ |
| 13 | LX-BZ4008SC0M | AA | DD | | C | Screw (M4 X 8) | ﾋﾞｽ |
| 14 | XBPSD30P20000 | AA | DD | | C | Screw (M3 X 20) | ﾋﾞｽ |
| 15 | XBPSD30P04000 | AA | DD | | C | Screw (M3 X 4) | ﾋﾞｽ |
| 16 | XBBSD40P12000 | AA | DD | | C | Screw (M4 X 12) | ﾋﾞｽ |
| | ﾕﾆｯﾄ (Unit) | | | | | | |
| 901 | CPLTM4067FC73 | BC | GD | | E | MC unit | MC ﾕﾆｯﾄ |

25 MCユニット(MC unit)



## 26 TCｹｰｽﾕﾆｯﾄ(TC case unit)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION | |
|---|---|---|---|---|---|---|---|
| | | Ex. | Ja. | | | | |
| 1 | PGiDM1547FCZ3 | AK | DX | | C | TC transport guide | TCﾊﾝｿｳｶﾞｲﾄﾞ |
| 2 | DWiR-0466CSZZ | BG | HC | | B | Charger wire | ﾁｬｰｼﾞﾜｲﾔｰ |
| 3 | MSPRT1395FCZZ | AA | DD | | C | Spring M | ｽﾌﾟﾘﾝｸﾞ M |
| 4 | XEPSD30P06000 | AA | DD | | C | Screw (M3 X 6) | ﾋﾞｽ |
| 5 | LPLTM3749FCZZ | AC | DD | | C | TC fixing plate | TCﾄﾘｯｹﾊﾞﾝ |
| 6 | PCOVP1275FCZ1 | AC | DJ | | C | TC holder cover R | TCﾎﾙﾀﾞｰｶﾊﾞｰR |
| 7 | LHLDZ1231FCZ2 | AH | DX | N | C | TC holder R | TCﾎﾙﾀﾞｰR |
| 8 | MSPRP1550FCZZ | AA | DD | | C | TC spring | TC ｽﾌﾟﾘﾝｸﾞ |
| 9 | PCOVP1274FCZ1 | AC | DJ | | C | TC holder cover F | TCﾎﾙﾀﾞｰｶﾊﾞｰF |
| 10 | LHLDZ1230FCZ1 | AG | DS | | C | TC holder F | TCﾎﾙﾀﾞｰF |
| 11 | PCASZ0271FCZZ | AH | DX | | C | TC case | TCｹｰｽ |
| 12 | PGiDH1546FCZZ | AH | DX | | C | TC paper guide | TCﾍﾟｰﾊﾟｶﾞｲﾄﾞ |
| 13 | PSHEP3832FCZZ | AE | DS | | C | TC sheet | TCﾏｲﾗｰ |
| 14 | PGiDM1597FCZZ | AP | EQ | | C | TC joint guide | TCﾚﾝｹﾂｶﾞｲﾄﾞ |
| 15 | PSPAZ0674FCZZ | AC | DJ | | C | TC PG lower spacer | TC PG ｼﾀｽﾍﾟｰｻｰ |
| | ﾕﾆｯﾄ (Unit) | | | | | | |
| 901 | CCASZ0271FC71 | BB | GD | | E | TC case unit | TCｹｰｽﾕﾆｯﾄ |

26 TCｹｰｽﾕﾆｯﾄ(TC case unit)



## 27 250トレイ (250 Tray)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION | |
|---|---|---|---|---|---|---|---|
| | | Ex. | Ja. | | | | |
| 1 | GCASP0167FCZ1 | BB | FX | N | D | 250 Tray | 250トレイ |
| 2 | LPLTP5028FCZZ | AE | DS | | C | Tray rear plate | トレイコウタンバン |
| 4 | LPLTP3757FCZ2 | AK | EB | N | C | Side plate R | ソクバンR |
| 7 | XEPSD40P08000 | AA | DD | | C | Screw (M4 X 8) | ビス |
| 8 | MSPRC1873FCZZ | AB | DD | | C | Return spring 250 | フッキスプリング 250 |
| 9 | PCUSF0319FCZZ | AE | DJ | | C | Tray cushion | トレイヨウクッション |
| 10 | LPLTP3756FCZ1 | AG | DX | | C | Side plate F | ソクバンF |
| 11 | MSPRC1804FCZZ | AA | DD | | C | Side plate ST spring | ソクバンST スプリング |
| 12 | LSTPP0255FCZ1 | AD | DJ | | C | Side plate stopper | ソクバンストッパー |
| 13 | LPLTM3909FCZZ | AD | DJ | | C | Side plate sub plate | ソクバンホキョウイタ |
| 14 | LX-WZ2028SCZZ | AA | DD | | C | Washer | ワッシャ |
| 15 | XEPSD30P08000 | AA | DD | | C | Screw (M3 X 8) | ビス |
| 16 | XEBSD40P12000 | AA | DD | | C | Screw (M4 X 12) | ビス |
| 17 | LDAiU0509FCZZ | AD | DJ | | C | Off center adjusting block | オフセンターチョウセイブロック |
| 18 | JKNBP0126FCZZ | AT | EZ | | C | Tray handle | トレイトッテ |
| 19 | LPLTP4781FCZZ | AH | DX | | C | Size display plate (Japan only) | サイズヒョウジバンJ |
| | LPLTP4783FCZZ | AH | DX | | C | Size display plate (Inch series) | サイズヒョウジバンIN |
| | LPLTP4782FCZZ | AH | DX | | C | Size display plate (AB series--Except Japan) | サイズヒョウジバンAB |
| 20 | NGERR1048FCZZ | AG | DS | | C | Tray rack gear R | トレイラックR |
| 21 | NGERR1047FCZZ | AF | DS | | C | Tray rack gear F | トレイラックF |
| 22 | NGERH0193FCZZ | AB | DD | | C | UC manual feed gear | UCテサシギヤー |
| 23 | MLEVP0671FCZZ | AE | DS | | C | PE actuator | PEアクチエーター |
| 28 | XWVSD40-05000 | AA | DD | | C | Washer | ワッシャ |
| 29 | XEBSD40P08000 | AA | DD | | C | Screw (4 X 8) | ビス |
| | ユニット (Unit) | | | | | | |
| 901 | CCASP0167FC45 | BG | GT | N | E | Tray unit(Not this includes NO19) | トレイユニット(NO19フクマナイ) |

## 27 250トレイ (250 Tray)



## 28 梱包材＆付属品(Packing material&Accessories)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION | |
|---|---|---|---|---|---|---|---|
| | | Ex. | Ja. | | | | |
| 1 | SPAKA5626FCZZ | AE | DS | | D | Top fixing cushion | ﾃﾝｺﾃｲｻﾞｲ |
| 2 | SPAKA5524FCZZ | AT | EZ | | D | Top packing cushion A | ﾃﾝﾊﾟｯｷﾝｸﾞｸｯｼｮﾝ A |
| 3 | CSOU-0090FC01 | AS | FG | | D | Delivery tray (Except Japan) | ﾊｲｼﾄﾚｲ |
| 4 | CSOU-0160FC01 | AX | FG | | D | Delivery tray (Japan only) | ﾊｲｼﾄﾚｲ |
| 5 | CPAKA5181FC05 | BB | GD | | D | Bottom case | ｿｺｹｰｽ |
| 6 | SPAKC5770FCZZ | BB | FX | N | D | Packing case (Japan only) | ﾊﾟｯｷﾝｸﾞｹｰｽ |
| | SPAKC5770FC11 | BB | FX | N | D | Packing case (USA only) | ﾊﾟｯｷﾝｸﾞｹｰｽ |
| | SPAKC5770FC17 | BB | FX | N | D | Packing case (CANADA only) | ﾊﾟｯｷﾝｸﾞｹｰｽ |
| | SPAKC5771FCZZ | BB | FX | N | D | Packing case (For Europe) | ﾊﾟｯｷﾝｸﾞｹｰｽ |
| | SPAKC5770FC12 | BB | FX | N | D | Packing case (Other coutries) | ﾊﾟｯｷﾝｸﾞｹｰｽ |
| 7 | TiNSJ1649FCZZ | AY | ZZ | N | D | Operation manual (Japanese) | ﾄﾘｱﾂｶｲｾﾂﾒｲｼｮ |
| | TiNSE1645FCZZ | AQ | EQ | N | D | Operation manual (USA) | ﾄﾘｱﾂｶｲｾﾂﾒｲｼｮ |
| | TiNSE1646FCZZ | AX | FG | N | D | Operation manual (U.Kingdom) | ﾄﾘｱﾂｶｲｾﾂﾒｲｼｮ |
| | TiNSE1647FCZZ | AT | EZ | N | D | Operation manual (English) | ﾄﾘｱﾂｶｲｾﾂﾒｲｼｮ |
| | TiNSF1648FCZZ | AZ | FX | N | D | Operation manual (French) | ﾄﾘｱﾂｶｲｾﾂﾒｲｼｮ |
| | TiNSE1658FCZZ | AU | EZ | N | D | Operation manual (Hong Kong) | ﾄﾘｱﾂｶｲｾﾂﾒｲｼｮ |
| | TiNSR1650FCZZ | | | N | D | Operation manual (Russian) | ﾄﾘｱﾂｶｲｾﾂﾒｲｼｮ |
| 8 | SPAKA5315FCZZ | AL | EB | | D | OC packing cushion L (Japan only) | OCｱﾄﾞL |
| | SPAKA5317FCZZ | AF | DS | | D | OC packing cushion L (Except Japan) | OCｱﾄﾞL |
| 9 | SPAKA5316FCZZ | AG | DX | | D | OC packing cushion R (Japan only) | OCｱﾄﾞR |
| | SPAKA5318FCZZ | AD | DJ | | D | OC packing cushion R (Except Japan) | OCｱﾄﾞR |
| 10 | SSAKA3001CCZZ | AA | DD | | D | Vinyl bag (140 × 360co) | ﾎﾟﾘﾌﾞｸﾛ |
| 11 | PSHEZ4024FCZZ | AE | DS | | D | Operation protect sheet | ｿｳｻﾌﾞﾎｺﾞｼｰﾄ |
| 12 | SPAKA5559FCZZ | AR | EQ | | D | Top packing cushion AR | ﾃﾝﾊﾟｯｷﾝｸﾞｸｯｼｮﾝ AR |
| 101 | LX-BZ0578FCZZ | AC | DD | | C | Lens fixing screw | ﾚﾝｽﾞｺﾃｲﾋﾞｽ |
| 102 | LX-BZ0649FCZZ | AB | DD | | C | 2nd,3rd mirror fixing screw | 2/3ﾐﾗｰｺﾃｲﾋﾞｽ |
| 103 | LX-BZ0772FCZZ | AD | DJ | | C | 4th, 5th mirror lock screw | 4/5ﾐﾗｰﾛｯｸﾋﾞｽ |
| 104 | LX-WZ0075FCZZ | AA | DD | | C | Washer | 2/3ﾐﾗｰﾜｯｼｬ |
| 105 | SPAKA4693FCZZ | AE | DS | | D | Packing cushion | ｶｲﾍｲﾚﾊﾞｰｺﾃｲｻﾞｲ |
| 106 | TCADZ1178FCZZ | AB | DJ | | D | Caution card | ﾈｼﾞｶｲｺﾝﾁｭｳｲｶｰﾄﾞ |
| 107 | CCASZ0067FC02 | AM | EG | | D | Maintenance card (Japan only) | ﾒﾝﾃﾅﾝｽｶｰﾄﾞ |
| | CCASZ0067FC01 | AD | DJ | | D | Maintenance card (Except Japan) | ﾒﾝﾃﾅﾝｽｶｰﾄﾞ |
| 108 | GCOVZ0195FCZZ | AV | FQ | | D | Dust cover (Japan only) | ﾀﾞｽﾄｶﾊﾞｰ |
| 109 | SSAKA2440QCZZ | AB | DD | | D | Vinyl bag for accessories (280 X 410mm) | ﾋﾞﾆｰﾙﾌﾞｸﾛ(ﾌｿﾞｸﾋﾝﾖｳ) |
| 110 | TCADS0764FCZZ | AE | DJ | | D | Warranty resist card (U,Kingdom only) | ﾜﾗﾝﾃｨｰﾚｼﾞｽﾄｶｰﾄﾞ |
| 112 | TCADZ1340FCZZ | AF | DS | N | D | Card (Japan only) | ｾｯﾁﾃｼﾞｭﾝｼｮ |
| | TCADZ2001QCZA | AE | DS | | D | Card (Australia,New zealand) | ｾｯﾁﾎｳｺｸｼｮ |
| | TCADS0649FCZZ | AM | EG | | D | Card (For Europe･･Except U,Kingdom) | ﾉｳﾆｭｳｾｯﾁﾎｳｺｸｼｮ E |
| | TCADZ1308FCZZ | AF | DS | N | D | Card (Russia only) | ｾｯﾁﾎｳｺｸｼｮ |
| 113 | TCADZ1341FCZZ | AF | DS | N | D | MSDS card (USA,CANADA,U,Kingdom) | MSDSｶｰﾄﾞ |
| 114 | TCADZ1300FCZZ | AB | DJ | | D | Caution card | ｶｲｺﾝﾁｭｳｲｶｰﾄﾞ |
| 115 | PCUSF0338FCZZ | AC | DJ | | C | 2nd,3rd mirror lock cushion | 2/3ﾐﾗｰﾛｯｸｸｯｼｮﾝ |
| 116 | PSHEZ4137FCZZ | AC | DJ | | D | Cabinet protect sheet | ｷｬﾋﾞﾎｺﾞｼｰﾄ |
| 117 | SPAKA5377FCZZ | AE | DJ | | D | 4th,5th mirror fixing cushion | 4/5ﾐﾗｰｺﾃｲｻﾞｲ |
| 119 | TCADZ1159FCZZ | AA | DJ | | D | Caution card | ｺﾃｲﾋﾞｽ ｶｲｺﾝﾁｭｳｲｶｰﾄﾞ |
| 120 | TLABZ3996FCZZ | AD | DJ | | C | Size label 13 (Australia,New Zealand,Hong Kong) | ｻｲｽﾞｵﾓﾃﾗﾍﾞﾙ13 |
| 121 | TLABZ4012FCZZ | AD | DJ | | C | B5 size display label (Taiwan only) | ｻｲｽﾞﾋｮｳｼﾞﾗﾍﾞﾙ B5 |
| 122 | TLABZ4014FCZZ | AD | DJ | | C | B5 size display label (Taiwan only) | ｻｲｽﾞﾋｮｳｼﾞﾗﾍﾞﾙ B5R |
| 123 | TCADZ1352FCZZ | AK | DX | N | D | Advise card (Japan only) | ｱﾄﾞﾊﾞｲｽｶｰﾄﾞ |
| | TCADZ1353FCZZ | AF | DS | N | D | Advise card (USA,Australia,New Zealand,U,Kingdom) | ｱﾄﾞﾊﾞｲｽｶｰﾄﾞ |
| | TCADZ1354FCZZ | AF | DS | N | D | Advise card (Other coutries) | ｱﾄﾞﾊﾞｲｽｶｰﾄﾞ ﾏﾙﾁ |
| 125 | LHLDW0544FCZZ | AC | DD | | C | Crip (FCA-10) | ｸﾘｯﾌﾟ |
| 126 | LPLTP5324FCZZ | AQ | EQ | | C | Rear plate (Australia,New Zealand,Hong Kong) | ｺｳﾀﾝﾊﾞﾝ 13IN |
| 127 | PSHEZ0287FCZZ | AG | DS | | D | Body vinyl sheet | ﾎﾝﾀｲﾎﾞﾘｼｰﾄ |

## 28 梱包材＆付属品(Packing material&Accessories)



## 29 ﾒｲﾝ基板 (Main PWB)

| NO. | PARTS CODE | PRICE RANK Ex. | PRICE RANK Ja. | NEW MARK | PART RANK | DESCRIPTION | |
|---|---|---|---|---|---|---|---|
| 1 | PRDAR0069FCZZ | AG | DX | | C | Heat sink (DPS25-30) | ﾎｳﾈﾂﾊﾞﾝ |
| 2 | PSHEP3223FCZZ | AB | DD | | C | IC socket protect sheet | IC ｿｹｯﾄﾎｺﾞｼｰﾄ |
| 3 | QCNCM0877FCZZ | AF | DS | | C | Connector (20Pin) [CN1] | ｺﾈｸﾀｰ |
| 4 | QCNCM0878FCZZ | AF | DS | | C | Connector (30Pin) [CN4,5] | ｺﾈｸﾀｰ |
| 5 | QCNCM0879FCZZ | AF | DS | | C | Connector (28Pin) [CN2] | ｺﾈｸﾀｰ |
| 6 | QCNCM7014SC0D | AB | DD | | C | Connector (4pin) [CN3] | ｺﾈｸﾀｰ |
| ⚠ 7 | QFS-D0334QCZZ | AE | DJ | | A | Fuse (1.6A 125V)(Japan, 100V series) [F1] | ﾋｭｰｽﾞ |
| ⚠ | QFS-D1328QCZZ | AE | DS | | A | Fuse (1.6A 125V)(200V series) [F1] | ﾋｭｰｽﾞ |
| 8 | QFSHA0025FCZZ | AA | DJ | | C | Fuse holder (S-N5057-01) | ﾋｭｰｽﾞﾎﾙﾀﾞｰ |
| 9 | QSOCZ2051SC32 | AC | DJ | | C | IC socket (32pin) | IC ｿｹｯﾄ |
| 10 | QSOCZ6408ACZZ | AB | DD | | C | IC socket (8pin) | IC ｿｹｯﾄ |
| 11 | RC-AZ0358FCZZ | AE | DS | | B | Capacitor [C58] | ｺﾝﾃﾞﾝｻｰ |
| 12 | RCRM-0001FCZZ | AD | DJ | | B | Ceramic oscilator (8.00MHz) [X1] | ｾﾗﾐｯｸﾊｯｼﾝｷ |
| 13 | RH-DZ0016FCZZ | AB | DD | | B | Diode (MA700) [D38,Da2] | ﾀﾞｲｵｰﾄﾞ |
| 14 | RMPTC4103QCJB | AD | DJ | | B | Block resistor (10KΩ × 4 1/8W ±5%) [BR4,BR5] | ﾌﾞﾛｯｸﾃｲｺｳ |
| 15 | RMPTC5102QCJB | AB | DD | | B | Block resistor (1.0KΩ × 5 1/8W ±5%) [BR9] | ﾌﾞﾛｯｸﾃｲｺｳ |
| 16 | RMPTC5103QCJB | AD | DJ | | B | Block resistor (10KΩ × 5 1/8W ±5%) [BR8] | ﾌﾞﾛｯｸﾃｲｺｳ |
| 17 | RMPTC6223QCJB | AB | DD | | B | Block resistor (22KΩ × 6 1/8W ±5%) [BR7,10] | ﾌﾞﾛｯｸﾃｲｺｳ |
| 18 | RMPTC6272QCJB | AC | DD | | B | Block resistor (2.7KΩ × 6 1/8W ±5%) [BR6] | ﾌﾞﾛｯｸﾃｲｺｳ |
| 19 | RMPTC8103QCJB | AC | DD | | B | Block resistor (10KΩ × 8 1/8W ±5%) [BR1,2,3] | ﾌﾞﾛｯｸﾃｲｺｳ |
| 20 | VCEAGU1AW476M | AA | DD | | C | Capacitor (10WV 47μF) [C1,56,Ca16] | ｺﾝﾃﾞﾝｻｰ |
| 21 | VCEAGA1AW477M | AB | DD | | C | Capacitor (10WV 470μF) [C5,11] | ｺﾝﾃﾞﾝｻｰ |
| 22 | VCEAGU1HW105M | AA | DD | | C | Capacitor (50WV 1.0μF) [C4] | ｺﾝﾃﾞﾝｻｰ |
| 23 | VCEAGA1HW224M | AA | DD | | C | Capacitor (50WV 0.22μF) [C6,7] | ｺﾝﾃﾞﾝｻｰ |
| 24 | VCEAGU1HW476M | AB | DD | | C | Capacitor (50WV 47μF) [C3] | ｺﾝﾃﾞﾝｻｰ |
| 25 | VCEAGA1VW106M | AA | DD | | C | Capacitor (35WV 10μF) [C2] | ｺﾝﾃﾞﾝｻｰ |
| 26 | VCEAGU1CW477M | AC | DD | | C | Capacitor (16WV 470μF) [C9] | ｺﾝﾃﾞﾝｻｰ |
| 27 | VCEAGU1VW477M | AD | DJ | | C | Capacitor (35WV 470μF) [C10] | ｺﾝﾃﾞﾝｻｰ |
| 28 | VCKYTQ1HB102K | AA | DD | | C | Capacitor (50WV 1000PF) [Ca15,C13~15,18~20,24,25,28,34,35,38~40,43,50~53,57] | ｺﾝﾃﾞﾝｻｰ |
| 29 | VCKYTQ1HB222K | AA | DD | | C | Capacitor (50WV 2200PF) [C17,29,49] | ｺﾝﾃﾞﾝｻｰ |
| 30 | VCKYTQ1HB223K | AB | DD | | C | Capacitor (50WV 0.022μF) [Ca1~a5,Ca10~14,C12,21~23,27,30,31,33,37,41,42,44~47,54,55,60] | ｺﾝﾃﾞﾝｻｰ |
| 31 | VCKYTQ1HB471K | AB | DD | | C | Capacitor (50WV 470PF) [C16,26] | ｺﾝﾃﾞﾝｻｰ |
| 32 | VCQYNU1HM103K | AA | DD | | C | Capacitor (50WV 0.010μF) [C8] | ｺﾝﾃﾞﾝｻｰ |
| 33 | VCQYNU1HM104K | AB | DD | | C | Capacitor (50WV 0.1μF) [C48] | ｺﾝﾃﾞﾝｻｰ |
| 34 | VCQYNU1HM224K | AC | DD | | C | Capacitor (50WV 0.22μF) [Ca17] | ｺﾝﾃﾞﾝｻｰ |
| 35 | VHDDAN202K/-1 | AB | DD | | B | Diode (DAN202K) [D3,8,9,12,17,19,27,36,39,55~57,61,73] | ﾀﾞｲｵｰﾄﾞ |
| 36 | VHDDAP202K/-1 | AB | DD | | B | Diode (DAP202K) [D11,13,18,20,24,29,34,43,45,47,63,64,68] | ﾀﾞｲｵｰﾄﾞ |
| 37 | VHDDSM1D1//-U | AB | DJ | | B | Diode (DSM1D1) [D1,2,16,48~54] | ﾀﾞｲｵｰﾄﾞ |
| 38 | VHDDSS133//-1 | AA | DD | | B | Diode (DSS133) [D23] | ﾀﾞｲｵｰﾄﾞ |
| 39 | VHDRU3M////-1 | AC | DD | | B | Diode (RU3M) [D4,5] | ﾀﾞｲｵｰﾄﾞ |
| 40 | VHEHZS5B3//-1 | AB | DJ | | B | Zener diode (HZS5B3) [ZD2] | ﾂｪﾅｰﾀﾞｲｵｰﾄﾞ |
| 41 | VHERD18EL3/-1 | AB | DD | | B | Zener diode (RD18EL3) [ZD3] | ﾂｪﾅｰﾀﾞｲｵｰﾄﾞ |
| 42 | VHERD22FB//-1 | AD | DJ | | B | Zener diode (RD22FB) [ZD1] | ﾂｪﾅｰﾀﾞｲｵｰﾄﾞ |
| 43 | VHiH83041K12F | BB | GD | | B | IC (H83041K12F) [IC6] | IC |
| 44 | VHiLM324N//-1 | AK | EG | | B | IC (LM324N) [IC14,17] | IC |
| 45 | VHiM51953BL-1 | AF | DS | | B | IC (M51953BL) [IC13] | IC |
| 46 | VHiNJM2901N-1 | AK | EB | | B | IC (NJM2901N) [IC20] | IC |
| 47 | VHiSLA7024MT/ | AS | EQ | | B | IC (SLA7024MT) [IC1] | IC |
| 48 | VHiSN74HC151N | AG | DX | | B | IC (SN74HC151N) [IC15,23] | IC |
| 49 | VHiSN74HC373S | AG | DS | | B | IC (SN74HC373S) [ICA2~4] | IC |
| 50 | VHiSN74LS138N | AG | EQ | | B | IC (SN74LS138N) [ICA1] | IC |
| 51 | VHiST25C04FB6 | AM | EG | | B | IC (ST25C04FB6) [IC4] | IC |
| 52 | VHiTA7291S/-1 | AF | DS | | B | IC (TA7291S) [IC5] | IC |
| 53 | VHiTD62504/-1 | AG | DX | | B | IC (TD62504) [IC3,10,11,18] | IC |
| 54 | VHiULN2004AN1 | AE | DS | | B | IC (ULN2004AN1) [IC2,9,19] | IC |
| 55 | VHi27C010D3FC | AX | FG | N | B | IC (27C010D3FC) [IC7] | IC |
| 56 | VHi74F02SJ/-1 | AF | DS | | B | IC (74F02SJ) [ICA5] | IC |
| 57 | VHi74HC04//-1 | AE | DJ | | B | IC (74HC04) [IC21] | IC |
| 58 | VHi74HC139/-1 | AG | DX | | B | IC (74HC139) [IC12] | IC |
| 59 | VRD-HT2EY103J | AA | DD | | C | Resistor (1/4W 10KΩ ±5%) [R96,97] | ﾃｨｺｳ |
| 60 | VRD-HT2EY271J | AA | DD | | C | Resistor (1/4W 270Ω ±5%) [R25,35] | ﾃｨｺｳ |
| 61 | VRD-HT2EY621J | AA | DD | | C | Resistor (1/4W 620KΩ ±5%) [R64] | ﾃｨｺｳ |
| 62 | VRNHT2HK1000F | AC | DD | | C | Resistor (1/2W 200Ω ±1%) [R45,52] | ﾃｨｺｳ |
| 63 | VRS-HT3DA1R0J | AB | DD | | C | Resistor (2W 1.0Ω ±5%) [R1,2] | ﾃｨｺｳ |
| 64 | VRS-HT3LAR22J | AC | DD | | C | Resistor (3.0W 0.22Ω ±5%) [R3] | ﾃｨｺｳ |
| 65 | VRS-ST3AB180J | AA | DD | | C | Resistor (1W 18Ω ±5%) [R4] | ﾃｨｺｳ |
| 66 | VRS-TS2AD101J | AA | DD | | C | Resistor (1/10W 100Ω ±5%) [R37,42] | ﾃｨｺｳ |
| 67 | VRS-TS2AD102J | AA | DD | | C | Resistor (1/10W 1.0KΩ ±5%) [R28,34,40,51,53,54,61,67,70,72,77,99] | ﾃｨｺｳ |
| 68 | VRS-TS2AD103J | AA | DD | | C | Resistor (1/10W 10KΩ ±5%) [Ra1,a5,a6,a9,a10,R18,19,22,24,26,30,31,38,65,66,78,84,85,88,103] | ﾃｨｺｳ |
| 69 | VRS-TS2AD104J | AA | DD | | C | Resistor (1/10W 100KΩ ±5%) [R48,50,60] | ﾃｨｺｳ |
| 70 | VRS-TS2AD105J | AA | DD | | C | Resistor (1/10W 1.0MΩ ±5%) [R87] | ﾃｨｺｳ |
| 71 | VRS-TS2AD152J | AA | DD | | C | Resistor (1/10W 1.5KΩ ±5%) [R94] | ﾃｨｺｳ |
| 72 | VRS-TS2AD153F | AA | DD | | C | Resistor (1/10W 15KΩ ±1%) [R44] | ﾃｨｺｳ |
| 73 | VRS-TS2AD162J | AA | DD | | C | Resistor (1/10W 1.6KΩ ±5%) [R86] | ﾃｨｺｳ |
| 74 | VRS-TS2AD202J | AA | DD | | C | Resistor (1/10W 2KΩ ±5%) [R6,69,73] | ﾃｨｺｳ |
| 75 | VRS-TS2AD222J | AA | DD | | C | Resistor (1/10W 2.2KΩ ±5%) [R90] | ﾃｨｺｳ |
| 76 | VRS-TS2AD242D | AA | DD | | C | Resistor (1/10W 2.4KΩ) [R57,58] | ﾃｨｺｳ |

## 29 ﾒｲﾝ基板 (Main PWB)

| NO. | PARTS CODE | PRICE RANK Ex. | PRICE RANK Ja. | NEW MARK | PART RANK | DESCRIPTION | |
|---|---|---|---|---|---|---|---|
| 77 | VRS-TS2AD242J | AA | DD | | C | Resistor (1/10W 2.4KΩ ±5%) [R15,23] | ﾃｲｺｳ |
| 78 | VRS-TS2AD243F | AB | DD | | C | Resistor (1/10W 24KΩ ±1%) [R74,76] | ﾃｲｺｳ |
| 79 | VRS-TS2AD243J | AA | DD | | C | Resistor (1/10W 24KΩ ±5%) [R21,79] | ﾃｲｺｳ |
| 80 | VRS-TS2AD271F | AA | DD | | C | Resistor (1/10W 270Ω ±1%) [R47] | ﾃｲｺｳ |
| 81 | VRS-TS2AD272J | AA | DD | | C | Resistor (1/10W 2.7KΩ ±5%) [R8,12,29,32] | ﾃｲｺｳ |
| 82 | VRS-TS2AD392J | AA | DD | | C | Resistor (1/10W 3.9KΩ ±5%) [R83] | ﾃｲｺｳ |
| 83 | VRS-TS2AD472F | AA | DD | | C | Resistor (1/10W 4.7KΩ ±1%) [R89] | ﾃｲｺｳ |
| 84 | VRS-TS2AD472J | AA | DD | | C | Resistor (1/10W 4.7KΩ ±5%) [R62] | ﾃｲｺｳ |
| 85 | VRS-TS2AD473F | AA | DD | | C | Resistor (1/10W 47KΩ ±1%) [R92] | ﾃｲｺｳ |
| 86 | VRS-TS2AD473J | AA | DD | | C | Resistor (1/10W 47KΩ ±5%) [R5,17,20,27,63,71,98] | ﾃｲｺｳ |
| 87 | VRS-TS2AD561J | AA | DD | | C | Resistor (1/10W 560Ω ±1%) [Ra2~4] | ﾃｲｺｳ |
| 88 | VRS-TS2AD562J | AA | DD | | C | Resistor (1/10W 5.6KΩ ±5%) [R7,13,36,39,41,55,68,Ra8] | ﾃｲｺｳ |
| 89 | VRS-TS2AD621J | AA | DD | | C | Resistor (1/10W 620Ω ±5%) [R14,16] | ﾃｲｺｳ |
| 90 | VRS-TS2AD622F | AA | DD | | C | Resistor (1/10W 6.2KΩ ±1%) [R49] | ﾃｲｺｳ |
| 91 | VRS-TS2AD622J | AA | DD | | C | Resistor (1/10W 6.2KΩ ±5%) [R10] | ﾃｲｺｳ |
| 92 | VRS-TS2AD681J | AA | DD | | C | Resistor (1/10W 680Ω ±5%) [R11,93] | ﾃｲｺｳ |
| 93 | VRS-TS2AD682J | AA | DD | | C | Resistor (1/10W 6.8KΩ ±5%) [R95] | ﾃｲｺｳ |
| 94 | VRS-TS2AD750F | AA | DD | | C | Resistor (1/10W 75Ω ±1%) [R46] | ﾃｲｺｳ |
| 95 | VRS-TS2AD750J | AA | DD | | C | Resistor (1/10W 75Ω ±5%) [R75] | ﾃｲｺｳ |
| 96 | VRS-TS2AD751F | AA | DD | | C | Resistor (1/10W 750Ω ±1%) [R43] | ﾃｲｺｳ |
| 97 | VRS-TS2AD752D | AA | DD | | C | Resistor (1/10W 7.5KΩ ) [R56,59] | ﾃｲｺｳ |
| 98 | VRS-TS2AD822J | AA | DD | | C | Resistor (1/10W 8.2KΩ ±5%) [R91] | ﾃｲｺｳ |
| 99 | VSDTA123YS/-1 | AB | DJ | | B | Transistor (DTA123YS) [Q1~3] | ﾄﾗﾝｼﾞｽﾀｰ |
| 100 | VS2SA673-C/-1 | AE | DS | | B | Transistor (2SA673) [Q5] | ﾄﾗﾝｼﾞｽﾀｰ |
| 101 | VS2SC945///-1 | AD | DJ | | B | Transistor (2SC945) [Q4,6~8] | ﾄﾗﾝｼﾞｽﾀｰ |
| 102 | VS2SK1286//-1 | AH | DX | | B | Transistor (2SK1286) [FET1] | ﾄﾗﾝｼﾞｽﾀｰ |
| 103 | XBPSD30P08K00 | AA | DD | | C | Screw (M3 × 8K) | ﾋﾞｽ |
| | ﾕﾆｯﾄ (Unit) | | | | | | |
| 901 | CPWBN1301FC51 | BV | RB | N | E | Main PWB (Japan,100V series) | ﾒｲﾝｷﾊﾞﾝ |
| | CPWBN1301FC52 | BV | RB | N | E | Main PWB (200V series) | ﾒｲﾝｷﾊﾞﾝ |

## 30 操作基板 (Operation PWB)

| NO. | PARTS CODE | PRICE RANK Ex. | PRICE RANK Ja. | NEW MARK | PART RANK | DESCRIPTION | |
|---|---|---|---|---|---|---|---|
| 1 | DHAi-2496FCZZ | AH | DX | | C | OP joint harness | OPｾｯｿﾞｸﾊｰﾈｽ |
| 2 | QCNCW0892FCZZ | AD | DJ | | C | Connector (6pin) [CN A] | ｺﾈｸﾀｰ |
| 3 | QCNCW0893FCZZ | AE | DS | | C | Connector (10pin) [CN B] | ｺﾈｸﾀｰ |
| 4 | QSW-P0465FCZZ | AC | DJ | | B | Tact switch (SKHVPB) [~9,C,CA,JOB SW,MSK,EX L,EX R,HE SW, INTERRUPT,RATIO H,RATIO L,DPC, SORTER,CS,100%,EXPOSURE,ZOOM L,ZOOM H] | ﾀｸﾄｽｲｯﾁ |
| 5 | QSW-P0469FCZZ | AD | DS | | B | Push switch (SKHWAC) [R] | ﾌﾟｯｼｭｽｲｯﾁ |
| 6 | VCEAJU1CW476M | AB | DD | | C | Capacitor (16WV 47μF) [C5,10] | ｺﾝﾃﾞﾝｻｰ |
| 7 | VCKYPU1HB331K | AA | DD | | C | Capacitor (50WV 330PF) [C1~4,6~9] | ｺﾝﾃﾞﾝｻｰ |
| 8 | VCKYPU1HF223Z | AA | DD | | C | Capacitor (50WV 0.022μF) [C11] | ｺﾝﾃﾞﾝｻｰ |
| 9 | VHDDSS133//-1 | AA | DD | | B | Diode (DSS133) [D1~17] | ﾀﾞｲｵｰﾄﾞ |
| 10 | VHiM66313FP-1 | AN | EQ | | B | IC (M66313FP) [IC1] | IC |
| 11 | VHPLB603MF/-1 | AQ | EQ | | B | LED (LB603MF) [LED1] | LED (ﾋﾓｼﾞ) |
| 12 | VHPSEL2213C// | AB | DD | | B | Photo transistor (SEL2213C) [M,D,T] | ﾌｫﾄﾄﾗﾝｼﾞｽﾀｰ |
| 13 | VHPSLR322MC3F | AC | DJ | | B | LED (SLR322MC3F) [SORT,GROUP,DUAL,HE,AUTO,MANUAL, PHOTO,EX1~5,PS1~7,P1,4,D200,141,122, 115,100,86,81,70,50,ZOOM,I,SSORT,MSL,PS,P] | LED (ﾐﾄﾞﾘ) |
| 14 | VHPSLR322VC3F | AC | DJ | | B | LED (SLR322VC3F) [P2,3,5,P,J3,5] | LED (ｱｶ) |
| 15 | VRD-HT2EY102J | AA | DD | | C | Resistor (1/4W 1KΩ ±5%) [R42~45] | ﾃｲｺｳ |
| 16 | VRD-HT2EY103J | AA | DD | | C | Resistor (1/4W 10KΩ ±5%) [R1,16~19,24~27] | ﾃｲｺｳ |
| 17 | VRD-HT2EY123J | AA | DD | | C | Resistor (1/4W 12KΩ ±5%) [R3] | ﾃｲｺｳ |
| 18 | VRD-HT2EY513J | AA | DD | | C | Resistor (1/4W 51KΩ ±5%) [R2] | ﾃｲｺｳ |
| 19 | VRD-HT2EY561J | AA | DD | | C | Resistor (1/4W 560Ω ±5%) [R20~23] | ﾃｲｺｳ |
| 20 | VRD-HT2EY562J | AA | DD | | C | Resistor (1/4W 5.6KΩ ±5%) [R4,28~30] | ﾃｲｺｳ |
| 21 | VRD-HT2EY750J | AA | DD | | C | Resistor (1/4W 75Ω ±5%) [R5~15,32~41,46,47] | ﾃｲｺｳ |
| 22 | VS2SB1240-/-1 | AD | DJ | | B | Transistor (2SB1240) [TR2~5] | ﾄﾗﾝｼﾞｽﾀｰ |
| 23 | VS2SD1991A/-1 | AD | DJ | N | B | Transistor (2SD1991A) [TR1] | ﾄﾗﾝｼﾞｽﾀｰ |
| | ﾕﾆｯﾄ (Unit) | | | | | | |
| 901 | CPWBF1303FC51 | BN | LE | N | E | Operation PWB | ｿｳｻｷﾊﾞﾝ |

## 33 AC回路基板 (AC circuit PWB)

| NO. | PARTS CODE | PRICE RANK Ex. | PRICE RANK Ja. | NEW MARK | PART RANK | DESCRIPTION | | |
|---|---|---|---|---|---|---|---|---|
| 1 | DHAi-2408FCZZ | AD | DJ | | C | AC PWB harness | [FG] | ACﾊﾝﾊｰﾈｽ |
| 2 | PRDAR0066FCZZ | AH | DX | | C | AC PWB heat sink | | ACﾊﾝﾎｳﾈｯﾊﾟﾝ |
| 3 | PSHEZ3777FCZZ | AD | DJ | | C | Insulator sheet | | ｾﾞﾂｴﾝｼｰﾄ |
| 4 | QCNCM0445FCZZ | AC | DJ | | C | Connector (Japan only) | [CN205] | ｺﾈｸﾀｰ |
| 5 | QCNCM0672FCZZ | AB | DD | | C | Connector (2pin)(100V series) | [CN203] | ｺﾈｸﾀｰ |
| | QCNCM0883FCZZ | AD | DJ | | C | Connector (4pin)(200V series) | [CN203] | ｺﾈｸﾀｰ |
| 6 | QCNCM0882FCZZ | AD | DJ | | C | Connector (2pin)(Red) | [CN202] | ｺﾈｸﾀｰ |
| 7 | QCNCM7014SC0D | AB | DD | | C | Connector (4pin) | [CN204] | ｺﾈｸﾀｰ |
| 8 | QCNCW0690FCZZ | AB | DD | | C | Connector (2pin) | [CN201] | ｺﾈｸﾀｰ |
| ⚠ | QFS-A2700QCZZ | AD | DJ | | A | Fuse (20A 125V)(Japan only) | [F201,202] | ﾋｭｰｽﾞ |
| ⚠ 9 | QFS-B0030FCZZ | AH | DS | | A | Fuse (15A 125V)(100V series･･Except Japan) | [F201] | ﾋｭｰｽﾞ |
| ⚠ | QFS-C1500QCZZ | AF | DS | | A | Fuse (10A 240V)(200V series) | [F201] | ﾋｭｰｽﾞ |
| ⚠ 10 | QFS-D0331QCZZ | AD | DJ | | A | Fuse (3.15A 125V)(100V series) | [F203] | ﾋｭｰｽﾞ |
| ⚠ | QFS-D1326QCZZ | AD | DS | | A | Fuse (T3.15A 250V)(200V series) | [F203] | ﾋｭｰｽﾞ |
| ⚠ 11 | QFS-D2002WCZZ | AB | DD | | A | Fuse (2A 125V)(Japan only) | [F204] | ﾋｭｰｽﾞ |
| 12 | QFSHA0025FCZZ | AA | DJ | | C | Fuse holder (S-N5057-01)(Japan only) | [for F203,204] | ﾋｭｰｽﾞﾎﾙﾀﾞｰ |
| | QFSHA0025FCZZ | AA | DJ | | C | Fuse holder (S-N5057-01)(Except Japan) | [for F203] | ﾋｭｰｽﾞﾎﾙﾀﾞｰ |
| 13 | QFSHD0001QCZZ | AA | DD | | C | Fuse holder (C2680R-H)(Japan only) | [for F201,202] | ﾋｭｰｽﾞﾎﾙﾀﾞｰ |
| | QFSHD0001QCZZ | AA | DD | | C | Fuse holder (C2680R-H)(Except Japan) | [for F201] | ﾋｭｰｽﾞﾎﾙﾀﾞｰ |
| 14 | QTANP0115FCZZ | AB | DD | | C | Tab terminal (T86032) | [L,N] | ﾀﾌﾀﾝｼ |
| 15 | RC-KZ472ANC3A | AD | DJ | | C | Capacitor (1KV 4700pF) | [C201,202] | ｺﾝﾃﾞﾝｻｰ |
| 16 | RCiLF0048FCZZ | AG | DS | | C | Coil (100μH 3A)(100V series) | [L202] | ｺｲﾙ |
| | RCiLF0043FCZ1 | AL | EG | | C | Coil (200V series) | [L202] | ｺｲﾙ |
| 17 | RH-DZ0019FCZZ | AG | DX | | B | Arrester (DSA-242MA)(100V series) | [A201] | ｱﾚｽﾀ |
| 18 | RMPTA0031FCZZ | AE | DJ | | B | CR mix part (ECQ-J0186X) | [CR201,202] | CRﾌｸｺﾞｳｷ |
| 19 | RR-WZ0328FCZZ | AD | DJ | | C | Resistor (5W 3Ω ±5%)(100V series) | [R201] | ﾃｲｺｳ |
| ⚠ 20 | RR-XZ0337FCZZ | AC | DJ | | B | Fuse resistor (1W 220Ω)(100V series) | [FR201] | ﾋｭｰｽﾞﾃｲｺｳ |
| ⚠ | RR-XZ0338FCZZ | AC | DJ | | B | Fuse resistor (1W 820Ω)(200V series) | [FR201] | ﾋｭｰｽﾞﾃｲｺｳ |
| 21 | RRLYD3202QCZZ | AN | EG | | B | Relay (For Europe) | [RY201] | ﾘﾚｰ |
| | RRLYJ3100QCZZ | AN | EQ | | B | Relay (Except Europe) | [RY201] | ﾘﾚｰ |
| 22 | VCEAGU1VW107M | AB | DD | | C | Capacitor (35WV 100μF) | [C209] | ｺﾝﾃﾞﾝｻｰ |
| 23 | VCFYEG2EA224M | AE | DS | | C | Capacitor (250WV 0.22μF)(100V series) | [C204] | ｺﾝﾃﾞﾝｻｰ |
| | VCFYEG2EA224M | AE | DS | | C | Capacitor (250WV 0.22μF)(200V series) | [C203,204] | ｺﾝﾃﾞﾝｻｰ |
| 24 | VCQYNU1HM104K | AB | DD | | C | Capacitor (50WV 0.10μF) | [C205,210] | ｺﾝﾃﾞﾝｻｰ |
| 25 | VCQYNU1HM223K | AA | DD | | C | Capacitor (50WV 0.022μF)(100V series) | [C208] | ｺﾝﾃﾞﾝｻｰ |
| | VCQYNU1HM473K | AB | DD | | C | Capacitor (0.047μF)(200V series) | [C208] | ｺﾝﾃﾞﾝｻｰ |
| 26 | VCQYNU1HM474K | AD | DJ | | C | Capacitor (50WV 0.47μF) | [C206,207] | ｺﾝﾃﾞﾝｻｰ |
| 27 | VHDD1N60///-1 | AC | DJ | | B | Diode (D1N60) | [D201] | ﾀﾞｲｵｰﾄﾞ |
| 28 | VHDS1WBA60S-1 | AD | DJ | | B | Diode (S1WBA60S) | [BD201] | ﾀﾞｲｵｰﾄﾞ |
| 29 | VHiHS4602//-1 | AT | EZ | | B | IC (HS4602) | [IC201] | IC |
| 30 | VHPPC112LY2-1 | AF | DS | | B | Photo transistor (PC112LY2) | [PC201] | ﾌｫﾄﾄﾗﾝｼﾞｽﾀｰ |
| 31 | VHRS11MD5V/-1 | AF | DS | | B | Photo thyristor (S11MD5V)(100V series) | [SSR201,202] | ﾌｫﾄｻｲﾘｽﾀｰ |
| | VHRS21MD3V/-1 | AE | DS | | B | Photo thyristor (S21MD3V)(200V series) | [SSR201,202] | ﾌｫﾄｻｲﾘｽﾀｰ |
| 32 | VHSTM1641P-LF | AQ | EQ | | B | Thyristor (TM1641P-LF)(100V series) | [TD201] | ｻｲﾘｽﾀｰ |
| | VHSTM1661P-LF | AQ | EQ | | B | Thyristor (TM1661P)(200V series) | [TD201] | ｻｲﾘｽﾀｰ |
| 33 | VHSTM1661S-LF | AK | EB | | B | CL triac (TM1661S) | [TD202] | CLﾄﾗｲｱｯｸ |
| 34 | VRD-HT2EY105J | AA | DD | | C | Resistor (1/4W 1.0MΩ ±5%)(100V series) | [R203] | ﾃｲｺｳ |
| | VRD-HT2EY474J | AA | DD | | C | Resistor (1/4W 470KΩ ±5%)(200V series･･Except Europe) | [R203] | ﾃｲｺｳ |
| | VRD-HT2HY474J | AA | DD | | C | Resistor (1/2W 470Ω ±5%)(200V series･･For Europe) | [R203] | ﾃｲｺｳ |
| 35 | VRNHT2EK2003F | AA | DD | | C | Resistor (1/4W 200KΩ ±1%)(100V series) | [R209,210] | ﾃｲｺｳ |
| | RR-NZ0442FCZZ | AB | DD | | C | Resistor (1/2W 412KΩ ±5%)(200V series) | [R209,210] | ﾃｲｺｳ |
| 36 | VRS-HT2HA101J | AA | DD | | C | Resistor (1/2W 100Ω ±5%) | [R204,206] | ﾃｲｺｳ |
| 37 | VRS-HT2HA121J | AA | DD | | C | Resistor (1/2W 120Ω ±5%)(100V series) | [R205,211] | ﾃｲｺｳ |
| | VRS-HT2HA201J | AA | DD | | C | Resistor (1/2W 200Ω ±5%)(200V series) | [R205,211] | ﾃｲｺｳ |
| 38 | VRS-RE3LA103J | AB | DD | | C | Resistor (3W 10KΩ ±5%)(100V series) | [R207] | ﾃｲｺｳ |
| | VRS-RE3LA103J | AB | DD | | C | Resistor (3W 10KΩ ±5)(200V series) | [R207,208] | ﾃｲｺｳ |
| 39 | XBPSD30P06000 | AA | DD | | C | Screw (3 X 6) | | ﾋﾞｽ |
| 40 | XBPSD30P08K00 | AA | DD | | C | Screw (3 X 8K) | | ﾋﾞｽ |
| 41 | XBPSD30P10K00 | AA | DD | | C | Screw (3 X 10K) | | ﾋﾞｽ |
| 42 | RCiLF0082FCZZ | AP | EQ | | C | Coil (8μF)(200V series) | [L201] | ｺｲﾙ |
| | ﾕﾆｯﾄ (Unit) | | | | | | | |
| 901 | CPWBF1215FC54 | BL | HR | | E | AC circuit PWB (Japan only) | | ACｶｲﾛｷﾊﾞﾝ |
| | CPWBF1215FC52 | BL | HL | | E | AC circuit PWB (100V series･･Except Japan) | | ACｶｲﾛｷﾊﾞﾝ |
| | CPWBF1304FC51 | BN | HZ | N | E | AC circuit PWB (200V series･･For Europe) | | ACｶｲﾛｷﾊﾞﾝ |
| | CPWBF1215FC53 | BN | HZ | | E | AC circuit PWB (200V series･･Except Europe) | | ACｶｲﾛｷﾊﾞﾝ |

## 34 DC電源基板(DC Power supply PWB)

| NO. | PARTS CODE | PRICE RANK Ex. | PRICE RANK Ja. | NEW MARK | PART RANK | DESCRIPTION | | |
|---|---|---|---|---|---|---|---|---|
| 1 | DHAi-2512FCZZ | AL | EB | | C | DC I/F harness (For Europe) | [CN301] | DCﾁｭｳｹｲﾊｰﾈｽ |
| | DHAi-2746FCZZ | AH | DX | | C | DC I/F harness (Except Europe) | [CN301] | DCﾁｭｳｹｲﾊｰﾈｽ |
| 2 | LPLTM4981FCZZ | AG | DS | | C | DC protect plate | | DCﾎｺﾞﾊﾞﾝ |
| 3 | PRDAR0078FCZZ | AK | EB | | C | DC PWB heat sink A | | DCｷﾊﾞﾝﾎｳﾈﾂﾊﾞﾝ A |
| 4 | PRDAR0079FCZZ | AL | EB | | C | DC PWB heat sink B | | DCｷﾊﾞﾝﾎｳﾈﾂﾊﾞﾝ B |
| 5 | PRDAR0080FCZZ | AK | DX | | C | Heat sink (DPS25-30)(Except Europe) | | ﾎｳﾈﾂﾊﾞﾝ |
| 6 | QCNCW0378FCZZ | AD | DJ | | C | Connector (18Pin)(For Eurpe) | [CN302] | ｺﾈｸﾀｰ |
| | QCNCW0903FCZZ | AF | DS | | C | Connector (22Pin)(Except Eurpe) | [CN302] | ｺﾈｸﾀｰ |
| ⚠ 7 | QFS-D0331QCZZ | AD | DJ | | A | Fuse (3.15A 125V)(100V series) | [F303] | ﾋｭｰｽﾞ |
| ⚠ | QFS-D1326QCZZ | AD | DS | | A | Fuse (T3.15 250V)(200V series) | [F303] | ﾋｭｰｽﾞ |
| ⚠ 8 | QFS-D0334QCZZ | AE | DJ | | A | Fuse (1.6A 125V)(100V series) | [F302] | ﾋｭｰｽﾞ |
| ⚠ | QFS-D1328QCZZ | AE | DS | | A | Fuse (T1.6A 250V)(200V series) | [F302] | ﾋｭｰｽﾞ |
| ⚠ 9 | QFS-D0431QCZZ | AE | DJ | | A | Fuse (6.3A 125V)(100V sries) | [F301] | ﾋｭｰｽﾞ |
| ⚠ | QFS-D1423QCZZ | AE | DS | | A | Fuse (T6.3A 250V)(200V series) | [F301] | ﾋｭｰｽﾞ |
| 10 | QFSHA0025FCZZ | AA | DJ | | C | Fuse holder (For Europe) | [for F301,302,303] | ﾋｭｰｽﾞﾎﾙﾀﾞｰ |
| | QFSHB0024FCZZ | AB | DJ | | C | Fuse holder (Except Europe) | [for F301,302,303] | ﾋｭｰｽﾞﾎﾙﾀﾞｰ |
| 11 | VCEAAL1HC822M | AK | EB | | C | Capacitor (50WV 8200pF) | [C301] | ｺﾝﾃﾞﾝｻｰ |
| 12 | VCEAEW1EC152M | AF | DS | | C | Capacitor (25WV 1500pF)(For Europe) | [C309] | ｺﾝﾃﾞﾝｻｰ |
| 13 | VCEAEW1EC222M | AF | DS | | C | Capacitor (25WV 2200pF) | [C310] | ｺﾝﾃﾞﾝｻｰ |
| 14 | VCEAGA1AW107M | AB | DD | | C | Capacitor (10WV 100μF)(For Europe) | [C311] | ｺﾝﾃﾞﾝｻｰ |
| | VCEAGA1AW107M | AB | DD | | C | Capacitor (10WV 100μF)(Except Europe) | [C311,315] | ｺﾝﾃﾞﾝｻｰ |
| 15 | VCEAGU1CW476M | AB | DD | | C | Capacitor (16WV 47μF) | [C306] | ｺﾝﾃﾞﾝｻｰ |
| 16 | VCEAGU1EW476M | AB | DD | | C | Capacitor (25WV 47μF) | [C313] | ｺﾝﾃﾞﾝｻｰ |
| 17 | VCEAGU1VW476M | AB | DD | | C | Capacitor (35WV 47μF) | [C304] | ｺﾝﾃﾞﾝｻｰ |
| 18 | VCKYPU1HF223Z | AA | DD | | C | Capacitor (50WV 0.022μF)(For Europe) | [C302,303,305,307,308,312] | ｺﾝﾃﾞﾝｻｰ |
| | VCKYPU1HF223Z | AA | DD | | C | Capacitor (50WV 0.022μF)(Except Europe) | [C302,303,305,307,308,312,314,316] | ｺﾝﾃﾞﾝｻｰ |
| 19 | VHDDSS131//-1 | AA | DD | | B | Diode (DSS131)(For Europe) | [D301,302,303,304] | ﾀﾞｲｵｰﾄﾞ |
| | VHDDSS131//-1 | AA | DD | | B | Diode (DSS131)(Except Europe) | [D302,303] | ﾀﾞｲｵｰﾄﾞ |
| 20 | VHDD10SC6MR-1 | AL | EB | | B | Diode (D10SC6MR) | [BD301] | ﾀﾞｲｵｰﾄﾞ |
| 21 | VHDD3SBA60/-1 | AG | DX | | B | Diode (D3SBA60)(For Europe) | [BD303] | ﾀﾞｲｵｰﾄﾞ |
| | VHDD4SBS6//-1 | AN | EG | | B | Diode (D4SBS6)(Except Europe) | [BD303] | ﾀﾞｲｵｰﾄﾞ |
| 22 | VHDRU3M////-1 | AC | DD | | B | Diode (RU3M)(Except Europe) | [D301,304] | ﾀﾞｲｵｰﾄﾞ |
| 23 | VHDSF10SC6/-1 | AK | DX | | B | Diode (SF10SC6) | [BD302] | ﾀﾞｲｵｰﾄﾞ |
| 24 | VHEMTZJ10A/-1 | AC | DJ | | B | Zener diode (MTZJ10A) | [ZD301] | ﾂｪﾅｰﾀﾞｲｵｰﾄﾞ |
| 25 | VHERD13EB1/-1 | AB | DD | | B | Zener diode (RD13EB1) | [ZD302,303] | ﾂｪﾅｰﾀﾞｲｵｰﾄﾞ |
| 26 | VHiPQ05RF2/-1 | AK | EB | | B | IC (PQ05RF2)(For Europe) | [IC301] | IC |
| | VHiPQ05RF2/-1 | AK | EB | | B | IC (PQ05RF2)(Except Europe) | [IC301,302] | IC |
| 27 | VRD-HT2EY101J | AA | DD | | C | Resistor (1/4W 100Ω ±5%) | [R302] | ﾃｲｺｳ |
| 28 | VRS-HT2HA271J | AB | DD | | C | Resistor (1/2W 270Ω ±5%) | [R301] | ﾃｲｺｳ |
| 29 | VS2SD1207-T-1 | AD | DJ | | B | Transistor (2SD1207-T) | [Q302] | ﾄﾗﾝｼﾞｽﾀｰ |
| 30 | VS2SD2045-/-1 | AH | EB | | B | Transistor (2SD2045) | [Q301] | ﾄﾗﾝｼﾞｽﾀｰ |
| 31 | XBPSD30P08KS0 | AA | DD | | C | Screw (3 × 8KS) | | ﾋﾞｽ |
| 32 | XHBSD30P08000 | AA | DD | | C | Screw (3 × 8) | | ﾋﾞｽ |
| 33 | PSHEP4404FCZZ | AE | DS | | C | DC protective sheet | | DCﾎｺﾞﾏｲﾗｰ |
| 34 | QCNCM1069AC0D | AC | DD | | C | Connector (4Pin)(For Europe) | [CN301] | ｺﾈｸﾀｰ |
| 35 | VHEMTZJ10D/-1 | AB | DJ | | B | Zener diode (MTZJ10D)(For Europe) | [ZD304] | ﾂｪﾅｰﾀﾞｲｵｰﾄﾞ |
| 36 | VRD-HT2EY163J | AA | DD | | C | Resistor (1/4W 16KΩ ±5%)(For Europe) | [R304] | ﾃｲｺｳ |
| 37 | VRD-HT2EY472J | AA | DD | | C | Resistor (1/4W 4.7KΩ ±5%)(For Europe) | [R305] | ﾃｲｺｳ |
| 38 | VS2SJ380///-1 | AN | EG | | B | Transistor (2SJ380)(For Europe) | [Q303] | ﾄﾗﾝｼﾞｽﾀｰ |
| | ﾕﾆｯﾄ (Unit) | | | | | | | |
| ⚠ 901 | CPWBF1216FC51 | BL | HL | | E | DC Power supply PWB (Japan,100V series) | | DCﾃﾞﾝｹﾞﾝｷﾊﾞﾝ |
| ⚠ | CPWBF1081FC53 | BH | HC | N | E | DC Power supply PWB (200V series･･For Europe) | | DCﾃﾞﾝｹﾞﾝｷﾊﾞﾝ |
| ⚠ | CPWBF1216FC52 | BL | HL | | E | DC Power supply PWB (200V series･･Except Europe) | | DCﾃﾞﾝｹﾞﾝｷﾊﾞﾝ |

## 35 ｻﾌﾞDC基板(Sub DC PWB)

| NO. | PARTS CODE | PRICE RANK Ex. | PRICE RANK Ja. | NEW MARK | PART RANK | DESCRIPTION | | |
|---|---|---|---|---|---|---|---|---|
| 1 | QCNCM0672FCZZ | AB | DD | | C | Connector (2Pin) | [CN-C] | ｺﾈｸﾀｰ |
| 2 | QCNCM1005MCZZ | AB | DD | | C | Connector (2Pin) | [CN-D] | ｺﾈｸﾀｰ |
| 3 | QCNCM7014SC0C | AA | DD | | C | Connector (3Pin) | [CN-B] | ｺﾈｸﾀｰ |
| ⚠ 4 | QFS-D0334QCZZ | AE | DJ | | A | Fuse (1.6A 125V)(100V series) | [Fa1] | ﾋｭｰｽﾞ |
| ⚠ | QFS-D1328QCZZ | AE | DS | | A | Fuse (1.6A 250V)(200V series) | [Fa1] | ﾋｭｰｽﾞ |
| 5 | QFSHB0001GCZZ | AB | DJ | | C | Fuse holder (S-N5057-01) | | ﾋｭｰｽﾞﾎﾙﾀﾞｰ |
| 6 | QPiN-0009FCZZ | AC | DJ | | C | Earth pin | | ｱｰｽﾋﾟﾝ |
| 7 | RRLYD3222QCZZ | AL | EB | | B | Relay (AJQ13-42 G94) | [PRa1] | ﾘﾚｰ |
| 8 | RTRNZ0529FCZZ | AT | EZ | | B | Power transformer (100V series) | [Ta1] | ﾊﾟﾜｰﾄﾗﾝｽ |
| | RTRNZ0530FCZZ | AT | EZ | | B | Power transformer (200V series) | [Ta1] | ﾊﾟﾜｰﾄﾗﾝｽ |
| 9 | VHDDSS133//-1 | AA | DD | | B | Diode (DSS133) | [Da1] | ﾀﾞｲｵｰﾄﾞ |
| 10 | VHDS1WBA60S-1 | AD | DJ | | B | Diode (S1WBA60S) | [BDa1] | ﾀﾞｲｵｰﾄﾞ |
| | ﾕﾆｯﾄ (Unit) | | | | | | | |
| 901 | CPWBF1302FC51 | BB | GD | N | E | Sub DC PWB (100V series) | | ｻﾌﾞDCｷﾊﾞﾝ |
| | CPWBF1302FC52 | BB | FX | N | E | Sub DC PWB (200V series) | | ｻﾌﾞDCｷﾊﾞﾝ |

## ■ 索引 (Index)

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. Ex. | PRICE R. Ja. | NEW | P/R |
|---|---|---|---|---|---|---|
| 【C】 | | | | | | |
| CARMM0192FC01 | 572 240 0213 | 11- 14 | AE | DS | | C |
| 〃 | 572 240 0213 | 20- 27 | AE | DS | | C |
| CBŌSZ1610FC01 | 572 202 0384 | 10- 12 | AN | EQ | | C |
| CBŌX-0085FC02 | 572 307 0285 | 15- 29 | AY | FQ | | C |
| CBŌX-0085FC69 | 572 307 0391 | 15- 901 | BU | NN | N | E |
| CBŌX-0086FC66 | 572 307 0392 | 13- 901 | BK | HC | N | E |
| CBŌX-0086FC67 | 572 307 0393 | 13- 901 | BK | HC | N | E |
| CBRGP0525FC02 | 572 272 0534 | 16- 22 | AN | EG | | B |
| CBRGP0528FC02 | 572 272 0535 | 16- 25 | AN | EG | | B |
| CBTN-0196FC01 | 572 170 0297 | 2- 8 | AR | EQ | | C |
| CBTN-0197FC32 | 572 170 0362 | 2- 5 | AL | EB | | E |
| CBTN-0198FC01 | 572 170 0299 | 2- 7 | AL | EB | | C |
| CBTN-0199FC01 | 572 170 0300 | 2- 4 | AL | EB | | C |
| CBTN-0200FC01 | 572 170 0301 | 2- 12 | AL | EB | | C |
| CBTN-0201FC01 | 572 170 0302 | 2- 10 | AK | EB | | C |
| CBTN-0236FC01 | 572 170 0385 | 2- 19 | AK | DX | | C |
| CBTN-0237FC02 | 572 170 0387 | 2- 11 | AN | EG | | C |
| CCAB-0876FC05 | 572 107 1666 | 1- 1 | BA | FX | N | D |
| CCASP0167FC45 | 572 108 1228 | 27- 901 | BG | GT | N | E |
| CCASZ0067FC01 | 572 108 0589 | 28- 107 | AD | DJ | | D |
| CCASZ0067FC02 | 572 108 0590 | 28- 107 | AM | EG | | D |
| CCASZ0271FC71 | 572 108 1196 | 26- 901 | BB | GD | | E |
| CCLR-0403FC01 | 572 318 0377 | 15- 5 | AH | DX | | C |
| CCŌVP1281FC01 | 572 110 0883 | 14- 82 | AQ | EQ | | D |
| CDAiU0506FC01 | 572 210 0937 | 6- 41 | BH | GX | | C |
| 〃 | 572 210 0937 | 7- 6 | BH | GX | | C |
| CDAiU0524FC01 | 572 210 0920 | 12- 12 | AV | FG | | C |
| CFRM-0687FC02 | 572 213 1494 | 11- 30 | AL | EB | | C |
| CFRM-0836FC01 | 572 213 1341 | 18- 50 | AW | FG | | C |
| CFRM-0836FC02 | 572 213 1342 | 18- 50 | AW | FG | | C |
| CFRM-0836FC74 | 572 213 1668 | 11- 1 | BT | NE | | E |
| 〃 | 572 213 1668 | 18- 901 | BT | NE | | E |
| CFRM-0836FC75 | 572 213 1669 | 11- 1 | BT | NE | | E |
| 〃 | 572 213 1669 | 18- 901 | BT | NE | | E |
| CFRM-0836FC76 | 572 213 1670 | 11- 1 | BT | NE | | E |
| 〃 | 572 213 1670 | 18- 901 | BT | NE | | E |
| CFRM-0836FC77 | 572 213 1777 | 11- 1 | BX | RR | N | E |
| 〃 | 572 213 1777 | 18- 901 | BX | RR | N | E |
| CFRM-0838FC01 | 572 213 1343 | 19- 33 | BC | GD | | C |
| 〃 | 572 213 1343 | 20- 23 | BC | GD | | C |
| CFRM-0839FC01 | 572 213 1345 | 19- 26 | AZ | FQ | | C |
| CFRM-0841FC01 | 572 213 1347 | 17- 16 | AL | EB | | C |
| CFRM-0841FC31 | 572 213 1348 | 17- 901 | BS | MJ | | E |
| 〃 | 572 213 1348 | 19- 13 | BS | MJ | | E |
| CFRM-0841FC32 | 572 213 1349 | 17- 901 | BT | NE | | E |
| 〃 | 572 213 1349 | 19- 13 | BT | NE | | E |
| CFS-T0104FC31 | 572 515 0400 | 12- 5 | AQ | EQ | | A |
| CGERH0267FC01 | 572 281 0140 | 18- 30 | AF | DS | | C |
| CGERH0268FC01 | 572 281 0141 | 18- 43 | AE | DS | | C |
| CGERH0406FC01 | 572 281 0054 | 17- 10 | AE | DS | | C |
| 〃 | 572 281 0054 | 18- 29 | AE | DS | | C |
| CGERH0754FC01 | 572 281 1250 | 18- 28 | AK | DX | | C |
| CGERH1032FC01 | 572 281 1216 | 18- 45 | AT | EZ | | C |
| CGERH1041FC01 | 572 281 1217 | 15- 15 | AG | DS | | C |
| CGiDH1541FC01 | 572 345 2293 | 10- 40 | AX | FG | | C |
| CGiDM1338FC08 | 572 345 2026 | 1- 18 | AQ | EQ | | C |
| CGiDM1338FC10 | 572 345 2334 | 1- 18 | AR | EQ | | C |
| CGiDM1338FC11 | 572 345 2335 | 1- 18 | AQ | EQ | | C |
| CGiDM1338FC12 | 572 345 2336 | 1- 18 | AR | EQ | | C |
| CHLDZ1234FC31 | 572 214 1495 | 6- 12 | BH | GX | | E |
| 〃 | 572 214 1495 | 9- 501 | BH | GX | | E |
| CHLDZ1235FC31 | 572 214 1496 | 7- 4 | BF | GN | | E |
| 〃 | 572 214 1496 | 9- 502 | BF | GN | | E |
| CLEVF0766FC01 | 572 248 1046 | 19- 27 | AG | DS | N | C |
| CLEVF0767FC01 | 572 248 1047 | 19- 29 | AG | DS | N | C |
| CPAKA5181FC05 | 572 902 1163 | 28- 5 | BB | GD | | D |
| CPiPP0182FC04 | 572 395 0186 | 14- 51 | AM | EG | | C |
| CPLTM2415FC01 | 572 221 0839 | 10- 42 | AG | DS | | C |
| CPLTM2632FC01 | 572 221 0723 | 10- 41 | AE | DJ | | C |
| CPLTM4027FC09 | 572 221 6670 | 14- 81 | AL | EB | | C |
| CPLTM4067FC73 | 572 221 6622 | 25- 901 | BC | GD | | E |
| CPLTM4129FC01 | 572 221 4389 | 25- 9 | AS | EZ | | C |
| CPLTM4532FC02 | 572 221 6125 | 6- 32 | AP | EQ | | C |
| CPLTM4599FC01 | 572 221 5072 | 6- 17 | AE | DS | | C |
| CPLTM4896FC01 | 572 221 5367 | 21- 42 | AN | EQ | | C |
| CPLTM4903FC02 | 572 221 5563 | 14- 47 | AU | EZ | | C |
| CPLTP5276FC01 | 572 221 5902 | 22- 25 | AG | DX | | C |
| CPWBF0976FC53 | 572 684 2356 | 14- 58 | AR | EQ | | E |
| CPWBF1081FC53 | 572 684 3069 | 20- 17 | BH | HC | N | E |
| CPWBF1081FC53 | 572 684 3069 | 34- 901 | BH | HC | N | E |
| CPWBF1084FC51 | 572 684 2366 | 10- 22 | AU | EZ | | E |
| CPWBF1086FC32 | 572 684 2562 | 17- 7 | AP | EQ | | E |
| CPWBF1088FC31 | 572 684 2335 | 17- 8 | AU | FG | | E |
| CPWBF1089FC32 | 572 684 2563 | 10- 48 | AR | EQ | | E |
| CPWBF1092FC51 | 572 684 2370 | 14- 10 | AS | EQ | | E |
| CPWBF1093FC31 | 572 684 2337 | 8- 17 | AV | FG | | E |
| CPWBF1094FC51 | 572 684 2371 | 14- 5 | BG | GT | | E |
| CPWBF1098FC51 | 572 684 2375 | 14- 4 | BB | GD | | E |
| CPWBF1215FC52 | 572 684 2713 | 20- 2 | BL | HL | | E |
| 〃 | 572 684 2713 | 33- 901 | BL | HL | | E |
| CPWBF1215FC53 | 572 684 2767 | 20- 2 | BN | HZ | | E |
| 〃 | 572 684 2767 | 33- 901 | BN | HZ | | E |
| CPWBF1215FC54 | 572 684 2768 | 20- 2 | BL | HR | | E |
| 〃 | 572 684 2768 | 33- 901 | BL | HR | | E |
| CPWBF1216FC51 | 572 684 2714 | 20- 17 | BL | HL | | E |
| 〃 | 572 684 2714 | 34- 901 | BL | HL | | E |
| CPWBF1216FC52 | 572 684 2769 | 20- 17 | BL | HL | | E |
| 〃 | 572 684 2769 | 34- 901 | BL | HL | | E |
| CPWBF1302FC51 | 572 684 3070 | 6- 65 | BB | GD | N | E |
| 〃 | 572 684 3070 | 35- 901 | BB | GD | N | E |
| CPWBF1302FC52 | 572 684 3071 | 6- 65 | BB | FX | N | E |
| 〃 | 572 684 3071 | 35- 901 | BB | FX | N | E |
| CPWBF1303FC51 | 572 684 3072 | 2- 13 | BN | LE | N | E |
| 〃 | 572 684 3072 | 30- 901 | BN | LE | N | E |
| CPWBF1304FC51 | 572 684 3073 | 20- 2 | BN | HZ | N | E |
| 〃 | 572 684 3073 | 33- 901 | BN | HZ | N | E |
| CPWBF1315FC51 | 572 684 3074 | 20- 19 | AT | EZ | N | E |
| CPWBN1301FC51 | 572 684 3075 | 11- 39 | BV | RB | N | E |
| 〃 | 572 684 3075 | 29- 901 | BV | RB | N | E |
| CPWBN1301FC52 | 572 684 3076 | 11- 39 | BV | RB | N | E |
| 〃 | 572 684 3076 | 29- 901 | BV | RB | N | E |
| CR-WZ0457FC01 | 572 580 0806 | 7- 17 | AU | FG | | B |
| CR-WZ0458FC01 | 572 580 0801 | 7- 17 | AU | FG | | B |
| CR-WZ0459FC01 | 572 580 0802 | 7- 17 | AU | FG | | B |
| CR-WZ0460FC01 | 572 580 0799 | 7- 10 | AY | FQ | | B |
| CR-WZ0461FC01 | 572 580 0804 | 17- 40 | AZ | FQ | | B |
| CREFL0145FC35 | 572 432 0014 | 6- 9 | BP | LP | | E |
| 〃 | 572 432 0014 | 12- 901 | BP | LP | | E |
| CREFL0145FC36 | 572 432 0015 | 6- 9 | BP | LP | | E |
| 〃 | 572 432 0015 | 12- 901 | BP | LP | | E |
| CRŌLP0921FC01 | 572 287 1106 | 21- 13 | AM | EG | | C |
| CRŌLR1048FC51 | 572 287 1462 | 21- 19 | AV | FG | | E |
| CRŌLR1052FC33 | 572 287 1435 | 19- 38 | AX | FG | | E |
| CSLi-0103FC31 | 572 256 0015 | 9- 2 | AF | DS | | E |
| 〃 | 572 256 0015 | 12- 9 | AF | DS | | E |
| CSŌU-0090FC01 | 572 226 0093 | 28- 3 | AS | FG | | D |
| CSŌU-0160FC01 | 572 226 0482 | 28- 4 | AX | FG | | D |
| CYŌK-0048FC31 | 572 421 0072 | 14- 21 | AL | EB | | D |
| 【D】 | | | | | | |
| DHAi-2400FCZZ | 572 542 0401 | 6- 39 | BE | GN | | C |
| 〃 | 572 542 0401 | 7- 33 | BE | GN | | C |
| 〃 | 572 542 0401 | 11- 41 | BE | GN | | C |
| DHAi-2401FCZZ | 572 542 0402 | 6- 39 | BF | GN | | C |
| 〃 | 572 542 0402 | 7- 33 | BF | GN | | C |
| 〃 | 572 542 0402 | 11- 41 | BF | GN | | C |
| DHAi-2404FCZZ | 572 542 0408 | 2- 18 | AY | FQ | | C |
| 〃 | 572 542 0408 | 6- 42 | AY | FQ | | C |
| 〃 | 572 542 0408 | 7- 38 | AY | FQ | | C |
| 〃 | 572 542 0408 | 11- 42 | AY | FQ | | C |
| DHAi-2406FC12 | 572 542 0415 | 10- 16 | AW | FG | | C |
| DHAi-2408FCZZ | 572 542 0416 | 33- 1 | AD | DJ | | C |
| DHAi-2413FCZZ | 572 542 0420 | 18- 56 | AD | DJ | | C |
| DHAi-2414FCZZ | 572 542 0421 | 10- 50 | AK | EB | | C |
| DHAi-2415FCZZ | 572 542 0422 | 21- 1 | AH | DX | | C |
| DHAi-2424FCZZ | 572 542 0434 | 20- 13 | AH | DX | | C |
| DHAi-2496FCZZ | 572 542 0510 | 2- 17 | AH | DX | | C |
| 〃 | 572 542 0510 | 30- 1 | AH | DX | | C |
| DHAi-2503FCZZ | 572 542 0511 | 12- 14 | BA | FX | | C |
| DHAi-2508FCZZ | 572 542 0518 | 14- 76 | AP | EQ | | C |
| DHAi-2510FCZZ | 572 542 0519 | 11- 19 | AH | DX | | C |
| DHAi-2511FCZZ | 572 542 0546 | 19- 80 | AF | DS | | C |
| DHAi-2512FCZZ | 572 542 0555 | 34- 1 | AL | EB | | C |
| DHAi-2568FCZZ | 572 542 0550 | 11- 53 | AP | EQ | | C |
| DHAi-2746FCZZ | 572 542 0867 | 34- 1 | AH | DX | | C |
| DHAi-2788FCZZ | 572 542 1027 | 11- 44 | AS | EQ | | C |
| 〃 | 572 542 1027 | 18- 7 | AS | EQ | | C |
| DHAi-2905FCZZ | 572 542 1179 | 11- 43 | BA | FX | N | C |
| 〃 | 572 542 1179 | 20- 21 | BA | FX | N | C |
| DHAi-2905FC11 | 572 542 1180 | 11- 43 | AZ | FX | N | C |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. Ex. | PRICE R. Ja. | NEW | P/R |
|---|---|---|---|---|---|---|
| DHAi-2905FC11 | 572 542 1180 | 20- 21 | AZ | FX | N | C |
| DHAi-2905FC12 | 572 542 1181 | 11- 43 | BA | FX | N | C |
| 〃 | 572 542 1181 | 20- 21 | BA | FX | N | C |
| DHAi-2905FC13 | 572 542 1182 | 11- 43 | BA | FX | N | C |
| 〃 | 572 542 1182 | 20- 21 | BA | FX | N | C |
| DHAi-2916FCZZ | 572 542 1188 | 10- 16 | AX | FG | N | C |
| DHAi-2917FCZZ | 572 542 1189 | 10- 16 | AW | FG | N | C |
| DHAi-2918FCZZ | 572 542 1190 | 10- 16 | AW | FG | N | C |
| DHAi-2919FCZZ | 572 542 1191 | 15- 19 | AQ | EQ | N | C |
| DHAi-2920FCZZ | 572 542 1192 | 11- 31 | AS | EQ | N | C |
| DUNTW6740FC61 | 572 685 1578 | 16- 901 | BU | NN | | E |
| DUNTW6740FC63 | 572 685 1579 | 16- 901 | BU | NN | | E |
| DUNTW6740FC65 | 572 685 1580 | 16- 901 | BU | NN | | E |
| DUNTW6740FC66 | 572 685 1423 | 16- 901 | BU | NN | | E |
| DUNTW6740FC68 | 572 685 1428 | 16- 901 | BU | NN | | E |
| DUNTW6740FC69 | 572 685 1581 | 16- 901 | BU | NN | | E |
| DUNTW6740FC70 | 572 685 1582 | 16- 901 | BU | NN | | E |
| DWiR-0466CSZZ | 572 427 1070 | 26- 2 | BG | HC | | B |
| 【G】 | | | | | | |
| GCAB-0746FCZZ | 572 107 1090 | 1- 7 | AN | EG | | D |
| GCAB-0747FCZZ | 572 107 1091 | 1- 4 | AN | EG | | D |
| GCAB-0748FCZ2 | 572 107 1202 | 1- 15 | AU | FG | | D |
| GCAB-0818FCZZ | 572 107 1353 | 1- 6 | AY | FQ | | D |
| GCAB-0818FCZ1 | 572 107 1354 | 1- 6 | AY | FQ | | D |
| GCAB-0820FCZZ | 572 107 1356 | 1- 5 | AZ | FQ | | D |
| GCAB-0822FCZ2 | 572 107 1691 | 5- 7 | AX | FG | N | D |
| GCAB-0877FCZ1 | 572 107 1695 | 1- 2 | AX | FG | N | D |
| GCASP0167FCZ1 | 572 108 1236 | 27- 1 | BB | FX | N | D |
| GCŌVH0194FCZ2 | 572 110 0913 | 3- 21 | BB | GD | | D |
| GCŌVH0211FCZZ | 572 110 0803 | 3- 11 | AW | FG | | D |
| GCŌVH0212FCZZ | 572 110 0804 | 3- 5 | AX | FQ | | D |
| GCŌVZ0195FCZZ | 572 110 0477 | 28- 108 | AV | FQ | | D |
| GDAi-0166FCZ1 | 572 112 0143 | 19- 52 | BN | HZ | | D |
| GLEGG0063FCZZ | 572 123 0067 | 19- 47 | AE | DJ | | C |
| 【H】 | | | | | | |
| HiNDP0765FCZZ | 572 156 0808 | 2- 1 | AX | FG | N | D |
| HiNDP0766FCZZ | 572 156 0809 | 2- 1 | AX | FG | N | D |
| HiNDP0767FCZZ | 572 156 0810 | 2- 1 | AX | FG | N | D |
| HiNDP0768FCZZ | 572 156 0811 | 2- 1 | AX | FG | N | D |
| HiNDP0769FCZZ | 572 156 0812 | 2- 1 | AX | FG | N | D |
| HiNDP0770FCZZ | 572 156 0813 | 2- 1 | AX | FG | N | D |
| HiNDP0771FCZZ | 572 156 0814 | 2- 1 | AX | FG | N | D |
| HiNDP0772FCZZ | 572 156 0815 | 2- 1 | AX | FG | N | D |
| HPNLC0236FCZ1 | 572 158 0576 | 1- 16 | AW | FG | N | D |
| 〃 | 572 158 0576 | 2- 3 | AW | FG | N | D |
| 【J】 | | | | | | |
| JBTN-0238FCZZ | 572 170 0377 | 2- 20 | AD | DJ | | C |
| JHNDP0109FCZZ | 572 172 0096 | 13- 21 | AD | DJ | | C |
| JHNDP0128FCZZ | 572 172 0125 | 10- 5 | AD | DJ | | C |
| JKNBP0126FCZZ | 572 174 0307 | 27- 18 | AT | EZ | | C |
| 【L】 | | | | | | |
| LANGT1320FCZZ | 572 200 0704 | 10- 29 | AB | DD | | C |
| LBNDJ0013FCZZ | 541 201 1001 | 12- 13 | AA | DD | | C |
| LBNDJ0013FCZ1 | 572 201 0118 | 6- 55 | AA | DJ | | C |
| 〃 | 572 201 0118 | 11- 57 | AA | DJ | | C |
| 〃 | 572 201 0118 | 14- 9 | AA | DJ | | C |
| 〃 | 572 201 0118 | 19- 79 | AA | DJ | | C |
| 〃 | 572 201 0118 | 20- 41 | AA | DJ | | C |
| LBNDJ0015FCZZ | 572 201 0009 | 11- 58 | AA | DD | | C |
| LBNDJ0016FCZZ | 572 201 0010 | 17- 39 | AA | DD | | C |
| LBNDJ0043FCZZ | 572 201 0022 | 17- 36 | AA | DD | | C |
| LBNDJ0043FCZ1 | 572 201 0125 | 21- 47 | AA | DJ | | C |
| LBŌSZ0979FCZZ | 572 202 0266 | 21- 34 | AF | DS | | C |
| LBŌSZ1124FCZZ | 572 202 0298 | 21- 37 | AF | DS | | C |
| LBŌSZ1125FCZZ | 572 202 0299 | 21- 40 | AC | DD | | C |
| LBSHC0327FCZZ | 572 204 0323 | 21- 43 | AC | DJ | | C |
| LBSHC0335FCZZ | 572 204 0332 | 20- 36 | AC | DJ | | C |
| LBSHZ0324FCZZ | 572 204 0331 | 10- 63 | AC | DJ | | C |
| LBSHZ0325FCZZ | 572 204 0324 | 11- 17 | AD | DJ | | C |
| LBSHZ0326FCZZ | 572 204 0325 | 10- 26 | AC | DJ | | C |
| LBSHZ2029SCZZ | 541 204 1007 | 19- 87 | AB | DD | | C |
| LDAiU0487FCZZ | 572 210 0867 | 16- 20 | AB | DJ | | C |
| LDAiU0488FCZZ | 572 210 0868 | 16- 17 | AB | DJ | | C |
| LDAiU0505FCZZ | 572 210 0901 | 10- 24 | AP | EQ | | C |
| LDAiU0507FCZZ | 572 210 0903 | 8- 10 | AR | EQ | | C |
| LDAiU0509FCZZ | 572 210 0905 | 27- 17 | AD | DJ | | C |
| LDAiU0515FCZZ | 572 210 0906 | 19- 45 | AG | DX | | C |
| LFiX-0016FCZZ | 572 211 0172 | 20- 6 | AD | DJ | | C |
| LFiX-0284FCZZ | 572 211 0176 | 7- 20 | AC | DD | | C |
| 〃 | 572 211 0176 | 9- 3 | AC | DD | | C |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. Ex. | PRICE R. Ja. | NEW | P/R |
|---|---|---|---|---|---|---|
| LFiX-0284FCZZ | 572 211 0176 | 9- 25 | AC | DD | | C |
| LFiX-0408FCZZ | 572 211 0345 | 7- 19 | AB | DD | | C |
| LFiX-0409FCZZ | 572 211 0346 | 7- 15 | AB | DD | | C |
| LFiX-0438FCZZ | 572 211 0497 | 9- 26 | AD | DJ | | C |
| LFRM-0745FCZZ | 572 213 1023 | 21- 27 | AE | DJ | | C |
| LFRM-0834FCZ1 | 572 213 1664 | 10- 13 | AV | FG | | C |
| LFRM-0835FCZ1 | 572 213 1665 | 10- 34 | AU | EZ | | C |
| 〃 | 572 213 1665 | 11- 49 | AU | EZ | | C |
| LFRM-0837FCZZ | 572 213 1353 | 18- 24 | AH | DX | | C |
| LFRM-0840FCZ1 | 572 213 1771 | 17- 17 | AT | EZ | N | C |
| LFRM-0842FCZ1 | 572 213 1495 | 16- 13 | AP | EQ | | C |
| LFRM-0843FCZZ | 572 213 1359 | 14- 56 | AY | FQ | | C |
| LFRM-0844FCZZ | 572 213 1360 | 14- 1 | AS | EQ | | C |
| LHLDW0544FCZZ | 572 214 0461 | 28- 125 | AC | DD | | C |
| LHLDW1013FCZZ | 572 214 0640 | 20- 37 | AB | DD | | C |
| LHLDW1269FCZZ | 572 214 1534 | 6- 46 | AC | DJ | | C |
| 〃 | 572 214 1534 | 11- 20 | AC | DJ | | C |
| LHLDW1287FCZZ | 572 214 1543 | 7- 39 | AD | DJ | | C |
| LHLDW2135SCZZ | 595 214 0096 | 6- 62 | AB | DD | | C |
| LHLDZ0932FCYZ | 572 214 1248 | 25- 12 | AD | DJ | | C |
| LHLDZ1094FCZZ | 572 214 1227 | 25- 10 | AD | DJ | | C |
| LHLDZ1095FCZZ | 572 214 1228 | 25- 6 | AD | DJ | | C |
| LHLDZ1191FCZZ | 572 214 1429 | 16- 11 | AC | DJ | | C |
| LHLDZ1201FCZZ | 572 214 1419 | 10- 10 | AE | DS | | C |
| LHLDZ1204FCZZ | 572 214 1422 | 17- 22 | AG | DX | | C |
| LHLDZ1229FCZZ | 572 214 1497 | 18- 8 | AN | EQ | | C |
| LHLDZ1230FCZ1 | 572 214 1575 | 26- 10 | AG | DS | | C |
| LHLDZ1231FCZ2 | 572 214 1809 | 26- 7 | AH | DX | N | C |
| LHLDZ1232FCZZ | 572 214 1500 | 8- 28 | AH | DX | | C |
| LHLDZ1235FCZZ | 572 214 1503 | 9- 34 | AM | EG | | C |
| LHLDZ1236FCZZ | 572 214 1504 | 9- 24 | AR | EQ | | C |
| LHLDZ1237FCZZ | 572 214 1505 | 15- 25 | AC | DJ | | C |
| LHLDZ1238FCZ1 | 572 214 1751 | 19- 44 | AE | DS | | C |
| LHLDZ1268FCZZ | 572 214 1507 | 10- 53 | AE | DS | | C |
| LHLDZ1274FCZZ | 572 214 1508 | 14- 57 | AF | DS | | C |
| LPiNS0089FCZZ | 572 218 0075 | 13- 35 | AA | DD | | C |
| LPiNS0094FCZZ | 572 218 0077 | 18- 23 | AB | DD | | C |
| LPiNS0133FCZZ | 572 218 0086 | 17- 25 | AA | DD | | C |
| 〃 | 572 218 0086 | 19- 18 | AA | DD | | C |
| LPiNS0134FCZZ | 572 218 0043 | 17- 32 | AB | DD | | C |
| LPiNS0155FCZZ | 572 218 0052 | 11- 6 | AA | DD | | C |
| 〃 | 572 218 0052 | 18- 18 | AA | DD | | C |
| 〃 | 572 218 0052 | 19- 8 | AA | DD | | C |
| LPiNS0165FCZZ | 572 218 0087 | 21- 16 | AB | DD | | C |
| LPiNS0280FCZZ | 572 218 0367 | 3- 9 | AD | DJ | | C |
| LPiNS0288FCZZ | 572 218 0390 | 6- 5 | AB | DJ | | C |
| LPiNS0297FCZZ | 572 218 0408 | 14- 40 | AB | DJ | | C |
| LPiNS0298FCZZ | 572 218 0409 | 14- 63 | AA | DJ | | C |
| LPLTM2430FCZZ | 572 221 2303 | 15- 26 | AC | DD | | C |
| LPLTM2573FCZ1 | 572 221 2384 | 1- 10 | AD | DJ | | C |
| LPLTM3718FCZZ | 572 221 3434 | 10- 46 | AG | DS | | C |
| LPLTM3749FCZZ | 572 221 3077 | 26- 5 | AC | DD | | C |
| LPLTM3772FCZ1 | 572 221 5580 | 15- 1 | AU | EZ | | C |
| LPLTM3877FCZZ | 572 221 3174 | 15- 12 | AD | DJ | | C |
| LPLTM3909FCZZ | 572 221 3249 | 27- 13 | AD | DJ | | C |
| LPLTM4046FCZZ | 572 221 4344 | 6- 23 | AD | DJ | | C |
| LPLTM4047FCZZ | 572 221 4345 | 6- 30 | AD | DJ | | C |
| LPLTM4054FCZZ | 572 221 4352 | 6- 11 | AB | DD | | C |
| LPLTM4067FCZZ | 572 221 4356 | 25- 8 | AN | EG | | C |
| LPLTM4068FCZZ | 572 221 4357 | 25- 11 | AM | EG | | C |
| LPLTM4124FCZZ | 572 221 4421 | 12- 1 | AC | DJ | | C |
| LPLTM4562FCZZ | 572 221 5084 | 7- 2 | AA | DJ | | C |
| LPLTM4757FCZZ | 572 221 5368 | 11- 4 | AL | EB | | C |
| LPLTM4759FCZZ | 572 221 5370 | 11- 38 | AK | DX | | C |
| LPLTM4761FCZZ | 572 221 5371 | 20- 9 | AF | DS | | C |
| LPLTM4763FCZZ | 572 221 5373 | 14- 42 | AC | DJ | | C |
| LPLTM4764FCZZ | 572 221 5374 | 14- 29 | AP | EQ | | C |
| LPLTM4765FCZZ | 572 221 5375 | 14- 7 | AD | DJ | | C |
| LPLTM4766FCZZ | 572 221 5376 | 6- 25 | AN | EG | | C |
| LPLTM4777FCZZ | 572 221 5380 | 18- 5 | AD | DJ | | C |
| LPLTM4778FCZZ | 572 221 5381 | 18- 4 | AD | DJ | | C |
| LPLTM4885FCZZ | 572 221 5387 | 19- 46 | AG | DX | | C |
| LPLTM4887FCZZ | 572 221 5389 | 19- 39 | AY | FQ | | C |
| LPLTM4966FCZZ | 572 221 5567 | 12- 6 | AR | EQ | | C |
| LPLTM4967FCZZ | 572 221 5568 | 12- 18 | AE | DS | | C |
| LPLTM4980FCZZ | 572 221 5581 | 19- 67 | AK | EB | | C |
| LPLTM4981FCZZ | 572 221 5536 | 34- 2 | AG | DS | | C |
| LPLTM4982FCZZ | 572 221 5537 | 14- 65 | AC | DJ | | C |
| LPLTM4984FCZZ | 572 221 5582 | 15- 33 | AP | EQ | | C |
| LPLTM5008FCZZ | 572 221 5593 | 21- 49 | AE | DS | | C |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. Ex. | PRICE R. Ja. | NEW | P/R |
|---|---|---|---|---|---|---|
| LPLTM5010FCZZ | 572 221 5583 | 16- 29 | AD | DJ | | C |
| LPLTM5015FCZZ | 572 221 5584 | 9- 36 | AE | DJ | | C |
| LPLTM5029FCZZ | 572 221 5692 | 6- 58 | AG | DX | | C |
| LPLTM5036FCZZ | 572 221 6041 | 16- 32 | AD | DJ | | C |
| LPLTM5156FCZZ | 572 221 5709 | 16- 33 | AE | DJ | | C |
| LPLTM5471FCZZ | 572 221 6752 | 6- 31 | AH | DX | N | C |
| LPLTP3756FCZ1 | 572 221 1224 | 27- 10 | AG | DX | | C |
| LPLTP3757FCZ2 | 572 221 6776 | 27- 4 | AK | EB | N | C |
| LPLTP4760FCZZ | 572 221 5394 | 20- 1 | AQ | EQ | | C |
| LPLTP4781FCZZ | 572 221 5395 | 27- 19 | AH | DX | | C |
| LPLTP4782FCZZ | 572 221 5396 | 27- 19 | AH | DX | | C |
| LPLTP4783FCZZ | 572 221 5397 | 27- 19 | AH | DX | | C |
| LPLTP4890FCZZ | 572 221 5398 | 10- 47 | AL | EB | | C |
| LPLTP4897FCZ1 | 572 221 5637 | 22- 14 | AK | DX | | C |
| LPLTP4964FCZZ | 572 221 5575 | 12- 7 | AP | EQ | | C |
| LPLTP4965FCZZ | 572 221 5576 | 12- 15 | AP | EQ | | C |
| LPLTP5028FCZZ | 572 221 5635 | 27- 2 | AE | DS | | C |
| LPLTP5324FCZZ | 572 221 6142 | 28- 126 | AQ | EQ | | C |
| LPLTZ5474FCZZ | 572 221 6623 | 25- 1 | AH | DX | | C |
| LRALM0116FCZZ | 572 223 0128 | 6- 37 | AE | DS | | C |
| LRALM0119FCZZ | 572 223 0142 | 7- 25 | AK | EB | | C |
| LSŌU-0141FCZ1 | 572 226 0419 | 22- 6 | AR | EQ | | D |
| LSŌU-0142FCZZ | 572 226 0389 | 22- 13 | AQ | EQ | | D |
| LSŌU-0144FCZZ | 572 226 0387 | 22- 15 | AL | EB | | D |
| LSTPF0172FCZ1 | 572 230 0380 | 16- 24 | AA | DJ | | C |
| LSTPF0262FCZZ | 572 230 0067 | 15- 28 | AC | DD | | C |
| LSTPP0255FCZ1 | 572 230 0412 | 27- 12 | AD | DJ | | C |
| LSTPP0260FCZZ | 572 230 0080 | 19- 53 | AB | DD | | C |
| LSTPP0274FCZZ | 572 230 0326 | 19- 31 | AA | DD | | C |
| LSTPP0278FCZZ | 572 230 0328 | 21- 8 | AC | DD | | C |
| LSTPP0279FCZZ | 572 230 0323 | 16- 38 | AB | DD | | C |
| 〃 | 572 230 0323 | 17- 34 | AB | DD | | C |
| LSTPP0314FCZZ | 572 230 0395 | 17- 19 | AA | DJ | | C |
| LSTPP0315FCZZ | 572 230 0396 | 22- 21 | AD | DJ | | C |
| LSTPP0320FCZZ | 572 230 0411 | 11- 51 | AC | DJ | | C |
| LSTPP0347FCZZ | 572 230 0475 | 13- 15 | AD | DJ | N | C |
| LSUPP0084FCZZ | 572 233 0114 | 20- 18 | AB | DJ | | C |
| LSUPP0086FCZZ | 572 233 0116 | 11- 47 | AB | DJ | | C |
| LSUPP0094FCZZ | 572 233 0117 | 11- 48 | AC | DJ | | C |
| LSUPP0095FCZZ | 572 233 0118 | 11- 46 | AC | DJ | | C |
| LX-BZ0032FCZZ | 572 970 0404 | 6- 4 | AB | DD | | C |
| LX-BZ0193FCZZ | 572 970 0304 | 17- 46 | AB | DD | | C |
| 〃 | 572 970 0304 | 19- 73 | AB | DD | | C |
| LX-BZ0266FCZZ | 572 970 0094 | 7- 36 | AB | DD | | C |
| LX-BZ0300FCZZ | 572 970 0172 | 14- 3 | AB | DD | | C |
| LX-BZ0320FCZZ | 572 970 0193 | 6- 19 | AA | DD | | C |
| 〃 | 572 970 0193 | 9- 21 | AA | DD | | C |
| LX-BZ0324FCZZ | 572 970 0197 | 6- 7 | AA | DD | | C |
| LX-BZ0334FCZZ | 572 970 0244 | 14- 26 | AA | DD | | C |
| LX-BZ0335FCZZ | 572 970 0245 | 6- 36 | AA | DD | | C |
| 〃 | 572 970 0245 | 7- 1 | AA | DD | | C |
| LX-BZ0342FCZZ | 572 970 0256 | 16- 21 | AB | DD | | C |
| LX-BZ0426FCZZ | 572 970 0382 | 14- 12 | AA | DD | | C |
| LX-BZ0529FCZZ | 572 970 0219 | 15- 27 | AA | DD | | C |
| LX-BZ0578FCZZ | 572 970 0131 | 28- 101 | AC | DD | | C |
| LX-BZ0581FCZZ | 572 970 0134 | 11- 34 | AB | DD | | C |
| LX-BZ0583FCZZ | 572 970 0135 | 11- 32 | AB | DD | | C |
| LX-BZ0589FCZZ | 572 970 0140 | 11- 21 | AA | DD | | C |
| LX-BZ0618FCZZ | 572 970 0056 | 9- 7 | AA | DD | | C |
| LX-BZ0637FCZZ | 572 970 0183 | 7- 21 | AC | DJ | | C |
| LX-BZ0649FCZZ | 572 970 1242 | 28- 102 | AB | DD | | C |
| LX-BZ0656FCZZ | 572 970 1247 | 14- 70 | AD | DJ | | C |
| LX-BZ0663FCZZ | 572 970 1239 | 10- 2 | AD | DJ | | C |
| LX-BZ0670FCZZ | 572 970 1361 | 10- 30 | AC | DD | | C |
| LX-BZ0713FCZZ | 572 970 1454 | 8- 23 | AB | DD | | C |
| LX-BZ0725FCZZ | 572 970 1494 | 9- 29 | AB | DD | | C |
| LX-BZ0753FCZZ | 572 970 1560 | 7- 7 | AC | DD | | C |
| 〃 | 572 970 1560 | 8- 12 | AC | DD | | C |
| LX-BZ0767FCZZ | 572 970 1571 | 12- 20 | AB | DD | | C |
| LX-BZ0771FCZZ | 572 970 1572 | 11- 37 | AC | DD | | C |
| 〃 | 572 970 1572 | 21- 2 | AC | DD | | C |
| LX-BZ0772FCZZ | 572 970 1580 | 28- 103 | AD | DJ | | C |
| LX-BZ0786FCZZ | 572 970 1621 | 8- 24 | AC | DD | | C |
| LX-BZ0840FCZZ | 572 970 1818 | 8- 41 | AC | DD | | C |
| LX-BZ4008SC0M | 577 970 0006 | 25- 13 | AA | DD | | C |
| LX-NZ0089FCZZ | 572 980 0101 | 18- 3 | AA | DD | | C |
| LX-WZ0017FCZZ | 572 990 0198 | 6- 16 | AA | DD | | C |
| LX-WZ0050FCZ1 | 572 990 0423 | 7- 22 | AA | DD | | C |
| LX-WZ0075FCZZ | 572 990 0171 | 28- 104 | AA | DD | | C |
| LX-WZ0134FCZZ | 572 990 0048 | 7- 23 | AA | DD | | C |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. Ex. | PRICE R. Ja. | NEW | P/R |
|---|---|---|---|---|---|---|
| LX-WZ0139FCZZ | 572 990 0054 | 9- 31 | AA | DD | | C |
| LX-WZ0186FCZZ | 572 990 0032 | 11- 24 | AA | DD | | C |
| LX-WZ0225FCZZ | 572 990 0180 | 13- 22 | AA | DD | | C |
| LX-WZ0256FCZZ | 572 990 0114 | 5- 13 | AA | DD | | C |
| 〃 | 572 990 0114 | 22- 23 | AA | DD | | C |
| LX-WZ0285FCZZ | 572 990 0112 | 14- 64 | AA | DD | | C |
| LX-WZ0294FCZZ | 572 990 0132 | 15- 14 | AA | DD | | C |
| LX-WZ0310FCZZ | 572 990 0383 | 14- 60 | AB | DD | | C |
| LX-WZ0314FCZZ | 572 990 0230 | 18- 33 | AA | DD | | C |
| LX-WZ0413FCZZ | 572 990 0432 | 9- 32 | AA | DD | | C |
| LX-WZ0421FCZZ | 572 990 0446 | 18- 42 | AA | DD | | C |
| LX-WZ0424FCZZ | 572 990 0450 | 8- 40 | AC | DD | | C |
| LX-WZ2028SCZZ | 509 990 5003 | 27- 14 | AA | DD | | C |
| LX-WZ5028BCZZ | 588 990 0012 | 9- 37 | AA | DD | | C |
| 【M】 | | | | | | |
| MARMP0116FCZZ | 572 240 0063 | 21- 7 | AC | DJ | | C |
| MARMP0117FCZ1 | 572 240 0155 | 21- 9 | AD | DS | | C |
| MARMP0120FCZZ | 572 240 0078 | 13- 29 | AE | DS | | C |
| MARMP0139FCZZ | 572 240 0084 | 13- 32 | AE | DS | | C |
| MARMP0187FCZZ | 572 240 0195 | 17- 29 | AC | DJ | | C |
| MARMP0190FCZ1 | 572 240 0228 | 19- 42 | AG | DS | | C |
| MARMP0194FCZZ | 572 240 0217 | 21- 14 | AG | DX | | C |
| MARMP0195FCZZ | 572 240 0218 | 22- 3 | AD | DJ | | C |
| MCAMM0093FCZZ | 572 241 0081 | 8- 22 | AF | DS | | C |
| MHNG-0086FCZZ | 572 246 0117 | 3- 23 | AL | EG | | C |
| MHNG-0096FCZZ | 572 246 0129 | 3- 22 | AL | EG | | C |
| MHNG-0170FCZ1 | 572 246 0256 | 3- 8 | AE | DS | | C |
| MHNG-0172FCZ1 | 572 246 0336 | 3- 3 | AQ | EQ | | C |
| MHNG-0173FCZ1 | 572 246 0337 | 3- 4 | AQ | EQ | | C |
| MLEVF0374FCZZ | 572 248 0280 | 10- 33 | AC | DJ | | C |
| MLEVF0666FCZZ | 572 248 0850 | 10- 6 | AF | DS | | C |
| MLEVP0667FCZ1 | 572 248 0893 | 10- 25 | AD | DJ | | C |
| MLEVP0668FCZZ | 572 248 0852 | 18- 11 | AE | DJ | | C |
| MLEVP0669FCZZ | 572 248 0853 | 17- 6 | AE | DJ | | C |
| MLEVP0670FCZZ | 572 248 0854 | 17- 18 | AE | DJ | | C |
| MLEVP0671FCZZ | 572 248 0855 | 27- 23 | AE | DS | | C |
| MLEVP0672FCZZ | 572 248 0856 | 14- 34 | AH | DX | | C |
| MLEVP0673FCZ1 | 572 248 0894 | 5- 10 | AF | DS | | C |
| MLEVP0688FCZZ | 572 248 0874 | 10- 4 | AH | DX | | C |
| MLEVP0738FCZZ | 572 248 0970 | 21- 30 | AC | DJ | | C |
| MLEVP0739FCZZ | 572 248 0971 | 21- 29 | AD | DJ | | C |
| MSPRB2278FCZZ | 572 258 2325 | 19- 54 | AY | FQ | | B |
| MSPRB2350FCZZ | 572 258 2326 | 19- 55 | AY | FQ | | B |
| MSPRC1299FCZZ | 572 258 1199 | 11- 35 | AA | DD | | C |
| MSPRC1315FCZZ | 572 258 1296 | 21- 36 | AD | DJ | | C |
| MSPRC1317FCZZ | 572 258 1279 | 21- 28 | AA | DD | | C |
| MSPRC1318FCZZ | 572 258 1285 | 21- 33 | AA | DD | | C |
| MSPRC1534FCZZ | 572 258 0451 | 11- 33 | AA | DD | | C |
| MSPRC1544FCZZ | 572 258 0453 | 21- 38 | AE | DS | | C |
| MSPRC1804FCZZ | 572 258 0364 | 27- 11 | AA | DD | | C |
| MSPRC1811FCZZ | 572 258 0374 | 14- 33 | AA | DD | | C |
| MSPRC1873FCZZ | 572 258 0274 | 27- 8 | AB | DD | | C |
| MSPRC2025FCZZ | 572 258 1895 | 14- 61 | AA | DD | | C |
| MSPRC2184FCZZ | 572 258 2218 | 10- 9 | AA | DJ | | C |
| MSPRC2276FCZZ | 572 258 2328 | 18- 34 | AB | DJ | | C |
| MSPRC2280FCZZ | 572 258 2330 | 19- 35 | AC | DJ | | C |
| MSPRC2281FCZZ | 572 258 2331 | 19- 34 | AC | DJ | | C |
| MSPRC2282FCZZ | 572 258 2332 | 10- 57 | AC | DJ | | C |
| MSPRC2287FCZ2 | 572 258 2426 | 14- 50 | AL | EB | | C |
| MSPRC2288FCZZ | 572 258 2335 | 14- 25 | AC | DJ | | C |
| MSPRC2295FCZZ | 572 258 2336 | 11- 36 | AC | DJ | | C |
| MSPRC2319FCZZ | 572 258 2340 | 11- 23 | AC | DJ | | C |
| MSPRC2335FCZZ | 572 258 2342 | 17- 30 | AK | DX | | C |
| MSPRC2336FCZZ | 572 258 2343 | 17- 28 | AC | DJ | | C |
| MSPRC2348FCZZ | 572 258 2345 | 16- 15 | AB | DJ | | C |
| MSPRC2366FCZZ | 572 258 2408 | 21- 21 | AC | DJ | | C |
| MSPRC2367FCZZ | 572 258 2415 | 19- 43 | AK | EB | | C |
| MSPRC2368FCZZ | 572 258 2409 | 10- 3 | AP | EQ | | C |
| MSPRC2369FCZZ | 572 258 2410 | 12- 24 | AP | EQ | | C |
| MSPRC2370FCZZ | 572 258 2416 | 19- 72 | AK | EB | | C |
| MSPRC2416FCZZ | 572 258 2497 | 19- 28 | AD | DJ | | C |
| MSPRC2417FCZZ | 572 258 2446 | 19- 74 | AD | DJ | | C |
| MSPRC2591FCZZ | 572 258 2773 | 10- 31 | AC | DJ | | C |
| MSPRC2697FCZZ | 572 258 2981 | 13- 14 | AC | DJ | N | C |
| MSPRC2704FCZZ | 572 258 2989 | 8- 8 | AD | DJ | | C |
| MSPRP1293FCZZ | 572 258 0086 | 18- 2 | AB | DD | | C |
| MSPRP1550FCZZ | 572 258 0472 | 26- 8 | AA | DD | | C |
| MSPRP2101FCZZ | 572 258 1988 | 12- 10 | AC | DJ | | C |
| MSPRP2354FCZZ | 572 258 2391 | 12- 4 | AG | DX | | C |
| MSPRP2355FCZZ | 572 258 2392 | 12- 16 | AL | EB | | C |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. Ex. | PRICE R. Ja. | NEW | P/R |
|---|---|---|---|---|---|---|
| MSPRT1203FCZZ | 572 258 0874 | 10- 45 | AA | DD | | C |
| MSPRT1324FCZ1 | 572 258 2242 | 16- 9 | AA | DJ | | C |
| MSPRT1395FCZZ | 572 258 0931 | 26- 3 | AA | DD | | C |
| MSPRT1640FCZZ | 572 258 0706 | 13- 30 | AC | DD | | C |
| MSPRT2277FCZZ | 572 258 2347 | 10- 52 | AC | DJ | | C |
| MSPRT2283FCZZ | 572 258 2348 | 20- 26 | AC | DJ | | C |
| MSPRT2285FCZZ | 572 258 2349 | 7- 5 | AC | DJ | | C |
| MSPRT2286FCZZ | 572 258 2350 | 16- 18 | AC | DJ | | C |
| MSPRT2320FCZZ | 572 258 2351 | 21- 12 | AC | DJ | | C |
| MSPRT2321FCZZ | 572 258 2352 | 21- 22 | AB | DJ | | C |
| MSPRT2521FCZZ | 572 258 2718 | 19- 22 | AC | DJ | | C |
| 【N】 | | | | | | |
| NBLTH0170FCZZ | 572 271 0046 | 19- 2 | AH | DX | | B |
| NBLTH0235FCZZ | 572 271 0404 | 17- 26 | AF | DX | | B |
| NBLTH0245FCZZ | 572 271 0421 | 11- 3 | AN | EQ | | B |
| NBLTH0246FCZZ | 572 271 0422 | 19- 4 | AK | DX | | B |
| NBRGC0080FCZZ | 572 272 0079 | 14- 31 | AD | DJ | | B |
| NBRGC0080FCZ1 | 572 272 0504 | 11- 26 | AD | DJ | | B |
| NBRGC0133FCZ1 | 572 272 0470 | 11- 9 | AC | DJ | | C |
| 〃 | 572 272 0470 | 18- 19 | AC | DJ | | C |
| 〃 | 572 272 0470 | 19- 11 | AC | DJ | | C |
| NBRGC0136FCZZ | 572 272 0096 | 18- 25 | AC | DD | | B |
| NBRGC0136FCZ1 | 572 272 0481 | 15- 7 | AC | DJ | | B |
| NBRGC0188FCZZ | 572 272 0243 | 19- 16 | AB | DD | | B |
| NBRGC0307FCZZ | 572 272 0112 | 8- 38 | AC | DJ | | C |
| NBRGC0387FCZ1 | 572 272 0471 | 6- 49 | AC | DJ | | B |
| NBRGC0401FCZZ | 572 272 0150 | 8- 39 | AC | DD | | C |
| NBRGC0504FCZZ | 572 272 0467 | 6- 50 | AC | DJ | | C |
| NBRGC0531FCZZ | 572 272 0514 | 8- 25 | AC | DJ | | C |
| NBRGC0536FCZZ | 572 272 0515 | 11- 11 | AF | DS | | C |
| NBRGC0537FCZZ | 572 272 0516 | 8- 21 | AG | DX | | C |
| NBRGC0580FCZZ | 572 272 0568 | 15- 36 | AG | DS | | B |
| NBRGC0584FCZZ | 572 272 0571 | 17- 43 | AD | DJ | | C |
| NBRGC2019SCZZ | 572 272 0187 | 17- 13 | AC | DJ | | C |
| NBRGC2029SCZZ | 572 272 0178 | 8- 3 | AB | DD | | B |
| NBRGP0191FCZZ | 572 272 0028 | 17- 15 | AB | DD | | C |
| NBRGP0299FCZZ | 572 272 0013 | 13- 34 | AC | DJ | | B |
| NBRGP0302FCZZ | 572 272 0020 | 21- 5 | AB | DD | | C |
| NBRGP0426FCZZ | 572 272 0168 | 8- 30 | AB | DD | | C |
| NBRGP0509FCZ1 | 572 272 0526 | 10- 58 | AG | DS | | C |
| NBRGP0510FCZZ | 572 272 0489 | 17- 4 | AC | DJ | | C |
| 〃 | 572 272 0489 | 19- 9 | AC | DJ | | C |
| NBRGP0533FCZZ | 572 272 0505 | 14- 52 | AG | DX | | C |
| NBRGP0534FCZ1 | 572 272 0614 | 14- 23 | AD | DJ | | C |
| NBRGP0535FCZZ | 572 272 0507 | 14- 48 | AD | DJ | | C |
| NBRGP0547FCZZ | 572 272 0520 | 19- 69 | AD | DJ | | C |
| NBRGP0593FCZZ | 572 272 0617 | 19- 1 | AD | DJ | N | C |
| NBRGY0513FCZZ | 572 272 0486 | 19- 24 | AK | EB | | C |
| NBRGY2122SCZZ | 595 272 0047 | 14- 41 | AB | DD | | C |
| NCPL-0007FCZZ | 572 274 0006 | 11- 22 | AC | DD | | C |
| NFANP0043FCZZ | 572 277 0056 | 7- 30 | AZ | FQ | | B |
| NGERH0070FCZZ | 572 281 0151 | 18- 47 | AD | DJ | | C |
| NGERH0111FCZZ | 572 281 0196 | 11- 27 | AD | DJ | | C |
| NGERH0147FCZZ | 572 281 0237 | 20- 30 | AF | DS | | C |
| NGERH0193FCZZ | 572 281 0318 | 5- 5 | AB | DD | | C |
| 〃 | 572 281 0318 | 22- 11 | AB | DD | | C |
| 〃 | 572 281 0318 | 27- 22 | AB | DD | | C |
| NGERH0205FCZZ | 572 281 0325 | 20- 29 | AC | DD | | C |
| NGERH0314FCZZ | 572 281 0602 | 13- 36 | AC | DD | | C |
| NGERH0349FCZZ | 572 281 0557 | 18- 41 | AC | DD | | C |
| NGERH0457FCZZ | 572 281 0266 | 18- 16 | AC | DD | | C |
| NGERH0495FCZZ | 572 281 0665 | 21- 17 | AC | DD | | C |
| NGERH0515FCZZ | 577 281 0053 | 20- 24 | AC | DD | | C |
| NGERH0623FCZZ | 572 281 0315 | 13- 38 | AB | DD | | C |
| NGERH0626FCZZ | 572 281 0408 | 13- 40 | AC | DD | | C |
| NGERH0739FCZZ | 572 281 0333 | 18- 31 | AB | DD | | C |
| NGERH0740FCZZ | 572 281 0336 | 18- 26 | AB | DD | | C |
| NGERH0742FCZZ | 572 281 0338 | 18- 36 | AB | DD | | C |
| NGERH0866FCZZ | 572 281 0955 | 19- 19 | AC | DD | | C |
| NGERH0892FCZZ | 572 281 0964 | 21- 15 | AB | DD | | C |
| NGERH1015FCZZ | 572 281 1155 | 11- 13 | AD | DJ | | C |
| 〃 | 572 281 1155 | 20- 28 | AD | DJ | | C |
| NGERH1029FCZZ | 572 281 1218 | 18- 38 | AD | DJ | | C |
| NGERH1030FCZZ | 572 281 1219 | 18- 32 | AE | DJ | | C |
| NGERH1031FCZZ | 572 281 1220 | 18- 22 | AD | DJ | | C |
| NGERH1033FCZZ | 572 281 1221 | 18- 40 | AF | DS | | C |
| NGERH1034FCZZ | 572 281 1222 | 19- 32 | AF | DS | | C |
| NGERH1035FCZZ | 572 281 1223 | 20- 31 | AE | DS | | C |
| NGERH1036FCZZ | 572 281 1224 | 8- 14 | AF | DS | | C |
| NGERH1037FCZZ | 572 281 1225 | 8- 20 | AG | DX | | C |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. Ex. | PRICE R. Ja. | NEW | P/R |
|---|---|---|---|---|---|---|
| NGERH1040FCZZ | 572 281 1226 | 15- 4 | AD | DJ | | C |
| NGERH1042FCZZ | 572 281 1227 | 14- 43 | AD | DJ | | C |
| NGERH1043FCZZ | 572 281 1228 | 14- 37 | AF | DS | | C |
| NGERH1044FCZZ | 572 281 1229 | 14- 24 | AF | DS | | C |
| NGERH1045FCZZ | 572 281 1230 | 14- 30 | AD | DJ | | C |
| NGERH1046FCZZ | 572 281 1231 | 11- 10 | AE | DJ | | C |
| NGERH1056FCZZ | 572 281 1232 | 15- 16 | AE | DJ | | C |
| NGERH1057FCZZ | 572 281 1233 | 15- 17 | AE | DJ | | C |
| NGERH1060FCZZ | 572 281 1235 | 21- 44 | AE | DJ | | C |
| NGERH1071FCZZ | 572 281 1236 | 6- 6 | AG | DS | | C |
| NGERH1074FCZZ | 572 281 1237 | 14- 39 | AD | DJ | | C |
| NGERH1078FCZZ | 572 281 1261 | 11- 16 | AD | DJ | | C |
| NGERH1079FCZZ | 572 281 1264 | 21- 45 | AE | DJ | | C |
| NGERH1214FCZZ | 572 281 1458 | 16- 26 | AP | EQ | | C |
| NGERR0377FCZZ | 572 281 0271 | 5- 3 | AD | DJ | | C |
| NGERR0878FCZZ | 572 281 0969 | 22- 7 | AD | DJ | | C |
| NGERR1038FCZZ | 572 281 1238 | 8- 26 | AF | DS | | C |
| NGERR1039FCZZ | 572 281 1239 | 9- 22 | AG | DX | | C |
| NGERR1047FCZZ | 572 281 1241 | 27- 21 | AF | DS | | C |
| NGERR1048FCZZ | 572 281 1242 | 27- 20 | AG | DS | | C |
| NGERR1283FCZZ | 572 281 1616 | 8- 44 | AD | DJ | | C |
| NPLYZ0106FCZZ | 572 284 0046 | 17- 27 | AC | DJ | | C |
| NPLYZ0172FCZ1 | 572 284 0138 | 6- 3 | AL | EB | | C |
| NPLYZ0258FCZZ | 572 284 0419 | 18- 52 | AC | DJ | | C |
| NPLYZ0276FCZZ | 572 284 0455 | 9- 6 | AG | DX | | C |
| NPLYZ0285FCZ1 | 572 284 0513 | 11- 8 | AE | DS | | C |
| NPLYZ0292FCZZ | 572 284 0504 | 6- 15 | AH | DX | | C |
| NPLYZ0295FCZ1 | 572 284 0642 | 17- 3 | AM | EG | | C |
| NPLYZ0297FCZZ | 572 284 0524 | 19- 7 | AD | DJ | | C |
| NPLYZ0298FCZZ | 572 284 0525 | 8- 13 | AH | DX | | C |
| NPLYZ0340FCZZ | 572 284 0648 | 6- 14 | AC | DJ | | C |
| 〃 | 572 284 0648 | 7- 8 | AC | DJ | | C |
| 〃 | 572 284 0648 | 8- 11 | AC | DJ | | C |
| NRŌLM1053FCZ1 | 572 287 1459 | 10- 59 | AY | FQ | | C |
| NRŌLM1061FCZ1 | 572 287 1725 | 15- 10 | BD | GN | N | C |
| NRŌLP0845FCZ1 | 572 287 1427 | 15- 21 | AR | EQ | | C |
| NRŌLP1054FCZ1 | 572 287 1451 | 19- 3 | AF | DS | | C |
| NRŌLP1060FCZZ | 572 287 1396 | 10- 54 | AF | DS | | C |
| 〃 | 572 287 1396 | 17- 20 | AF | DS | | C |
| NRŌLR0878FCZZ | 572 287 0690 | 17- 35 | AM | EG | | C |
| NRŌLR1049FCZ1 | 572 287 1436 | 17- 24 | AU | EZ | | C |
| NRŌLR1051FCZZ | 572 287 1365 | 21- 18 | AT | EZ | | C |
| NRŌLR1055FCZ1 | 572 287 1477 | 19- 10 | AY | FQ | | C |
| NRŌLR1056FCZ3 | 572 287 1642 | 19- 17 | AY | FQ | | C |
| NRŌLR1058FCZ3 | 572 287 1558 | 19- 25 | BH | GX | | C |
| NRŌLR1059FCZ1 | 572 287 1511 | 17- 5 | AS | EZ | | C |
| NRŌLR1112FCZZ | 572 287 1456 | 16- 10 | AG | DX | | C |
| NRŌLR1113FCZZ | 572 287 1457 | 16- 31 | AG | DX | | C |
| NRŌLS0848FCZZ | 572 287 0488 | 13- 28 | AP | EQ | | C |
| NRŌLT1063FCZ2 | 572 287 1452 | 16- 23 | BD | GN | | C |
| NSFTD1597FCZZ | 572 290 0162 | 7- 16 | AP | EQ | | C |
| NSFTZ1595FCZZ | 572 290 0461 | 10- 36 | AD | DJ | | C |
| NSFTZ1627FCZZ | 572 290 0472 | 13- 33 | AG | DS | | C |
| NSFTZ1628FCZZ | 572 290 0473 | 13- 31 | AF | DS | | C |
| NSFTZ2120FCZ2 | 572 290 2242 | 10- 32 | AP | EQ | | C |
| NSFTZ2121FCZ1 | 572 290 1891 | 11- 7 | AK | EB | | C |
| NSFTZ2122FCZZ | 572 290 1802 | 18- 39 | AL | EB | | C |
| NSFTZ2123FCZZ | 572 290 1803 | 18- 44 | AK | DX | | C |
| NSFTZ2124FCZ1 | 572 290 1892 | 18- 27 | AL | EB | | C |
| NSFTZ2125FCZZ | 572 290 1805 | 18- 46 | AK | DX | | C |
| NSFTZ2126FCZZ | 572 290 1806 | 11- 25 | AN | EG | | C |
| NSFTZ2127FCZZ | 572 290 1807 | 10- 55 | AM | EG | | C |
| NSFTZ2129FCZZ | 572 290 1808 | 17- 33 | AP | EQ | | C |
| NSFTZ2130FCZZ | 572 290 1809 | 17- 21 | AF | DS | | C |
| NSFTZ2131FCZ1 | 572 290 2264 | 6- 1 | AS | EQ | | C |
| NSFTZ2132FCZZ | 572 290 1811 | 7- 3 | AF | DS | | C |
| NSFTZ2133FCZZ | 572 290 1812 | 6- 44 | AH | DX | | C |
| 〃 | 572 290 1812 | 19- 56 | AH | DX | | C |
| NSFTZ2134FCZZ | 572 290 1813 | 8- 31 | AG | DX | | C |
| NSFTZ2183FCZ1 | 572 290 1921 | 21- 11 | AM | EG | | C |
| NSFTZ2186FCZZ | 572 290 1818 | 10- 8 | AF | DS | | C |
| NSFTZ2206FCZZ | 572 290 1819 | 17- 23 | AK | DX | | C |
| NSFTZ2497FCZZ | 572 290 2334 | 13- 13 | AG | DS | N | C |
| NSFTZ2499FCZZ | 572 290 2292 | 1- 23 | AD | DJ | N | C |
| NSRW-0023FCZZ | 572 292 0032 | 14- 49 | AS | EZ | | C |
| 【P】 | | | | | | |
| PBŌX-0086FCZZ | 572 307 0230 | 13- 44 | AN | EQ | | D |
| PBRSR0140FCZ1 | 572 310 0217 | 16- 14 | AH | DX | | B |
| PBRSS0185FCZZ | 572 310 0258 | 19- 81 | AF | DS | | B |
| PBRSS0186FCZZ | 572 310 0259 | 19- 82 | AF | DS | | B |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. Ex. | PRICE R. Ja. | NEW | P/R |
|---|---|---|---|---|---|---|
| PCASZ0271FCZZ | 572 315 0171 | 26- 11 | AH | DX | | C |
| PCLC-0237FCZ1 | 572 316 0271 | 17- 14 | AX | FG | | B |
| PCLC-0250FCZ1 | 572 316 0273 | 19- 12 | AX | FG | | B |
| PCLC-0270FCZZ | 572 316 0300 | 17- 11 | AW | FG | | B |
| PCLR-0230FCZZ | 572 318 0173 | 17- 31 | AD | DJ | | C |
| PCLR-0351FCZZ | 572 318 0130 | 8- 29 | AB | DD | | C |
| PCLR-0367FCZZ | 572 318 0325 | 18- 53 | AC | DD | | C |
| PCLR-0401FCZZ | 572 318 0378 | 17- 12 | AD | DJ | | C |
| 〃 | 572 318 0378 | 18- 17 | AD | DJ | | C |
| PCLR-0402FCZZ | 572 318 0379 | 9- 30 | AE | DJ | | C |
| PCŌVP0911FCZZ | 572 323 0239 | 1- 51 | AB | DD | | C |
| PCŌVP0941FCZZ | 572 323 0253 | 1- 52 | AB | DD | | C |
| PCŌVP1130FCZZ | 572 323 1107 | 25- 4 | AB | DD | | C |
| PCŌVP1184FCZ1 | 572 323 1198 | 14- 59 | AC | DJ | | C |
| PCŌVP1271FCZZ | 572 323 1370 | 1- 8 | AZ | FQ | | D |
| PCŌVP1272FCZ1 | 572 323 1747 | 1- 26 | AH | DX | N | C |
| PCŌVP1273FCZZ | 572 323 1385 | 1- 12 | AM | EG | | D |
| PCŌVP1274FCZ1 | 572 323 1484 | 26- 9 | AC | DJ | | C |
| PCŌVP1275FCZ1 | 572 323 1485 | 26- 6 | AC | DJ | | C |
| PCŌVP1276FCZZ | 572 323 1373 | 6- 18 | AR | EQ | | C |
| PCŌVP1277FCZZ | 572 323 1374 | 7- 13 | AN | EQ | | C |
| PCŌVP1301FCZZ | 572 323 1377 | 10- 39 | AL | EB | | C |
| PCŌVP1327FCZZ | 572 323 1410 | 1- 27 | AF | DS | | C |
| PCŌVP1398FCZZ | 572 323 1581 | 2- 21 | AN | EQ | | C |
| PCŌVP1465FCZZ | 572 323 1743 | 13- 1 | AQ | EQ | N | C |
| PCŌVP1466FCZZ | 572 323 1744 | 13- 11 | AN | EG | N | C |
| PCŌVQ1278FCZZ | 572 323 1379 | 16- 2 | BA | FX | | D |
| PCUSF0319FCZZ | 572 326 0287 | 27- 9 | AE | DJ | | C |
| PCUSF0334FCZZ | 572 326 0296 | 12- 17 | AP | EQ | | C |
| PCUSF0336FCZZ | 572 326 0297 | 3- 13 | AH | DX | | C |
| PCUSF0338FCZZ | 572 326 0300 | 28- 115 | AC | DJ | | C |
| PCUSS0201FCZZ | 572 326 0103 | 9- 8 | AA | DD | | C |
| PCUSS0327FCZZ | 572 326 0293 | 12- 8 | AD | DJ | | C |
| PDUC-0061FCZZ | 572 332 0048 | 7- 28 | AM | EG | | C |
| PDUC-0092FCZZ | 572 332 0097 | 10- 20 | AS | EQ | | C |
| PDUC-0093FCZZ | 572 332 0108 | 19- 61 | AL | EB | | C |
| PFiLD0186FCZZ | 572 337 0169 | 7- 32 | AF | DS | | B |
| PFiLZ0267FCZZ | 572 337 0335 | 19- 63 | AU | EZ | | B |
| PFiLZ0268FCZZ | 572 337 0336 | 10- 19 | AU | EZ | N | B |
| PFTA-0110FCZZ | 572 344 0085 | 6- 27 | AF | DS | | C |
| PGiDH1546FCZZ | 572 345 2297 | 26- 12 | AH | DX | | C |
| PGiDH1548FCZZ | 572 345 2298 | 16- 19 | AG | DX | | C |
| PGiDH1581FCZZ | 572 345 2299 | 21- 4 | AN | EQ | | C |
| PGiDH1718FCZZ | 572 345 2677 | 19- 23 | AM | EG | | C |
| PGiDH1765FCZZ | 572 345 2749 | 16- 35 | AD | DJ | | C |
| PGiDM1268FCZZ | 572 345 1048 | 5- 8 | AC | DJ | | C |
| PGiDM1269FCZZ | 572 345 1049 | 5- 9 | AC | DJ | | C |
| PGiDM1337FCZZ | 572 345 1840 | 1- 20 | AK | EB | | C |
| PGiDM1539FCZZ | 572 345 2257 | 6- 40 | AC | DJ | | C |
| PGiDM1543FCZZ | 572 345 2300 | 10- 51 | AR | EQ | | C |
| PGiDM1547FCZ3 | 572 345 2908 | 26- 1 | AK | DX | | C |
| PGiDM1582FCZ1 | 572 345 3011 | 21- 20 | AV | FG | N | C |
| 〃 | 572 345 3011 | 22- 24 | AV | FG | N | C |
| PGiDM1583FCZZ | 572 345 2338 | 22- 2 | AF | DS | | C |
| PGiDM1584FCZZ | 572 345 2339 | 22- 1 | AF | DS | | C |
| PGiDM1597FCZZ | 572 345 2307 | 26- 14 | AP | EQ | | C |
| PGiDM1602FCZZ | 572 345 2360 | 14- 54 | AG | DX | | C |
| PGiDM1834FCZZ | 572 345 2985 | 13- 17 | AE | DS | N | C |
| PGiDM1834FCZ1 | 572 345 2986 | 13- 17 | AE | DS | N | C |
| PGLSP0072FCZ1 | 572 348 0113 | 7- 14 | AN | EG | | B |
| PGLSP0074FCZ3 | 572 348 0116 | 1- 19 | AZ | FQ | | B |
| PGSK-0012FCZZ | 572 350 0011 | 19- 85 | AG | DX | | C |
| PGUMS0147FCZZ | 572 352 0149 | 6- 29 | AA | DD | | C |
| PGUMS0228FCZZ | 572 352 0197 | 6- 22 | AA | DD | | C |
| PHŌG-0359FCZZ | 572 355 0120 | 20- 14 | AA | DD | | C |
| PHŌG-1023CCZZ | 505 355 5001 | 20- 14 | AB | DD | | C |
| PLNS-0043FCZ1 | 572 372 0064 | 8- 1 | BK | HL | | C |
| PMAGT0015FCZZ | 572 373 0029 | 1- 9 | AD | DJ | | B |
| PMiR-0076FCZZ | 572 374 0070 | 12- 11 | AP | EQ | | B |
| PMiR-0127FCZZ | 572 374 0150 | 7- 18 | AT | EZ | | B |
| PMiR-0128FCZZ | 572 374 0151 | 9- 4 | AU | EZ | | B |
| PMiR-0129FCZZ | 572 374 0152 | 9- 5 | AY | FQ | | B |
| PMiR-0130FCZZ | 572 374 0153 | 9- 28 | AW | FG | | B |
| PMiR-0131FCZZ | 572 374 0154 | 9- 27 | AS | EQ | | B |
| PMLT-0834FCZZ | 572 375 0331 | 13- 4 | AB | DD | | C |
| PMLT-0835FCZZ | 572 375 0332 | 13- 8 | AA | DD | | C |
| PMLT-0836FCZZ | 572 375 0333 | 13- 7 | AB | DD | | C |
| PMLT-0984FCZ1 | 572 375 0698 | 14- 46 | AF | DS | | C |
| PMLT-0985FCZ1 | 572 375 0699 | 14- 45 | AF | DS | | C |
| PMLT-0991FCZZ | 572 375 0689 | 14- 73 | AA | DJ | | C |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. Ex. | PRICE R. Ja. | NEW | P/R |
|---|---|---|---|---|---|---|
| PMLT-0995FCZZ | 572 375 0690 | 19- 60 | AC | DJ | | C |
| PMLT-0999FCZZ | 572 375 0681 | 14- 44 | AC | DJ | | C |
| PMLT-1001FCZZ | 572 375 0695 | 17- 42 | AC | DJ | | C |
| PMLT-1005FCZZ | 572 375 0700 | 14- 84 | AC | DJ | | C |
| PMLT-1012FCZZ | 572 375 0697 | 14- 75 | AA | DJ | | C |
| PMLT-1023FCZZ | 572 375 0709 | 13- 47 | AB | DJ | | C |
| PMLT-1025FCZZ | 572 375 0707 | 14- 77 | AE | DS | | C |
| PMLT-1026FCZZ | 572 375 0708 | 14- 78 | AF | DS | | C |
| PMLT-1153FCZZ | 572 375 0835 | 19- 83 | AC | DJ | | C |
| PPiPP0109FCZZ | 572 395 0039 | 21- 35 | AB | DD | | C |
| PPiPP0124FCZZ | 572 395 0026 | 21- 39 | AB | DD | | C |
| PRDAR0066FCZZ | 572 397 0154 | 33- 2 | AH | DX | | C |
| PRDAR0069FCZZ | 572 397 0157 | 29- 1 | AG | DX | | C |
| PRDAR0078FCZZ | 572 397 0170 | 34- 3 | AK | EB | | C |
| PRDAR0079FCZZ | 572 397 0171 | 34- 4 | AL | EB | | C |
| PRDAR0080FCZZ | 572 397 0172 | 34- 5 | AK | DX | | C |
| PREFL0145FCZZ | 572 134 0252 | 12- 2 | AT | FG | | C |
| PRNGP0019FCZZ | 572 399 0026 | 15- 11 | AA | DD | | C |
| PRNGP0025FCZZ | 572 399 0036 | 6- 13 | AA | DD | | C |
| 〃 | 572 399 0036 | 14- 38 | AA | DD | | C |
| PRNGP0026FCZZ | 578 399 0001 | 14- 66 | AA | DD | | C |
| PRNGP0034FCZZ | 572 399 0007 | 10- 27 | AA | DD | | C |
| PRNGP0040FCZZ | 572 399 0011 | 1- 29 | AA | DD | | C |
| PRNGP0049FCZZ | 572 399 0019 | 11- 15 | AA | DD | | C |
| PRNGP0050FCZZ | 572 399 0021 | 15- 8 | AE | DS | | C |
| PRNGP0081FCZZ | 572 399 0178 | 21- 10 | AA | DJ | | C |
| PSEL-0432FCZZ | 572 400 0226 | 13- 42 | AA | DD | | C |
| PSEL-0433FCZZ | 572 400 0227 | 13- 41 | AB | DD | | C |
| PSEL-0443FCZZ | 572 400 0246 | 15- 9 | AA | DD | | C |
| PSEL-0446FCZZ | 572 400 0248 | 13- 3 | AA | DD | | C |
| PSEL-0652FCZZ | 572 400 0484 | 15- 24 | AC | DJ | | C |
| PSEL-0660FCZZ | 572 400 0483 | 13- 10 | AG | DX | | C |
| PSEL-0669FCZZ | 572 400 0498 | 10- 61 | AD | DJ | | C |
| PSEL-0670FCZZ | 572 400 0494 | 15- 35 | AC | DJ | | C |
| PSEL-0675FCZZ | 572 400 0496 | 15- 23 | AC | DJ | | C |
| PSEL-0676FCZZ | 572 400 0497 | 15- 22 | AC | DJ | | C |
| PSHEG2817FCZ1 | 572 403 0096 | 8- 2 | AC | DJ | | C |
| PSHEG3831FCZ1 | 572 403 4116 | 18- 14 | AF | DS | | C |
| PSHEP2335FCZZ | 572 403 0485 | 8- 5 | AA | DD | | C |
| PSHEP2348FCZZ | 572 403 1821 | 17- 2 | AB | DD | | C |
| 〃 | 572 403 1821 | 19- 6 | AB | DD | | C |
| PSHEP2713FCZZ | 572 403 1038 | 15- 32 | AC | DD | | C |
| PSHEP2751FCZZ | 572 403 1692 | 8- 6 | AC | DD | | C |
| PSHEP2917FCZZ | 572 403 1533 | 13- 43 | AB | DD | | C |
| PSHEP3223FCZZ | 572 403 2524 | 29- 2 | AB | DD | | C |
| PSHEP3741FCZZ | 572 403 3274 | 10- 60 | AF | DS | | C |
| PSHEP3747FCZZ | 572 403 3277 | 7- 11 | AE | DJ | | C |
| PSHEP3824FCZZ | 572 403 3280 | 14- 2 | AF | DS | | C |
| PSHEP3827FCZZ | 572 403 3346 | 19- 70 | AE | DJ | | C |
| PSHEP3832FCZZ | 572 403 3282 | 26- 13 | AE | DS | | C |
| PSHEP3903FCZZ | 572 403 3347 | 21- 23 | AC | DJ | | C |
| PSHEP3904FCZZ | 572 403 3348 | 21- 25 | AC | DJ | | C |
| PSHEP3905FCZZ | 572 403 3349 | 21- 48 | AE | DS | | C |
| PSHEP3906FCZZ | 572 403 3350 | 17- 41 | AD | DJ | | C |
| PSHEP3907FCZZ | 572 403 3382 | 6- 56 | AD | DJ | | C |
| PSHEP3929FCZZ | 572 403 3366 | 14- 68 | AD | DJ | | C |
| PSHEP3930FCZ1 | 572 403 3432 | 14- 72 | AD | DJ | | C |
| PSHEP3931FCZZ | 572 403 3368 | 14- 74 | AD | DJ | | C |
| PSHEP3953FCZZ | 572 403 3383 | 20- 35 | AD | DJ | | C |
| PSHEP3955FCZZ | 572 403 3423 | 13- 27 | AD | DJ | | C |
| PSHEP3958FCZZ | 572 403 3385 | 13- 45 | AD | DJ | | C |
| PSHEP4019FCZZ | 572 403 3401 | 14- 79 | AC | DJ | | C |
| PSHEP4026FCZ1 | 572 403 4097 | 22- 26 | AC | DJ | | C |
| PSHEP4047FCZZ | 572 403 3558 | 20- 38 | AD | DJ | | C |
| PSHEP4058FCZZ | 572 403 3504 | 8- 43 | AC | DJ | | C |
| PSHEP4059FCZZ | 572 403 3505 | 8- 7 | AK | EB | | C |
| PSHEP4067FCZZ | 572 403 3506 | 8- 42 | AD | DJ | | C |
| PSHEP4068FCZ1 | 572 403 3640 | 10- 64 | AE | DJ | | C |
| PSHEP4109FCZZ | 572 403 3560 | 20- 39 | AD | DJ | | C |
| PSHEP4115FCZZ | 572 403 3610 | 17- 45 | AD | DJ | | C |
| PSHEP4116FCZZ | 572 403 3579 | 19- 48 | AF | DS | | C |
| PSHEP4345FCZZ | 572 403 3864 | 21- 52 | AC | DJ | | C |
| PSHEP4400FCZZ | 572 403 3923 | 16- 37 | AD | DJ | | C |
| PSHEP4404FCZZ | 572 403 4043 | 34- 33 | AE | DS | | C |
| PSHEP4456FCZZ | 572 403 3975 | 19- 84 | AD | DJ | | C |
| PSHEP4569FCZZ | 572 403 4152 | 13- 12 | AC | DJ | N | C |
| PSHEP4593FCZZ | 572 403 4177 | 7- 40 | AF | DS | N | C |
| PSHEP4594FCZZ | 572 403 4171 | 19- 36 | AD | DJ | N | C |
| PSHEP4595FCZZ | 572 403 4172 | 19- 37 | AD | DJ | N | C |
| PSHEZ0287FCZZ | 572 403 2286 | 28- 127 | AG | DS | | D |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. Ex. | PRICE R. Ja. | NEW | P/R |
|---|---|---|---|---|---|---|
| PSHEZ1760FCZZ | 572 403 1764 | 5- 6 | AB | DD | | C |
| 〃 | 572 403 1764 | 22- 10 | AB | DD | | C |
| PSHEZ2714FCZZ | 572 403 1432 | 3- 1 | AT | FG | | D |
| PSHEZ2715FCZZ | 572 403 1433 | 3- 25 | AU | FQ | | D |
| PSHEZ3777FCZZ | 572 403 3351 | 33- 3 | AD | DJ | | C |
| PSHEZ3899FCZ1 | 572 403 3424 | 14- 69 | AC | DJ | | C |
| PSHEZ3908FCZZ | 572 403 3436 | 20- 33 | AF | DS | | C |
| PSHEZ3909FCZZ | 572 403 3373 | 11- 55 | AE | DS | | C |
| PSHEZ3910FCZZ | 572 403 3439 | 15- 2 | AB | DJ | | C |
| PSHEZ3945FCZZ | 572 403 3402 | 21- 24 | AD | DJ | | C |
| PSHEZ4015FCZZ | 572 403 3429 | 14- 13 | AC | DJ | | C |
| PSHEZ4024FCZZ | 572 403 3459 | 28- 11 | AE | DS | | D |
| PSHEZ4137FCZZ | 572 403 3583 | 28- 116 | AC | DJ | | D |
| PSHEZ4203FCZZ | 572 403 3867 | 2- 2 | AK | EB | | D |
| PSHEZ4204FCZZ | 572 403 3844 | 2- 2 | AK | EB | | D |
| PSHEZ4364FCZZ | 572 403 4154 | 2- 2 | AK | EB | N | D |
| PSHEZ4449FCZZ | 572 403 3977 | 16- 36 | AC | DJ | | C |
| PSHEZ4460FCZZ | 572 403 4051 | 18- 58 | AC | DJ | | C |
| PSHEZ4461FCZZ | 572 403 4052 | 18- 59 | AC | DJ | | C |
| PSHEZ4462FCZZ | 572 403 4053 | 18- 60 | AD | DJ | | C |
| PSPAZ0363FCZZ | 572 413 0286 | 18- 35 | AA | DD | | C |
| PSPAZ0674FCZZ | 572 413 0573 | 26- 15 | AC | DJ | | C |
| PSPAZ0679FCZZ | 572 413 0577 | 21- 50 | AC | DJ | | C |
| PSPAZ0695FCZZ | 572 413 0598 | 19- 76 | AC | DJ | | C |
| PSPAZ1393FCZZ | 572 413 0630 | 1- 36 | AC | DJ | | C |
| PSTK-0015FCZZ | 572 416 0055 | 3- 6 | AQ | EZ | | C |
| PTME-0168FCZZ | 572 420 0174 | 16- 16 | AF | DX | | S |
| PTME-0211FCZ1 | 572 420 0240 | 14- 62 | AG | DX | | C |
| PTME-0244FCZZ | 572 420 0258 | 19- 21 | AG | DX | | C |
| PTME-0270FCZZ | 572 420 0290 | 13- 16 | AE | DS | N | C |
| PTPE-0217FCZZ | 572 423 0178 | 20- 40 | AC | DJ | | C |
| PTPE-0226FCZZ | 572 423 0184 | 1- 35 | AC | DJ | | C |
| PTUBG0100FCZZ | 572 424 0043 | 16- 28 | AC | DD | | C |
| PWiR-0173FCZZ | 572 427 1605 | 6- 8 | AS | EQ | | C |
| PWiR-0174FCZZ | 572 427 1606 | 8- 9 | AU | EZ | | C |
| PWiR-0176FCZZ | 572 427 1610 | 16- 30 | AP | EQ | | C |
| 【Q】 | | | | | | |
| QACCD7419QCZZ | 572 500 0079 | 20- 14 | AS | EQ | | B |
| QACCE7422QCZZ | 572 500 0080 | 20- 14 | BB | GD | | B |
| QACCJ1415QCZZ | 572 500 0074 | 20- 14 | AS | EZ | | B |
| QACCL8421QCZZ | 572 500 0019 | 20- 14 | AW | FX | | B |
| QACCV6420QCN2 | 572 500 0060 | 20- 14 | AU | FQ | | B |
| QCNCM0445FCZZ | 572 510 0820 | 33- 4 | AC | DJ | | C |
| QCNCM0672FCZZ | 595 510 0041 | 33- 5 | AB | DD | | C |
| 〃 | 595 510 0041 | 35- 1 | AB | DD | | C |
| QCNCM0877FCZZ | 572 510 0842 | 29- 3 | AF | DS | | C |
| QCNCM0878FCZZ | 572 510 0822 | 29- 4 | AF | DS | | C |
| QCNCM0879FCZZ | 572 510 0823 | 29- 5 | AF | DS | | C |
| QCNCM0882FCZZ | 572 510 0843 | 33- 6 | AD | DJ | | C |
| QCNCM0883FCZZ | 572 510 0844 | 33- 5 | AD | DJ | | C |
| QCNCM1005MCZZ | 589 510 0004 | 35- 2 | AB | DD | | C |
| QCNCM1069AC0D | 569 510 0002 | 34- 34 | AC | DD | | C |
| QCNCM7014SC0C | 595 510 0338 | 35- 3 | AA | DD | | C |
| QCNCM7014SC0D | 595 510 0345 | 29- 6 | AB | DD | | C |
| 〃 | 595 510 0345 | 33- 7 | AB | DD | | C |
| QCNCW0378FCZZ | 572 510 0068 | 34- 6 | AD | DJ | | C |
| QCNCW0690FCZZ | 572 510 0090 | 33- 8 | AB | DD | | C |
| QCNCW0892FCZZ | 572 510 0829 | 30- 2 | AD | DJ | | C |
| QCNCW0893FCZZ | 572 510 0830 | 30- 3 | AE | DS | | C |
| QCNCW0903FCZZ | 572 510 0861 | 34- 6 | AF | DS | | C |
| QCNW-0001QCZZ | 572 512 0055 | 20- 14 | AN | EQ | | B |
| QCNW-0069FCZZ | 572 512 0048 | 20- 14 | AC | DD | | C |
| QFS-A2700QCZZ | 571 515 0003 | 33- 9 | AD | DJ | | A |
| QFS-B0030FCZZ | 572 515 0062 | 33- 9 | AH | DS | | A |
| QFS-C1500QCZZ | 572 515 0120 | 33- 9 | AF | DS | | A |
| QFS-D0331QCZZ | 572 515 0369 | 33- 10 | AD | DJ | | A |
| 〃 | 572 515 0369 | 34- 7 | AD | DJ | | A |
| QFS-D0334QCZZ | 572 515 0395 | 29- 7 | AE | DJ | | A |
| 〃 | 572 515 0395 | 34- 8 | AE | DJ | | A |
| 〃 | 572 515 0395 | 35- 4 | AE | DJ | | A |
| QFS-D0431QCZZ | 572 515 0396 | 34- 9 | AE | DJ | | A |
| QFS-D1326QCZZ | 572 515 0360 | 33- 10 | AD | DS | | A |
| 〃 | 572 515 0360 | 34- 7 | AD | DS | | A |
| QFS-D1328QCZZ | 572 515 0398 | 29- 7 | AE | DS | | A |
| 〃 | 572 515 0398 | 34- 8 | AE | DS | | A |
| 〃 | 572 515 0398 | 35- 4 | AE | DS | | A |
| QFS-D1423QCZZ | 572 515 0399 | 34- 9 | AE | DS | | A |
| QFS-D2002WCZZ | 572 515 0115 | 33- 11 | AB | DD | | A |
| QFSHA0025FCZZ | 572 516 0047 | 29- 8 | AA | DJ | | C |
| 〃 | 572 516 0047 | 33- 12 | AA | DJ | | C |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. Ex. | PRICE R. Ja. | NEW | P/R |
|---|---|---|---|---|---|---|
| QFSHA0025FCZZ | 572 516 0047 | 34- 10 | AA | DJ | | C |
| QFSHB0001GCZZ | 578 516 0006 | 35- 5 | AB | DJ | | C |
| QFSHB0024FCZZ | 572 516 0044 | 34- 10 | AB | DJ | | C |
| QFSHD0001QCZZ | 572 516 0006 | 33- 13 | AA | DD | | C |
| QPiN-0009FCZZ | 572 523 0026 | 35- 6 | AC | DJ | | C |
| QPLGA4171CCZZ | 571 524 0009 | 20- 14 | AN | EG | | B |
| QSLP-0157FCZZ | 572 520 0108 | 25- 7 | AE | DS | | C |
| QSLP-0158FCZ1 | 572 537 0005 | 25- 3 | AE | DS | | C |
| QSŌCZ2051SC32 | 595 527 0012 | 29- 9 | AC | DJ | | C |
| QSŌCZ6408ACZZ | 578 527 0004 | 29- 10 | AB | DD | | C |
| QSW-C9170QCZZ | 572 530 0306 | 10- 14 | AK | EB | | B |
| QSW-M0296FCZZ | 572 530 0234 | 10- 15 | AM | EG | | B |
| QSW-M0431FCZZ | 572 530 0150 | 18- 54 | AF | DS | | B |
| QSW-P0465FCZZ | 572 530 0525 | 30- 4 | AC | DJ | | B |
| QSW-P0469FCZZ | 572 530 0536 | 30- 5 | AD | DS | | B |
| QSW-W9030QSZZ | 572 530 0581 | 11- 18 | AV | FG | | B |
| QTANN0015FCZZ | 572 532 0016 | 20- 12 | AG | DS | | C |
| QTANP0088FCZZ | 572 532 0023 | 20- 14 | AA | DD | | C |
| QTANP0115FCZZ | 572 532 0041 | 33- 14 | AB | DD | | C |
| QTANP0176FCZZ | 572 532 0122 | 20- 14 | AB | DD | | C |
| 【R】 | | | | | | |
| RC-AZ0358FCZZ | 572 591 0017 | 29- 11 | AE | DS | | B |
| RC-KZ472ANC3A | 585 593 0027 | 33- 15 | AD | DJ | | C |
| RCiLF0043FCZ1 | 572 614 0177 | 33- 16 | AL | EG | | C |
| RCiLF0045FCZZ | 572 614 0042 | 20- 15 | AN | EQ | | C |
| RCiLF0048FCZZ | 572 614 0015 | 33- 16 | AG | DS | | C |
| RCiLF0082FCZZ | 572 614 0212 | 33- 42 | AP | EQ | | C |
| RCŌRF0026FCZZ | 572 615 0040 | 6- 61 | AL | EB | | C |
| RCŌRF6661RCZZ | 579 615 0020 | 11- 56 | AK | EB | N | C |
| RCRM-0001FCZZ | 572 616 0044 | 29- 12 | AD | DJ | | B |
| RDTCT0116FCZZ | 572 618 0105 | 16- 8 | AR | EQ | | B |
| RDTCT0117FCZ1 | 572 618 0129 | 15- 30 | AY | FQ | N | B |
| RH-DZ0016FCZZ | 572 570 0001 | 29- 13 | AB | DD | | B |
| RH-DZ0019FCZZ | 572 570 0002 | 33- 17 | AG | DX | | B |
| RLMPU0494FCZ1 | 572 626 0472 | 12- 3 | BC | GN | | B |
| RLMPU0495FCZ1 | 572 626 0473 | 12- 3 | BC | GN | | B |
| RLMPU0546FCZZ | 572 626 0476 | 16- 27 | BD | GJ | | B |
| RLMPU0547FCZZ | 572 626 0477 | 16- 27 | BD | GJ | | B |
| RLMPU0548FCZZ | 572 626 0478 | 16- 27 | BD | GJ | | B |
| RLMPU0551FCZZ | 572 626 0480 | 16- 27 | BD | GJ | | B |
| RLMPU0552FCZZ | 572 626 0481 | 16- 27 | BD | GJ | | B |
| RLMPU0553FCZZ | 572 626 0482 | 16- 27 | BD | GJ | | B |
| RMŌTD0619FCZZ | 572 630 0160 | 11- 29 | AR | EZ | | B |
| RMŌTE0700FCZZ | 572 630 0687 | 19- 62 | AX | FX | | B |
| RMŌTN0765FCZZ | 572 630 0780 | 18- 13 | BL | HL | | B |
| RMŌTN0768FCZZ | 572 630 0781 | 6- 20 | AZ | FQ | | B |
| RMŌTP0764FCZZ | 572 630 0782 | 10- 18 | AZ | FQ | | B |
| RMŌTP0766FCZ1 | 572 630 0930 | 8- 18 | AX | FG | N | B |
| RMPTA0031FCZZ | 572 631 0002 | 33- 18 | AE | DJ | | B |
| RMPTC4103QCJB | 541 631 5008 | 29- 14 | AD | DJ | | B |
| RMPTC5102QCJB | 596 631 0048 | 29- 15 | AB | DD | | B |
| RMPTC5103QCJB | 572 631 0025 | 29- 16 | AD | DJ | | B |
| RMPTC6223QCJB | 571 631 0096 | 29- 17 | AB | DD | | B |
| RMPTC6272QCJB | 572 631 0057 | 29- 18 | AC | DD | | B |
| RMPTC8103QCJB | 585 631 0061 | 29- 19 | AC | DD | | B |
| RPLU-0279FCZZ | 572 647 0216 | 21- 32 | AN | EG | | B |
| RPLU-0304FCZZ | 572 647 0257 | 18- 10 | AN | EQ | | B |
| RR-NZ0442FCZZ | 572 580 0635 | 33- 35 | AB | DD | | C |
| RR-WZ0328FCZZ | 572 580 0367 | 33- 19 | AD | DJ | | C |
| RR-XZ0337FCZZ | 572 580 0362 | 33- 20 | AC | DJ | | B |
| RR-XZ0338FCZZ | 572 580 0363 | 33- 20 | AC | DJ | | B |
| RRLYD3202QCZZ | 572 637 0147 | 33- 21 | AN | EG | | B |
| RRLYD3222QCZZ | 572 637 0139 | 35- 7 | AL | EB | | B |
| RRLYJ3100QCZZ | 572 637 0141 | 33- 21 | AN | EQ | | B |
| RTHM-0009FCZZ | 572 644 0002 | 16- 6 | AK | EB | | B |
| RTHM-0014FCZZ | 572 644 0009 | 16- 6 | AM | EG | | B |
| RTRNP0536FCZZ | 572 654 0286 | 20- 16 | BD | GN | N | B |
| RTRNP0537FCZZ | 572 654 0287 | 20- 16 | BE | GN | N | B |
| RTRNP0538FCZZ | 572 654 0288 | 20- 16 | BD | GN | N | B |
| RTRNP0540FCZZ | 572 654 0289 | 20- 16 | BD | GN | N | B |
| RTRNP0541FCZZ | 572 654 0290 | 20- 16 | BE | GN | N | B |
| RTRNP0542FCZZ | 572 654 0291 | 20- 16 | BF | GN | | B |
| RTRNZ0529FCZZ | 572 660 0396 | 35- 8 | AT | EZ | | B |
| RTRNZ0530FCZZ | 572 660 0397 | 35- 8 | AT | EZ | | B |
| RTRNZ0535FCZZ | 572 660 0409 | 11- 45 | BS | MJ | N | B |
| 【S】 | | | | | | |
| SPAKA4693FCZZ | 572 902 0929 | 28- 105 | AE | DS | | D |
| SPAKA5315FCZZ | 572 902 1107 | 28- 8 | AL | EB | | D |
| SPAKA5316FCZZ | 572 902 1108 | 28- 9 | AG | DX | | D |
| SPAKA5317FCZZ | 572 902 1109 | 28- 8 | AF | DS | | D |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. Ex. | PRICE R. Ja. | NEW | P/R |
|---|---|---|---|---|---|---|
| SPAKA5318FCZZ | 572 902 1110 | 28- 9 | AD | DJ | | D |
| SPAKA5377FCZZ | 572 902 1145 | 28- 117 | AE | DJ | | D |
| SPAKA5524FCZZ | 572 902 1239 | 28- 2 | AT | EZ | | D |
| SPAKA5559FCZZ | 572 902 1243 | 28- 12 | AR | EQ | | D |
| SPAKA5626FCZZ | 572 902 1254 | 28- 1 | AE | DS | | D |
| SPAKC5770FCZZ | 572 901 1317 | 28- 6 | BB | FX | N | D |
| SPAKC5770FC11 | 572 901 1318 | 28- 6 | BB | FX | N | D |
| SPAKC5770FC12 | 572 901 1319 | 28- 6 | BB | FX | N | D |
| SPAKC5770FC17 | 572 901 1323 | 28- 6 | BB | FX | N | D |
| SPAKC5771FCZZ | 572 901 1326 | 28- 6 | BB | FX | N | D |
| SSAKA2440QCZZ | 595 906 0005 | 28- 109 | AB | DD | | D |
| SSAKA3001CCZZ | 502 906 0002 | 28- 10 | AA | DD | | D |
| 【T】 | | | | | | |
| TCADS0649FCZZ | 572 913 0534 | 28- 112 | AM | EG | | D |
| TCADS0764FCZZ | 577 913 0005 | 28- 110 | AE | DJ | | D |
| TCADZ1159FCZZ | 572 913 0632 | 28- 119 | AA | DJ | | D |
| TCADZ1178FCZZ | 572 913 0651 | 28- 106 | AB | DJ | | D |
| TCADZ1300FCZZ | 572 913 0752 | 28- 114 | AB | DJ | | D |
| TCADZ1308FCZZ | 572 913 0771 | 28- 112 | AF | DS | N | D |
| TCADZ1340FCZZ | 572 913 0818 | 28- 112 | AF | DS | N | D |
| TCADZ1341FCZZ | 572 913 0809 | 28- 113 | AF | DS | N | D |
| TCADZ1352FCZZ | 572 913 0819 | 28- 123 | AK | DX | N | D |
| TCADZ1353FCZZ | 572 913 0816 | 28- 123 | AF | DS | N | D |
| TCADZ1354FCZZ | 572 913 0817 | 28- 123 | AF | DS | N | D |
| TCADZ2001QCZA | 579 913 0089 | 28- 112 | AE | DS | | D |
| TCAUA0766FCZZ | 572 914 0012 | 1- 13 | AB | DD | | C |
| TCAUA0770FCZZ | 572 914 0035 | 1- 13 | AB | DD | | C |
| TCAUH0819FCZZ | 572 914 0575 | 14- 83 | AA | DD | | C |
| TCAUH0821FCZZ | 572 914 0577 | 14- 83 | AA | DD | | C |
| TCAUH0918FCZZ | 572 914 0078 | 1- 13 | AA | DD | | C |
| TCAUH0974FCZZ | 572 914 0608 | 14- 83 | AB | DJ | | C |
| TCAUH0999FCZZ | 572 914 0630 | 16- 3 | AE | DJ | | C |
| TCAUH1000FCZZ | 572 914 0631 | 16- 3 | AE | DJ | | C |
| TCAUH1001FCZZ | 572 914 0638 | 6- 60 | AF | DS | | C |
| TCAUH1002FCZZ | 572 914 0634 | 6- 60 | AH | DX | | C |
| TCAUH1018FCZZ | 572 914 0652 | 16- 3 | AG | DX | | C |
| TCAUH1028FCZZ | 572 914 0653 | 1- 13 | AC | DJ | | C |
| TCAUH1039FCZZ | 572 914 0665 | 14- 83 | AC | DJ | | C |
| TiNSE1645FCZZ | 572 916 1420 | 28- 7 | AQ | EQ | N | D |
| TiNSE1646FCZZ | 572 916 1421 | 28- 7 | AX | FG | N | D |
| TiNSE1647FCZZ | 572 916 1422 | 28- 7 | AT | EZ | N | D |
| TiNSE1658FCZZ | 572 916 1426 | 28- 7 | AU | EZ | N | D |
| TiNSF1648FCZZ | 572 916 1423 | 28- 7 | AZ | FX | N | D |
| TiNSJ1649FCZZ | 572 916 1428 | 28- 7 | AY | ZZ | N | D |
| TiNSR1650FCZZ | | 28- 7 | | | N | D |
| TLABH3709FCZZ | 572 917 2841 | 1- 24 | AC | DJ | | C |
| TLABH3805FCZZ | 572 917 2919 | 6- 59 | AF | DS | | C |
| TLABH4082FCZZ | 572 917 3106 | 3- 12 | AD | DJ | | C |
| TLABH4083FCZZ | 572 917 3107 | 1- 38 | AD | DJ | | C |
| TLABH4084FCZZ | 572 917 3108 | 1- 38 | AE | DJ | | C |
| TLABZ2811FCZZ | 572 917 1175 | 1- 22 | AB | DD | | C |
| TLABZ3733FCZ1 | 572 917 3168 | 5- 11 | AF | DS | | C |
| TLABZ3757FCZZ | 572 917 2845 | 22- 4 | AK | DX | | C |
| TLABZ3759FCZZ | 572 917 2847 | 22- 4 | AK | DX | | C |
| TLABZ3903FCZZ | 572 917 2991 | 1- 37 | AF | DS | | C |
| TLABZ3996FCZZ | 572 917 3061 | 28- 120 | AD | DJ | | C |
| TLABZ4011FCZZ | 572 917 3063 | 22- 4 | AE | DS | | C |
| TLABZ4012FCZZ | 572 917 3064 | 28- 121 | AD | DJ | | C |
| TLABZ4014FCZZ | 572 917 3066 | 28- 122 | AD | DJ | | C |
| 【U】 | | | | | | |
| UCLEZ0108FCZ1 | 572 704 0015 | 14- 27 | AV | FG | | C |
| 【V】 | | | | | | |
| VCEAAL1HC822M | 572 594 0623 | 34- 11 | AK | EB | | C |
| VCEAEW1EC152M | 572 594 0624 | 34- 12 | AF | DS | | C |
| VCEAEW1EC222M | 572 594 0625 | 34- 13 | AF | DS | | C |
| VCEAGA1AW107M | 585 594 0057 | 34- 14 | AB | DD | | C |
| VCEAGA1AW477M | 541 591 5323 | 29- 21 | AB | DD | | C |
| VCEAGA1HW224M | 501 591 5002 | 29- 23 | AA | DD | | C |
| VCEAGA1VW106M | 572 594 0093 | 29- 25 | AA | DD | | C |
| VCEAGU1AW476M | 507 591 5008 | 29- 20 | AA | DD | | C |
| VCEAGU1CW476M | 541 591 5063 | 34- 15 | AB | DD | | C |
| VCEAGU1CW477M | 579 594 0079 | 29- 26 | AC | DD | | C |
| VCEAGU1EW476M | 571 594 0230 | 34- 16 | AB | DD | | C |
| VCEAGU1HW105M | 541 591 5065 | 29- 22 | AA | DD | | C |
| VCEAGU1HW476M | 579 594 0059 | 29- 24 | AB | DD | | C |
| VCEAGU1VW107M | 579 594 0049 | 33- 22 | AB | DD | | C |
| VCEAGU1VW476M | 579 594 0046 | 34- 17 | AB | DD | | C |
| VCEAGU1VW477M | 585 594 0061 | 29- 27 | AD | DJ | | C |
| VCEAJU1CW476M | 596 594 0062 | 30- 6 | AB | DD | | C |
| VCFYEG2EA224M | 572 590 0008 | 33- 23 | AE | DS | | C |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. Ex. | PRICE R. Ja. | NEW | P/R |
|---|---|---|---|---|---|---|
| VCKYPU1HB331K | 502 595 0004 | 30- 7 | AA | DD | | C |
| VCKYPU1HF223Z | 500 595 0046 | 30- 8 | AA | DD | | C |
| 〃 | 500 595 0046 | 34- 18 | AA | DD | | C |
| VCKYTQ1HB102K | 505 591 5021 | 29- 28 | AA | DD | | C |
| VCKYTQ1HB222K | 596 593 0117 | 29- 29 | AA | DD | | C |
| VCKYTQ1HB223K | 572 593 0191 | 29- 30 | AB | DD | | C |
| VCKYTQ1HB471K | 594 593 0206 | 29- 31 | AB | DD | | C |
| VCQYNU1HM103K | 507 591 5016 | 29- 32 | AA | DD | | C |
| VCQYNU1HM104K | 505 591 5015 | 29- 33 | AB | DD | | C |
| 〃 | 505 591 5015 | 33- 24 | AB | DD | | C |
| VCQYNU1HM223K | 595 596 0107 | 33- 25 | AA | DD | | C |
| VCQYNU1HM224K | 592 596 0011 | 29- 34 | AC | DD | | C |
| VCQYNU1HM473K | 505 591 5016 | 33- 25 | AB | DD | | C |
| VCQYNU1HM474K | 577 596 0003 | 33- 26 | AD | DJ | | C |
| VHDDAN202K/-1 | 500 570 5005 | 29- 35 | AB | DD | | B |
| VHDDAP202K/-1 | 500 570 0037 | 29- 36 | AB | DD | | B |
| VHDDSM1D1//-U | 572 570 0383 | 29- 37 | AB | DJ | | B |
| VHDDSS131//-1 | 579 570 0029 | 34- 19 | AA | DD | | B |
| VHDDSS133//-1 | 500 570 5006 | 29- 38 | AA | DD | | B |
| 〃 | 500 570 5006 | 30- 9 | AA | DD | | B |
| 〃 | 500 570 5006 | 35- 9 | AA | DD | | B |
| VHDD1N60///-1 | 572 570 0414 | 33- 27 | AC | DJ | | B |
| VHDD10SC6MR-1 | 572 570 0412 | 34- 20 | AL | EB | | B |
| VHDD3SBA60/-1 | 572 570 0410 | 34- 21 | AG | DX | | B |
| VHDD4SBS6//-1 | 572 570 0459 | 34- 21 | AN | EG | | B |
| VHDRU3M////-1 | 588 570 0010 | 29- 39 | AC | DD | | B |
| 〃 | 588 570 0010 | 34- 22 | AC | DD | | B |
| VHDSF10SC6/-1 | 572 570 0413 | 34- 23 | AK | DX | | B |
| VHDS1WBA60S-1 | 572 570 0030 | 33- 28 | AD | DJ | | B |
| 〃 | 572 570 0030 | 35- 10 | AD | DJ | | B |
| VHEHZS5B3//-1 | 572 571 0157 | 29- 40 | AB | DJ | | B |
| VHEMTZJ10A/-1 | 572 571 0178 | 34- 24 | AC | DJ | | B |
| VHEMTZJ10D/-1 | 594 571 0125 | 34- 35 | AB | DJ | | B |
| VHERD13EB1/-1 | 571 571 0054 | 34- 25 | AB | DD | | B |
| VHERD18EL3/-1 | 571 571 0056 | 29- 41 | AB | DD | | B |
| VHERD22FB//-1 | 500 571 0074 | 29- 42 | AD | DJ | | B |
| VHiHS4602//-1 | 572 573 1222 | 33- 29 | AT | EZ | | B |
| VHiH83041K12F | 572 573 1205 | 29- 43 | BB | GD | | B |
| VHiLM324N//-1 | 541 573 1182 | 29- 44 | AK | EG | | B |
| VHiM51953BL-1 | 588 573 0032 | 29- 45 | AF | DS | | B |
| VHiM66313FP-1 | 572 573 0047 | 30- 10 | AN | EQ | | B |
| VHiNJM2901N-1 | 541 573 1174 | 29- 46 | AK | EB | | B |
| VHiPQ05RF2/-1 | 572 573 1224 | 34- 26 | AK | EB | | B |
| VHiSLA7024MT/ | 572 573 1217 | 29- 47 | AS | EQ | | B |
| VHiSN74HC151N | 572 573 1286 | 29- 48 | AG | DX | | B |
| VHiSN74HC373S | 595 573 1129 | 29- 49 | AG | DS | | B |
| VHiSN74LS138N | 502 573 0007 | 29- 50 | AG | EQ | | B |
| VHiST25C04FB6 | 572 573 1500 | 29- 51 | AM | EG | | B |
| VHiTA7291S/-1 | 572 573 0188 | 29- 52 | AF | DS | | B |
| VHiTD62504/-1 | 572 573 0133 | 29- 53 | AG | DX | | B |
| VHiULN2004AN1 | 572 573 0899 | 29- 54 | AE | DS | | B |
| VHi27C010D3FC | 572 573 1697 | 29- 55 | AX | FG | N | B |
| VHi74F02SJ/-1 | 541 573 5403 | 29- 56 | AF | DS | | B |
| VHi74HC04//-1 | 572 573 1218 | 29- 57 | AE | DJ | | B |
| VHi74HC139/-1 | 595 573 3199 | 29- 58 | AG | DX | | B |
| VHPGP1A22LC-1 | 572 574 0100 | 7- 26 | AK | EB | | B |
| 〃 | 572 574 0100 | 18- 49 | AK | EB | | B |
| VHPLB603MF/-1 | 572 574 0262 | 30- 11 | AQ | EQ | | B |
| VHPPC112LY2-1 | 572 574 0246 | 33- 30 | AF | DS | | B |
| VHPSEL2213C// | 572 574 0082 | 30- 12 | AB | DD | | B |
| VHPSLR322MC3F | 572 574 0292 | 30- 13 | AC | DJ | | B |
| VHPSLR322VC3F | 572 574 0293 | 30- 14 | AC | DJ | | B |
| VHRS11MD5V/-1 | 572 574 0005 | 33- 31 | AF | DS | | B |
| VHRS21MD3V/-1 | 572 575 0031 | 33- 31 | AE | DS | | B |
| VHSTM1641P-LF | 572 575 0139 | 33- 32 | AQ | EQ | | B |
| VHSTM1661P-LF | 572 575 0140 | 33- 32 | AQ | EQ | | B |
| VHSTM1661S-LF | 572 575 0116 | 33- 33 | AK | EB | | B |
| VRD-HT2EY101J | 500 581 5010 | 34- 27 | AA | DD | | C |
| VRD-HT2EY102J | 507 581 5010 | 30- 15 | AA | DD | | C |
| VRD-HT2EY103J | 505 581 5044 | 29- 59 | AA | DD | | C |
| 〃 | 505 581 5044 | 30- 16 | AA | DD | | C |
| VRD-HT2EY105J | 500 581 0464 | 33- 34 | AA | DD | | C |
| VRD-HT2EY123J | 590 581 0040 | 30- 17 | AA | DD | | C |
| VRD-HT2EY163J | 579 581 0136 | 34- 36 | AA | DD | | C |
| VRD-HT2EY271J | 572 581 0032 | 29- 60 | AA | DD | | C |
| VRD-HT2EY472J | 507 581 5018 | 34- 37 | AA | DD | | C |
| VRD-HT2EY474J | 590 581 0039 | 33- 34 | AA | DD | | C |
| VRD-HT2EY513J | 581 581 0002 | 30- 18 | AA | DD | | C |
| VRD-HT2EY561J | 579 581 0166 | 30- 19 | AA | DD | | C |
| VRD-HT2EY562J | 595 581 0480 | 30- 20 | AA | DD | | C |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. Ex. | PRICE R. Ja. | NEW | P/R |
|---|---|---|---|---|---|---|
| VRD-HT2EY621J | 595 581 0436 | 29- 61 | AA | DD | | C |
| VRD-HT2EY750J | 588 581 0062 | 30- 21 | AA | DD | | C |
| VRD-HT2HY474J | 572 581 0035 | 33- 34 | AA | DD | | C |
| VRNHT2EK2003F | 572 581 0089 | 33- 35 | AA | DD | | C |
| VRNHT2HK1000F | 572 581 1788 | 29- 62 | AC | DD | | C |
| VRS-HT2HA101J | 572 581 0062 | 33- 36 | AA | DD | | C |
| VRS-HT2HA121J | 572 581 0041 | 33- 37 | AA | DD | | C |
| VRS-HT2HA201J | 572 581 0058 | 33- 37 | AA | DD | | C |
| VRS-HT2HA271J | 572 581 1789 | 34- 28 | AB | DD | | C |
| VRS-HT3DA1R0J | 567 581 0073 | 29- 63 | AB | DD | | C |
| VRS-HT3LAR22J | 595 581 0245 | 29- 64 | AC | DD | | C |
| VRS-RE3LA103J | 572 581 0374 | 33- 38 | AB | DD | | C |
| VRS-ST3AB180J | 572 581 1614 | 29- 65 | AA | DD | | C |
| VRS-TS2AD101J | 500 581 5047 | 29- 66 | AA | DD | | C |
| VRS-TS2AD102J | 595 581 0137 | 29- 67 | AA | DD | | C |
| VRS-TS2AD103J | 501 581 5009 | 29- 68 | AA | DD | | C |
| VRS-TS2AD104J | 500 581 5039 | 29- 69 | AA | DD | | C |
| VRS-TS2AD105J | 500 581 5040 | 29- 70 | AA | DD | | C |
| VRS-TS2AD152J | 500 581 5043 | 29- 71 | AA | DD | | C |
| VRS-TS2AD153F | 595 581 0179 | 29- 72 | AA | DD | | C |
| VRS-TS2AD162J | 595 581 0183 | 29- 73 | AA | DD | | C |
| VRS-TS2AD202J | 596 581 0126 | 29- 74 | AA | DD | | C |
| VRS-TS2AD222J | 501 581 5011 | 29- 75 | AA | DD | | C |
| VRS-TS2AD242D | 572 581 1803 | 29- 76 | AA | DD | | C |
| VRS-TS2AD242J | 578 581 0026 | 29- 77 | AA | DD | | C |
| VRS-TS2AD243F | 572 581 1777 | 29- 78 | AB | DD | | C |
| VRS-TS2AD243J | 595 581 0214 | 29- 79 | AA | DD | | C |
| VRS-TS2AD271F | 585 581 0091 | 29- 80 | AA | DD | | C |
| VRS-TS2AD272J | 500 581 5094 | 29- 81 | AA | DD | | C |
| VRS-TS2AD392J | 595 581 0117 | 29- 82 | AA | DD | | C |
| VRS-TS2AD472F | 572 581 0445 | 29- 83 | AA | DD | | C |
| VRS-TS2AD472J | 501 581 5013 | 29- 84 | AA | DD | | C |
| VRS-TS2AD473F | 572 581 0447 | 29- 85 | AA | DD | | C |
| VRS-TS2AD473J | 500 581 5051 | 29- 86 | AA | DD | | C |
| VRS-TS2AD561J | 501 581 5014 | 29- 87 | AA | DD | | C |
| VRS-TS2AD562J | 500 581 5056 | 29- 88 | AA | DD | | C |
| VRS-TS2AD621J | 595 581 0340 | 29- 89 | AA | DD | | C |
| VRS-TS2AD622F | 572 581 0419 | 29- 90 | AA | DD | | C |
| VRS-TS2AD622J | 595 581 0342 | 29- 91 | AA | DD | | C |
| VRS-TS2AD681J | 579 581 0095 | 29- 92 | AA | DD | | C |
| VRS-TS2AD682J | 501 581 5015 | 29- 93 | AA | DD | | C |
| VRS-TS2AD750F | 572 581 1653 | 29- 94 | AA | DD | | C |
| VRS-TS2AD750J | 596 581 0106 | 29- 95 | AA | DD | | C |
| VRS-TS2AD751F | 572 581 1716 | 29- 96 | AA | DD | | C |
| VRS-TS2AD752D | 572 581 1801 | 29- 97 | AA | DD | | C |
| VRS-TS2AD822J | 595 581 0305 | 29- 98 | AA | DD | | C |
| VSDTA123YS/-1 | 572 576 0352 | 29- 99 | AB | DJ | | B |
| VS2SA673-C/-1 | 502 576 0001 | 29- 100 | AE | DS | | B |
| VS2SB1240-/-1 | 572 576 0451 | 30- 22 | AD | DJ | | B |
| VS2SC945///-1 | 541 576 0023 | 29- 101 | AD | DJ | | B |
| VS2SD1207-T-1 | 505 576 5021 | 34- 29 | AD | DJ | | B |
| VS2SD1991A/-1 | 572 576 0506 | 30- 23 | AD | DJ | N | B |
| VS2SD2045-/-1 | 572 576 0379 | 34- 30 | AH | EB | | B |
| VS2SJ380///-1 | 572 576 0428 | 34- 38 | AN | EG | | B |
| VS2SK1286//-1 | 572 576 0327 | 29- 102 | AH | DX | | B |
| 【X】 | | | | | | |
| XBBSD30P06000 | 541 970 5028 | 6- 28 | AA | DD | | C |
| XBBSD30P08000 | 571 970 0241 | 18- 20 | AA | DD | | C |
| XBBSD30P18000 | 572 970 0624 | 15- 20 | AA | DD | | C |
| XBBSD40P08000 | 572 970 0627 | 13- 25 | AA | DD | | C |
| 〃 | 572 970 0627 | 18- 57 | AA | DD | | C |
| XBBSD40P10000 | 577 970 0051 | 6- 10 | AA | DD | | C |
| 〃 | 577 970 0051 | 7- 27 | AA | DD | | C |
| XBBSD40P12000 | 572 970 0642 | 25- 16 | AA | DD | | C |
| XBBSD40P14000 | 572 970 1400 | 19- 71 | AA | DD | | C |
| XBPBN30P05K00 | 572 970 1588 | 12- 19 | AB | DD | | C |
| XBPBW30P06000 | 571 970 0321 | 15- 34 | AA | DD | | C |
| XBPSD20P03000 | 571 970 0115 | 18- 12 | AA | DD | | C |
| XBPSD30P04000 | 501 970 0024 | 25- 15 | AA | DD | | C |
| XBPSD30P06000 | 541 970 1080 | 8- 27 | AA | DD | | C |
| 〃 | 541 970 1080 | 14- 8 | AA | DD | | C |
| 〃 | 541 970 1080 | 33- 39 | AA | DD | | C |
| XBPSD30P08KS0 | 541 970 1097 | 15- 3 | AA | DD | | C |
| 〃 | 541 970 1097 | 34- 31 | AA | DD | | C |
| XBPSD30P08K00 | 541 970 0014 | 19- 77 | AA | DD | | C |
| 〃 | 541 970 0014 | 29- 103 | AA | DD | | C |
| 〃 | 541 970 0014 | 33- 40 | AA | DD | | C |
| XBPSD30P10K00 | 541 970 0015 | 33- 41 | AA | DD | | C |
| XBPSD30P10000 | 502 970 0009 | 25- 5 | AA | DD | | C |
| XBPSD30P16000 | 541 970 1103 | 20- 11 | AA | DD | | C |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. Ex. | PRICE R. Ja. | NEW | P/R |
|---|---|---|---|---|---|---|
| XBPSD30P18000 | 541 970 1118 | 9- 35 | AC | DD | | C |
| XBPSD30P20000 | 571 970 0176 | 25- 14 | AA | DD | | C |
| XBPSD40P06K00 | 541 970 1038 | 6- 24 | AA | DD | | C |
| 〃 | 541 970 1038 | 7- 9 | AA | DD | | C |
| 〃 | 541 970 1038 | 7- 29 | AA | DD | | C |
| 〃 | 541 970 1038 | 11- 40 | AA | DD | | C |
| XBPSD40P06000 | 541 970 0011 | 9- 23 | AA | DD | | C |
| 〃 | 541 970 0011 | 18- 51 | AA | DD | | C |
| 〃 | 541 970 0011 | 20- 8 | AA | DD | | C |
| XBPSD40P08ES0 | 572 970 1633 | 10- 62 | AA | DD | | C |
| XBPSD40P08KS0 | 541 970 0013 | 6- 54 | AA | DD | | C |
| XBPSD40P08K00 | 541 970 1106 | 20- 7 | AA | DD | | C |
| XBPSD40P10KS0 | 541 970 1107 | 20- 5 | AA | DD | | C |
| XBPSD40P12000 | 571 970 0447 | 18- 48 | AA | DD | | C |
| XBPSD40P25XS0 | 577 970 0052 | 20- 4 | AA | DD | | C |
| XBPSD40P30K00 | 572 970 0548 | 6- 45 | AA | DD | | C |
| 〃 | 572 970 0548 | 19- 57 | AA | DD | | C |
| XBSSE30P10000 | 572 970 0679 | 1- 11 | AA | DD | | C |
| XBTSC40P04000 | 577 970 0045 | 7- 12 | AA | DD | | C |
| XBTSE40P04000 | 572 970 1473 | 1- 21 | AA | DD | | C |
| XEBSD30P06000 | 578 970 0102 | 10- 38 | AA | DD | | C |
| 〃 | 578 970 0102 | 22- 9 | AA | DD | | C |
| XEBSD30P08000 | 578 970 0105 | 13- 6 | AA | DD | | C |
| 〃 | 578 970 0105 | 14- 28 | AA | DD | | C |
| 〃 | 578 970 0105 | 15- 31 | AA | DD | | C |
| XEBSD30P10000 | 578 970 0106 | 15- 18 | AA | DD | | C |
| XEBSD30P20000 | 572 970 1581 | 14- 36 | AA | DD | | C |
| XEBSD40P08000 | 572 970 0587 | 3- 10 | AA | DD | | C |
| 〃 | 572 970 0587 | 13- 26 | AA | DD | | C |
| 〃 | 572 970 0587 | 19- 20 | AA | DD | | C |
| 〃 | 572 970 0587 | 27- 29 | AA | DD | | C |
| XEBSD40P10000 | 572 970 0588 | 14- 53 | AA | DD | | C |
| XEBSD40P12000 | 578 970 0084 | 10- 56 | AA | DD | | C |
| 〃 | 578 970 0084 | 27- 16 | AA | DD | | C |
| XEBSD40P30000 | 572 970 1429 | 19- 68 | AA | DD | | C |
| XEBSE30P08000 | 595 970 0121 | 22- 5 | AA | DD | | C |
| XEBSE30P10000 | 595 970 0122 | 1- 28 | AA | DD | | C |
| XEBSE40P10000 | 572 970 0575 | 1- 17 | AA | DD | | C |
| XEBSF30P06000 | 572 970 0574 | 12- 23 | AA | DD | | C |
| XEBSF30P08000 | 577 970 0058 | 13- 24 | AA | DD | | C |
| XEBS230P08000 | 572 970 1522 | 14- 55 | AA | DD | | C |
| XEPSD20P08000 | 595 970 0144 | 2- 15 | AA | DD | | C |
| XEPSD30P06000 | 595 970 0135 | 25- 2 | AA | DD | | C |
| 〃 | 595 970 0135 | 26- 4 | AA | DD | | C |
| XEPSD30P08X00 | 595 970 0136 | 16- 12 | AA | DD | | C |
| 〃 | 595 970 0136 | 19- 75 | AA | DD | | C |
| XEPSD30P08000 | 595 970 0137 | 2- 16 | AA | DD | | C |
| 〃 | 595 970 0137 | 5- 1 | AA | DD | | C |
| 〃 | 595 970 0137 | 8- 19 | AA | DD | | C |
| 〃 | 595 970 0137 | 14- 6 | AA | DD | | C |
| 〃 | 595 970 0137 | 19- 30 | AA | DD | | C |
| 〃 | 595 970 0137 | 27- 15 | AA | DD | | C |
| XEPSD40P06000 | 578 970 0083 | 9- 1 | AA | DD | | C |
| XEPSD40P08000 | 572 970 0580 | 20- 3 | AA | DD | | C |
| 〃 | 572 970 0580 | 21- 3 | AA | DD | | C |
| 〃 | 572 970 0580 | 27- 7 | AA | DD | | C |
| XEPSD40P10000 | 572 970 0581 | 17- 9 | AA | DD | | C |
| 〃 | 572 970 0581 | 17- 38 | AA | DD | | C |
| XEPSD40P30000 | 572 970 0583 | 7- 31 | AA | DD | | C |
| XEPSD40P35000 | 572 970 0584 | 10- 17 | AA | DD | | C |
| XHBSD30P04000 | 578 970 0072 | 16- 4 | AA | DD | | C |
| XHBSD30P06000 | 541 970 1017 | 10- 21 | AA | DD | | C |
| 〃 | 541 970 1017 | 12- 21 | AA | DD | | C |
| 〃 | 541 970 1017 | 16- 1 | AA | DD | | C |
| XHBSD30P08000 | 578 970 0060 | 6- 63 | AA | DD | | C |
| 〃 | 578 970 0060 | 21- 26 | AA | DD | | C |
| 〃 | 578 970 0060 | 34- 32 | AA | DD | | C |
| XHBSD30P10000 | 572 970 0530 | 16- 7 | AA | DD | | C |
| XHBSD40P06000 | 578 970 0073 | 20- 34 | AA | DD | | C |
| XHBSD40P08000 | 578 970 0074 | 10- 49 | AA | DD | | C |
| 〃 | 578 970 0074 | 20- 22 | AA | DD | | C |
| 〃 | 578 970 0074 | 20- 32 | AA | DD | | C |
| 〃 | 578 970 0074 | 21- 41 | AA | DD | | C |
| XHBSD40P12000 | 572 970 1269 | 19- 41 | AA | DD | | C |
| XHBSD40P14000 | 572 970 1592 | 19- 86 | AA | DD | | C |
| XHBSE40P08000 | 572 970 0539 | 1- 14 | AA | DD | | C |
| 〃 | 572 970 0539 | 5- 12 | AA | DD | | C |
| 〃 | 572 970 0539 | 10- 1 | AA | DD | | C |
| 〃 | 572 970 0539 | 11- 2 | AA | DD | | C |
| 〃 | 572 970 0539 | 17- 37 | AA | DD | | C |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. Ex. | PRICE R. Ja. | NEW | P/R |
|---|---|---|---|---|---|---|
| XHBSE40P08000 | 572 970 0539 | 18- 9 | AA | DD | | C |
| 〃 | 572 970 0539 | 22- 22 | AA | DD | | C |
| XHBSE40P10000 | 595 970 0167 | 1- 3 | AA | DD | | C |
| 〃 | 595 970 0167 | 6- 64 | AA | DD | | C |
| 〃 | 595 970 0167 | 10- 11 | AA | DD | | C |
| 〃 | 595 970 0167 | 19- 14 | AA | DD | | C |
| 〃 | 595 970 0167 | 19- 59 | AA | DD | | C |
| XHPSD23P10000 | 572 970 0531 | 18- 55 | AA | DD | | C |
| XHPSD30P06000 | 588 970 0137 | 10- 28 | AA | DD | | C |
| 〃 | 588 970 0137 | 11- 28 | AA | DD | | C |
| 〃 | 588 970 0137 | 18- 1 | AA | DD | | C |
| XHPSD40P08000 | 572 970 0565 | 6- 26 | AA | DD | | C |
| 〃 | 572 970 0565 | 7- 37 | AA | DD | | C |
| 〃 | 572 970 0565 | 20- 10 | AA | DD | | C |
| XJBSD40P12000 | 572 970 0570 | 3- 2 | AA | DD | | C |
| 〃 | 572 970 0570 | 3- 24 | AA | DD | | C |
| XNESD30−24000 | 541 980 0002 | 12- 22 | AA | DD | | C |
| 〃 | 541 980 0002 | 19- 78 | AA | DD | | C |
| XNESF40−32000 | 572 980 0057 | 7- 24 | AA | DD | | C |
| 〃 | 572 980 0057 | 9- 33 | AA | DD | | C |
| XRESP20−03000 | 572 399 0065 | 8- 4 | AA | DD | | C |
| 〃 | 572 399 0065 | 10- 37 | AA | DD | | C |
| 〃 | 572 399 0065 | 13- 18 | AA | DD | | C |
| XRESP30−04000 | 571 399 0015 | 8- 15 | AA | DD | | C |
| XRESP30−05000 | 571 399 0017 | 10- 43 | AA | DD | | C |
| XRESP40−06000 | 509 399 5001 | 10- 44 | AA | DD | | C |
| 〃 | 509 399 5001 | 13- 37 | AA | DD | | C |
| 〃 | 509 399 5001 | 14- 35 | AA | DD | | C |
| 〃 | 509 399 5001 | 15- 13 | AA | DD | | C |
| 〃 | 509 399 5001 | 18- 37 | AA | DD | | C |
| 〃 | 509 399 5001 | 21- 6 | AA | DD | | C |
| XRESP50−06000 | 572 399 0063 | 6- 48 | AA | DD | | C |
| 〃 | 572 399 0063 | 11- 12 | AA | DD | | C |
| 〃 | 572 399 0063 | 14- 71 | AA | DD | | C |
| 〃 | 572 399 0063 | 15- 6 | AA | DD | | C |
| 〃 | 572 399 0063 | 17- 44 | AA | DD | | C |
| 〃 | 572 399 0063 | 18- 21 | AA | DD | | C |
| 〃 | 572 399 0063 | 19- 15 | AA | DD | | C |
| 〃 | 572 399 0063 | 21- 46 | AA | DD | | C |
| XRESP70−08000 | 571 399 0027 | 6- 2 | AA | DD | | C |
| 〃 | 571 399 0027 | 10- 7 | AA | DD | | C |
| 〃 | 571 399 0027 | 11- 5 | AA | DD | | C |
| 〃 | 571 399 0027 | 14- 32 | AA | DD | | C |
| 〃 | 571 399 0027 | 17- 1 | AA | DD | | C |
| 〃 | 571 399 0027 | 18- 15 | AA | DD | | C |
| 〃 | 571 399 0027 | 19- 5 | AA | DD | | C |
| 〃 | 571 399 0027 | 20- 25 | AA | DD | | C |
| 〃 | 571 399 0027 | 21- 51 | AA | DD | | C |
| XUBSD30P05000 | 572 970 0572 | 13- 23 | AA | DD | | C |
| XUPSD30P04000 | 507 970 0003 | 14- 11 | AA | DD | | C |
| XWHSD30−05070 | 572 990 0246 | 22- 8 | AA | DD | | C |
| XWHSD30−05080 | 500 990 0026 | 13- 39 | AA | DD | | C |
| 〃 | 500 990 0026 | 16- 5 | AA | DD | | C |
| XWHSD30−08100 | 505 990 5001 | 5- 4 | AA | DD | | C |
| 〃 | 505 990 5001 | 22- 12 | AA | DD | | C |
| XWUSD50−06100 | 572 990 0452 | 9- 41 | AA | DD | | C |
| XWVSD40−05000 | 572 990 0241 | 27- 28 | AA | DD | | C |
| XXXSP30L15000 | 572 970 1449 | 16- 34 | AB | DD | | C |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. Ex. | PRICE R. Ja. | NEW | P/R |
|---|---|---|---|---|---|---|

SHARP

**COPYRIGHT © 1997 BY SHARP CORPORATION**

All rights reserved.
Printed in Japan.
No part of this publication may be reproduced,
stored in a retrieval system, or transmitted,
in any form or by any means,
electronic, mechanical, photocopying, recording, or otherwise,
without prior written permission of the publisher.

**SHARP CORPORATION**
Printing & Reprographic Systems Group
Quality & Reliability Control Center
Yamatokoriyama, Nara 639-11, Japan
December 1997 Printed in Japan Ⓝ